

Model: EB-SOC60G

FCC ID: WR925SC1AG0ARC

IC: 7981A-25SC1AG0ARD

Radar Board Host Installation Assembly

For Models ECB601 and ECB501 only


Version 1

December 29, 2025

ecobee


Disassembly - Remove Rear Housing

1. Remove the 4 screws holding the backing plate in place
2. Remove rear cover
3. Using a plastic wedge, lift the rear housing away from the front housing



Screw Torque
6.0 +/- 0.2 kgf-cm

Disassembly – Gaskets and Connectors






Wire
connectors

FFC Flex
Connector


Gaskets

6. Remove and set aside the two gaskets
7. Detach the speaker wire connector by gently tugging up.
8. Open FFC flex connector drawer
9. Gently tug the FFC flex connector up to detach




Front Housing to Rear Housing Disassembly

1. Pull apart both sub assembly halves. Ensure FPC Cable and speaker connector are loose during disassembly.



Disassembly – Front Housing Radar Board PCBA Connections

FFC Flex
Connector




1. Open FFC flex connector
2. Remove FFC flex cable from PCBA connector


Front Housing – Radar Board Insertion and removal



1. Ensure orientation of radar board is correct
2. Insert radar board into the LDS frame
3. Reverse the process to remove the radar board




Front Housing – PCBA Connections



1. Insert Radar flex into PCBA connector, check the silk screen line is parallel with connector.
2. Insert Radar FFC flex into connector.
3. Close connector.

Assembly – Gaskets and Connectors





Wire
connectors

FFC Flex
Connector


Gaskets

6. Insert the two gaskets
7. Connect the speaker wire connector by lining up the connector and gently pushing down.
8. Open FFC flex connector drawer
9. Gently push the FFC flex connector in and close the drawer to latch flex in



Front Housing to Rear Housing Assembly


1. Bring both sub assembly halves together as a clamshell. Ensure FPC Cable does not get caught underneath during assembly.




Full Unit Assembly – Rear Cover

Photos for reference purposes only

Torque
6.0 +/- 0.2 kgf-cm



1. Place rear cover into opening of housing.
2. Insert and torque 4x screws.
3. Torque screws in the following pattern as labelled below.



Integration instructions

Regulatory Approvals

This Limited Modular Approved device complies with FCC 15.255 & 15.209 rules and RSS-210 requirements. The host device manufacturer is responsible for compliance to any other FCC/ISED rules that apply to the host not covered by the modular transmitter grant certification. The final host device will require Part 15 Subpart B/ICES-003 compliance testing with the modular transmitter installed.

This module is not sold separately and is not intended/installed to be used in any host except for Ecobee Inc. Models ECB601 and ECB501 and in case where the module will be integrated in other non-identical hosts in the future, we will expand the LMA to include the new hosts after an appropriate assessment to the FCC/ISED rules.

Integration instructions for host device manufacturers can be found below and are compliant with the KDB 996369 D03 OEM Manual v01.

Specific Operational Use Conditions

The module is tested for mobile RF exposure use conditions. Using the module for portable conditions will require additional assessment though a Class II permissive change or a change in FCC ID through a new application.

The host manufacturer installing this module into their product must ensure that the final product complies with the FCC and/or ISED requirements by a technical assessment or evaluation against the FCC and/or ISED rules. The host manufacturer must be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The host's end-user manual shall include all required regulatory information/warning as shown in this manual.

The module are not permitted to be used in satellites and aircrafts.

Limited Module Procedure

This limited module approved transmitter does not have a RF shield over the transmitter portion of the device and the transmitter is not tested in stand-alone configuration. The end host shall ensure spurious radiated emissions meets FCC and ISED rules.

Integration instructions Continued

RF Exposure Conditions

A 20 cm minimum distance must be maintained between the antenna and the users for the host device this module is integrated into. Under such configuration, the FCC radiation exposure limits set forth for an uncontrolled environment can be satisfied. Further RF exposure shall be re-evaluated to the scenario of portable and co-located use.

Antenna

Antenna is integrated in the RF chip. Tx antenna gain is 3 dBi. No external antenna connection is required for normal function of the radar.

User Manual of the End Product

In the user manual of the end product, the end user must be informed to keep at least 20 cm separation with the antenna while this end product is installed and operated. The end user must be informed that the FCC radio-frequency exposure guidelines for an uncontrolled environment can be satisfied.

The end user must also be informed that any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

Label and compliance information

The final end product must be labeled, in a font size of 4pt or greater, in a visible area with the following:

Contains FCC ID: WR925SC1AG0ARC

Contains IC: 7981A-25SC1AG0ARD

Integration instructions Continued

Additional Notice

This module is intended for internal use with the specific platform ECB601 and ECB501. The integrator is responsible for the compliance to all the rules that apply to the product into which this certified limited RF module is integrated. Additional testing and certification may be necessary when multiple transmitter are used.

A Class II permissive change is required if the module is integrated in different hosts.

1. Radiated power (EIRP) must be tested per ANSI C63.10-2020, KDB 36244 D01 and comply with FCC Part 15.255(c), RSS-210 J.3 requirements. After the module is installed into the host device, the fundamental Emission power (EIRP) must not exceed the module granted power.
2. Transmitter Spurious Emissions must be tested per ANSI C63.10-2020, KDB 364244 D01 and comply with FCC Part 15.255(d), 15.209 and RSS-210 J.4, J.5.
3. If connected to public AC Mains network, an assessment of conducted emissions should be performed as per FCC Part 15.207 and ICES-003.
4. RF Exposure should be re-examined if the use case has been changed to ensure the RF exposure compliance from the initial filling is still applicable. If no longer applicable, KDB 447498 D04 and other appropriate FCC RF Exposure procedure should be consulted and consideration of C2PC procedure if required per FCC policy.

A 20 cm minimum distance has to be able to be maintained between the antenna and the users for the host this module is integrated into. Under such configuration, the radiation exposure limits set forth for a population/ uncontrolled environment can be satisfied. Further RF exposure shall be re-evaluated to the scenario of portable, and collocated use.