VanTop

User Manual

Moment 4U

VanTop

- APP: VanTop Surveillance
- Support: support@vantop.com
- Support: www.vantop.com

ENGLISH

PACKING LIST

PACKING LIST

Tip

- For mounting steps, you can install using your Moment 4U camera or the mounting bracket. Please choose the one that suits you best.
- Choose a mounting location that ensures a flat surface.

MOUNTING

PRODUCT OVERVIEW

PRODUCT OVERVIEW

Please make sure the surface is smooth and clean before mounting.

PRODUCT OVERVIEW

Connect the USB-C to the camera and the other end to a power source (5V, 1A or more).

SAFETY WARNINGS

Please be sure to observe the following warnings, to ensure the safe installation and prevent injury or equipment damage caused by improper use.

- Do not disassemble the camera.
- Do not expose the device to extreme humidity or dust, corrosive substances, or salt spray. Avoid placing the camera near heating or cooling units, such as radiators, heaters, or air conditioners.
- Do not expose the device to the hot sun, direct sunlight or high temperatures.
- Keep the device away from water and liquids to prevent electrical hazards.
- Do not use the device if the power cable shows signs of damage, such as fraying or exposed wires. Stop using the device immediately and replace the cable with a compatible one.
- Only use the power cable that is provided with the device. Using an incompatible cable may damage the device and void the warranty.
- Do not place heavy objects on the power cable, as this can cause damage and pose a fire hazard.
- Do not attempt to repair the device yourself. Contact customer support for assistance.

CAMERA MODES

Press the power button to turn on the camera. Press the button to cycle through the modes.

How to Switch Camera Modes

CAMERA MODES

CAMERA MODES

ALBUMS

ALBUMS

2. Delete the unlimited photos saved

- Enter into the camera settings.
- Click Delete Files, then choose Delete All Files or Delete Single File to delete the unlimited photos saved.

ALBUMS

SETTINGS

SETTINGS

APP

Option 1

Search and download **Moment** in APP Store or Google Play, or scan the QR code below to download.

Option 2

Scan the QR code below to download.

WiFi CONNECTION

- Turn on Camera's WiFi
- Search and connect to the camera's hotspot from the app when prompted.

- Open the app
- Click the Add Device button on the upper right corner
- Connect to Camera's WiFi
- Enter the camera's WiFi password (WiFi settings, then camera's hotspot name)
- Launch the App's Preview

WiFi CONNECTION

MAINTENANCE

MAINTENANCE

SPECIFICATION

Video Codec	H.264 Super, H.265 Main Profile
Video Codec	H.264 HP, MP
Night Vision	IR
Touch Screen	2.0" IPS LCD
Wireless Local	Support up to 128GB micro SD card
Internal Flash Memory	MP4 (ITU - H.264)
Default Resolution	Video: 2.5K + 2.5K (Max.) Photo: 5MP
Voice Recognition	Support
Photo Resolution	2592*1944 (5MP)
Video Resolution	4K@25fps,2K@30fps,1080P@30fps,720P@30fps,480P@30fps,360P@30fps,240P@30fps

SPECIFICATION

OS	Android, Apple iOS
WiFi	2.4 GHz/5G, IEEE802.11a/b/g/n
Speaker	Built-in
Waterproof	IP67 with waterproof case

FCC Statement

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

MAINTENANCE

- Clean the camera lens cover by the following steps:
- Use an anti-static compressed air duster to blow away dust and debris.
- Moisten the dedicated cleaning cloth with a small amount of lens cleaning solution.
- Gently wipe the lens in a circular motion, starting from the center and moving outward.
- Use a dry cloth to remove any remaining moisture.
- Avoid touching the lens with your fingers.

If Camera Cannot:

- Ensure the camera is compatible with FCC standards and has the FCC certification.
- Check the camera's settings to confirm that it is set to operate on the frequency bands allowed by the FCC.

FCC Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

A product approved and certified as an ISED Canada Licence-Exempt Radio Apparatus (Exempt radio apparatus that operates with licence) that is a transmitter or contains a transmitter, shall display the following:

- The term "Contains transmitter module IC: 20098-VT4" or "Contains transmitter module 20098-VT4" or similar wording that expresses the same meaning.
- The exact model name or number of the ISED Canada Licence-Exempt Radio Apparatus (Exempt radio apparatus that operates with licence) that is a transmitter or contains a transmitter.

The device is compliant with RF exposure guidelines, when the device is placed at minimum 20 cm from operator and nearby persons.

IC Statement Statement

This equipment complies with IC ICES-003 of Canada.

Cet appareil est conforme avec NMB-3 du Canada.

ISED Warning

This device complies with ISED RSS-247 & RSS-GEN of Canada. CAN ICES-3 (B)/NMB-3(B)

Cet appareil est conforme avec NMB-3 du Canada. Cet appareil est conforme aux normes CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliant with RF exposure guidelines, when the device is placed at minimum 20 cm from operator and nearby persons.

L'appareil est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. L'appareil doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

CAUTION

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

ATTENTION: Il y a un risque d'explosion si la batterie est remplacée par un type incorrect. Mettre au rebut les batteries usagées conformément aux instructions.

CAMERA MODES

Turn on the camera and press the power button to enter the video recording mode.

Press the button to start recording. Press the button again to stop recording.

ALBUMS

SETTINGS

- Tap the gear icon to enter the settings.
- Tap the Time Stamp.
- Select ON to turn the date/time stamp function on.
- Select OFF to turn the date/time stamp function off.
- Tap the back button to save the settings and return to the previous menu.

The power cord can be extended to a maximum length of 3 meters.