



☎ - 888.493.5559

✉ - INFO@ESLVISION.COM

🌐 - WWW.ESLVISION.COM

📍 - 1136 SOUTH 3600 WEST SALT LAKE CITY, UTAH 84104

User manual

Model: ESL-KNX-RPP-001


1. This product (module) is used in ESL Visions ESL-DVAN-SLR/PNL product series. The module can be connected to a DVAN driver to achieve 0-10 dimming. It can also work with an ESL VISION App to perform other functionalism.
2. To download ESL Vision's APP, you can visit www.eslvision.com or find it in the app store
3. Once the module is learned-in via the ESL Vision APP. The user will be able to set specified settings such as 0-10V Dimming, high and trim, LED driver ON / OFF, and real-time power monitoring, grouping and other such features.
4. Please make sure this product is set up with the corresponding DVAN driver model.
5. For how to use ESL Vision's app to control the TAP Module, please refer to the ESL Vision app manual.
6. Bluetooth Version: V4.1

APP introduction:



The Login page:

- 1: new account registration
- 2: account login, forgot password, you can retrieve Password.




Country/Region 中国(+86) >
 password
 forgot password 2
 1 create account



< REGISTER
 3 Country/Region 中国(+86) >
 Mobile number/Email address
 Verification code Get code
 4 Set password
 Confirm password
 OK

3: For new account registration, you can choose Mobile number or Email address to register according to the country or region. Mobile number, Email address accept the verification code, and also serve as a login account.

4: When registering, set the account password at the same time.



5: PRESETS

6: DEVICES

7: GROUPS

8: SCENES


9: SCHEDULES

10: ALERTS

11: REPORTS

12: ACCOUNT

13: ABOUT




5: PRESETS:

5.1 Power of ESL DVAN drivers are : 25W, 45W, 75W, among which the maximum power is 75W.

5.2. Color temperature: adjustable arbitrarily between 2700K-6500K.

5.3. Delay for turning on the light and delay for turning off the light.

5.4. return to Home page



6: DEVICES: All devices that have been added will be on this list, including: Lamps, Power pack, Sensor, Wall Switch, Gateway.

6.1 Click "+" to learn devices

6.2 Show all Devices

6.3 Ungrouped: Show Devices that are not currently in a group

6.4 Device List :

a) Tap the item to Enter the equipment adjustment page.

b) Tap and hold: Enter the function to modify the device name and delete (the device cannot be deleted when it is not powered on. If you want to delete it forcibly, you can scan it with the app to see if the device that was forcibly deleted can be reset from the software. If not, You need to reset the Bluetooth module by turn the power on and of for 6 times each).



7: GROUPS

7.1 Create new Group


7.2 Turning the Group ALL ON or ALL OFF.

7.3 Tap to Enter the group function control center.

Tap and hold to Enter the function for changing the device name or delete the device

(Hint: there are devices in the group, you cannot delete them). OFF or ON control a single group (OFF or ON in the upper right corner of the software interface)


8: SCENES: Scene selection.



9: SCHEDULES:

9.1 Create a SCHEDULES for, GROUPS, LAMPS, Power Pack.

9.2 A List of the schedules that have been created.



10: ALERTS

Shows the offline devices which cannot be operated.



11: REPORTS

If you have any problem or questions regarding to the ESL App, you may use the "REPORTS" to send an email to ESL team for consultation.



- 888.493.5559
- INFO@ESLVISION.COM
- WWW.ESLVISION.COM
- 1136 SOUTH 3600 WEST SALT LAKE CITY, UTAH 84104

ACCOUNT

Nick name 1 None

Account 53.com

Password 2 Click to modify

Network 3 1

LOGOUT

12: ACCOUNT

12.1 Edit Name.

12.2 Edit password.

12.3 You can switch to different network within the same account.

ABOUT

ESL VISION

Version 1.1.3

Website <http://www.eslvision.com/>

13: ABOUT

You can view the App version website: Click the URL to view more products on ESL website.



☎ - 888.493.5559

✉ - INFO@ESLVISION.COM

🌐 - WWW.ESLVISION.COM

📍 - 1136 SOUTH 3600 WEST SALT LAKE CITY, UTAH 84104

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.