





03. GT-E321{B Label Location



0.13T±0.01)

The label is placed inside the battery compartment