


Package contents

- Device
- Ejection pin
- USB power adaptor
- Quick start guide
- USB cable

- The items supplied with the device and their images may vary by region.
- The charger should remain close to the electric socket and easily accessible while charging.

Installing a nano-SIM card (sold separately)

▶ Single SIM models:




Accessing more information

Visit www.samsung.com to view device information and more. To view the user manual, scan the QR code on the front cover. You may incur additional charges for accessing the Internet.



▶ Dual SIM models:



Support for single SIM and dual SIM models may vary by region.

Safety information

Read all safety information before using the device to ensure safe and proper use. You can view more safety information in the safety information menu of the Settings app.

Follow the warnings below to prevent incidents, such as fires or explosions, injuries, or damage to the device

- Your device contains magnets. Keep a safe distance between your device and objects that may be affected by magnets such as credit cards and implantable medical devices. If you have an implantable medical device, consult your physician before use.
- Do not expose the device to physical impact or damage.
- Use only Samsung-approved batteries, chargers, and cables specifically designed for your device.
- Prevent the multipurpose jack and battery terminals from coming into contact with foreign materials such as metal, liquids, or dust.

- If any part of the device, such as the glass or acrylic body, is broken, smokes, or emits a burning odor, stop using the device immediately. Use the device again only after it has been repaired at a Samsung Service Center.
- Do not turn on or use the device when the battery compartment is exposed.
- Do not disassemble or reuse the battery.
- The device can be used in locations with an ambient temperature of 0 °C to 35 °C. You can store the device at an ambient temperature of -20 °C to 50 °C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery's lifespan.



To prevent possible hearing damage when using a headset, do not listen to sound at high volume for long periods.

If your device is frozen and unresponsive, press and hold the Side key and the Volume Down key simultaneously for more than 7 seconds to restart it.

It is recommended not to use fixed graphics on part or all of the touchscreen for extended periods. Doing so may result in afterimages (screen burn-in) or ghosting.

Federal Communication Commission (FCC)

Certification information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

If your device required FCC approval, you can view the FCC certification by opening Settings → About phone → Status or Status information.

Specific Absorption Rate (SAR) certification information

Your mobile is designed not to exceed the limits for exposure to radio waves recommended by international guidelines.

For SAR values specific to your model, visit www.samsung.com/sar and search for your region and device with the model number.

Samsung Limited Warranty Summary

Samsung Electronics Co., Ltd. ("Samsung") warrants this product against defects in material, design and workmanship to end-users who legally acquire possession of the product ("Customer") for one year from the original date of purchase or receipt of the product from Samsung or its authorized distributor. This Warranty will not be valid for any defect caused (howsoever) by wear and tear, accident, misuse, neglect, rough handling or abuse. This Warranty will cease to be valid when any alterations or repairs are carried out by unauthorized persons. This warranty will be subject to the terms and detailed information available at samsung.com/support/warranty (please select the original country of sale to access the relevant local Samsung website and then navigate to the warranty condition applicable to the product).

To receive Warranty service, contact Samsung customer service, or visit a Samsung authorized service center. Samsung will, at its own discretion, repair or replace any such defects in the product at no additional charge. Available service options may vary depending on the country in which service is requested and may be limited to the original country of sale. Repair parts or replacement of the product will be furnished on an exchange basis, and will either be new or refurbished parts (where legally permissible). All original items replaced in the performance of services shall become the property of Samsung and the new or replacement parts will become the property of the Customer. This Warranty is only valid when the Customer presents the original purchase invoice or receipt for the product (from when the product was first sold to the original Customer) which must not be defaced in any way and must show the purchase date, dealer name, and model name/number (where legally permissible).

This Warranty does not affect Customers' statutory or other legal rights under any applicable law. This Warranty will be the Customer's sole and exclusive remedy unless otherwise stated in the applicable law, which may vary from country to country. This is not an international warranty and is valid only in the original country of sale.

English (LTN)