


6. Push the memory module into the slot at a slight angle until the connectors are fully engaged.



7. Push down on the edge of the memory module until the module snaps into place.
8. Align the memory module compartment door with the compartment and push the door down until it snaps into place.
9. Reinstall the screw you removed in step 2.
10. Turn on the computer and perform a complete POST to check the memory integrity.

Docking Options

Contact your reseller for a list of docking options available for your Notebook computer. User's manuals are included with the docking options.

Wireless LAN

The wireless LAN option allows easy connection to large or small office networks while also providing freedom from the constraints of cables and sockets.

To setup and use the Wireless LAN, please refer to the Wireless Connection section of the manual.