



Operational Description

Section 1 : Hardware set up

A. Connecting yePP' to PC

- 1) Connect the USB cable to the USB port of the computer.
- 2) Turn the player on and connect the other end of the cable to the download connector.

Section 2 : Software set up

A. Installing Software on PC

- 1) Insert the Installation CD into the CD-ROM drive.
- 2) Click the next button on each successive window.

B. Formatting flash memory

- 1) Execute the MF Explorer.
Double click the icon the MF Explorer in your selected Folder.
- 2) Click "Format" and select.

C. Sending files to yePP'

Before sending files to your yePP' connect the yePP' to PC and click Refresh icon on the yePP' Explorer.

- 1) Execute the MF Explorer.
Double click the icon the MF Explorer in your selected Folder.
- 2) Turn on the yePP' by pressing
- 3) Click the Your Selected Folder Name on the MFO Explorer.
- 4) Click the your selected "Flash Memory" or "SmartMedia Card" Folder.
- 5) Select the file you would like to send to your yePP'
- 6) Click Write.

The selected file has been saved. Now you can listen to music with yePP'

D. Making MP3 files from an audio CD

- 1) Execute RealJukebox
Double click the icon of the Realjukebox on the desktop.
- 2) Insert an audio CD into the CD-ROM drive.
The CD information is displayed.
- 3) Select the track you would like to convert into MP3 file.
- 4) Click "Record Ctrl+R"
- 5) Recording status is displayed.