TOSHIBA
DVD VIDEO PLAYER / VIDEO CASSETTE RECORDER SD-V390
DVD
OPEN/CLOSE
VHS
EJECT
VIDEO
AUDIO
CHANNEL
dts
DIGITAL
DVD/VCR SELECT
DVD
VCR
STOP
PLAY
REWIND
PAUSE

ANT. IN
RF OUT
CAUTION
DVD EXCLUSIVE OUT
VHS IN 1
DVD/VHS OUT
COMPONENT VIDEO OUT
AUDIO OUT
R - AUDIO - R
L - AUDIO - L
VIDEO
VIDEO
Pr
Pb
Y
R
L
COAXIAL
S-VIDEO
COMPONENT
DIGITAL AUDIO OUT
OPTICAL
CAUTION
TOSHIBA