


---

## Test Setup photographs

---

### EUT Position: X-axis



## Test Setup photographs

### EUT Position: Y-axis






---

## Test Setup photographs

---

### EUT Position: Z-axis



## Test Setup photographs

### EUT Position: X-axis





---

## Test Setup photographs


---

### EUT Position: Y-axis



## Test Setup photographs

### EUT Position: Z-axis



## Test Setup photographs

