

· KOREAN
· ENGLISH



서울시 강남구 선릉동 320-8 OJU CTN B/D 320-8, Sungnae-Dong,
오주원/D Kangdong-Gu, Seoul, Korea
02-2225-8000 : Tel Tel: 82-2-2225-8000
02-2225-8080 : Fax Fax: 82-2-2225-8080
http://www.ojuctn.co.kr
http://www.asiansources.com/ojuctn.co
E-mail : sales@ojuctn.co.kr

PLUS FM USER GUIDE

Car - MP3 & Hands-free Kit



본 제품은 MP3 Player와 핸드폰에 동시에 연결, 차량 내에서 음악 청취기능은 물론
핸즈프리 킷으로도 이용하실 수 있습니다.

● 사용방법

1. 라디오 주파수 고정

PLUS FM 주파수를 선택한 후 자동차 내 라디오 주파수를 제품주파수와 동일하게 고정합니다.
지역별 FM 방송 주파수가 없는 곳을 선택합니다.
(선택가능 주파수 : 88.20MHz, 88.40MHz, 88.60MHz, 88.80MHz)

2. 음악 청취 기능

2-1. 제공되는 오디오 케이블로 각종 휴대용 오디오 기기(MP3 player, CD player, MD
player 등)의 오디오 출력단자와 PLUS FM의 오디오 입력단자를 연결합니다.
2-2. 오디오 기기가 작동되면, 자동차 FM 라디오를 통하여 음악을 감상할 수 있습니다.

3. 핸즈프리 기능


3-1. 제공되는 케이블로 휴대용 오디오 출력 단자와 PLUS FM의 핸즈프리 입력단자를
연결합니다.
3-2. 통화시 상대방의 음성은 자동차 라디오를 통하여 들을 수 있고, PLUS FM에 내장된
마이크로 깨끗한 통화를 하실 수 있습니다.

4. 오디오 홀드

음악 청취 중 휴대폰이 울리면 오디오 홀드 버튼을 눌러 핸즈프리기능으로 전환, 통화 후 다시
음악 청취기능으로 되돌아 갈 수 있습니다. (핸즈프리 ↔ 음악청취)

4. POWER 연결

DC 9V 건전지나 차량용 시가전원에 연결합니다.
※ 시가전원 연결시 건전지는 작동되지 않음.



Simply connect it to MP3 player & mobile phone and set the FM frequency.
It will offer you safe and pleasant driving.
(FM based wireless hands-free and music transmission function)

● How to use

1. Radio Frequency

Choose available FM frequency from PLUS FM selector and set the car radio to the
same frequency.
(88.20MHz, 88.40MHz, 88.60MHz, 88.80MHz are available)

2. For Music play

2-1. Connect an audio device(MP3 player, CD player, MD player) to audio
connector of plus FM by using provided cable.
2-2. While audio device is in operation, you can hear the music through FM car radio.

3. For Hands-Free

3-1. Connect a mobile phone to hands-Free connector of Plus FM by using provided
cable.
3-2. You can catch counter speaker's voice through FM car radio and send your voice
through built-in microphone of Plus FM

4. Audio Hold

You can switch each function with audio hold button.
(Hands-Free ↔ Music Play)

5. Power

DC 9V Battery or Car cigarette adapter.
※Note : When cigarette adapter is connected, battery power does not work.