

TUNE UP PROCEDURE NBE-20, NBE-100 AND NBE-250

The NBE Fm exciter series utilizes state of the art technology, therefore there is nothing for the end user to “tune” and setup is a breeze.

Please consult the users manual for setting the frequency via the front panel controls.

Power is adjusted by a small potentiometer located on the front of the unit. Power may be varied from zero to twenty watts. Power level as well as reflected power is indicated on the LCD display on the front of the unit.

Modulation adjust is adjusted in the same manner by a potentiometer on the back of the unit. Modulation for the main channel, SCA, etc are adjusted with a small jewelers tip screwdriver. Modulation levels for the composite input can be monitored on the front Panel LCD display.

The unit will operate on 90 – 220 VAX 60 or 50 HZ. This is automatically adjusted in the units power supply. No user intervention is required.