


Test Setup photographs (PCE)


EUT Position: X-axis



EUT Position: Y-axis



EUT Position: Z-axis




Test Setup photographs (PCE)


EUT with Dual Display: 0 degree




EUT with Dual Display: 180 degree



EUT with Dual Display: 360 degree



Test Setup Photo of Radiated Measurement (PCE)



Test Setup Photo of Radiated Measurement (PCE)

