

360智慧生活		单位:mm	比例:1:1
物料名称(Name)	Window Camera_海外说明书(图形化部分)		
材质(Material)	80g哑粉		
尺寸(Dimension)	平铺:100x700mm, 折后:100x100mm, 共14P(正反各7P)		
公差(Tolerance)	模切公差:±0.5mm, 印刷套印偏位:±0.2mm		
印刷(Printing)	80%K		
表面工艺(Coating)	/		
备注(remarks)	/		

正面

背面

What's in the box

Here is the camera

LED status description

Status Indicator Light	Operating mode description
Yellow	Camera is online
Blinking Blue	Video streaming in progress
Solid Green	Camera is booting / fault
Blinking Green	Camera is ready to setup

Set up your camera

Step 1: You can either scan the QR code or search for the "Botslab" app on the App Store or Google Play.

Scan the QR code to download Botslab APP

Install the camera

The camera is typically installed on a window pane. Prior to installation, check the lens view (see Botslab APP) and select a suitable location (the best location is an observed field of view, a height between 1.5m to 2.0m (5 ft to 6 ft), a generally unobstructed field of vision, a sturdy power cable is available to supply power to the camera, and that the location maintains a strong Wi-Fi signal. Use the included power adapter and cable to power the device.

What's in the box

Here is the camera

LED status description

Status Indicator Light	Operating mode description
Yellow	Camera is online
Blinking Blue	Video streaming in progress
Solid Green	Camera is booting / fault
Blinking Green	Camera is ready to setup

Set up your camera

Step 1: You can either scan the QR code or search for the "Botslab" app on the App Store or Google Play.

Scan the QR code to download Botslab APP

Install the camera

The camera is typically installed on a window pane. Prior to installation, check the lens view (see Botslab APP) and select a suitable location (the best location is an observed field of view, a height between 1.5m to 2.0m (5 ft to 6 ft), a generally unobstructed field of vision, a sturdy power cable is available to supply power to the camera, and that the location maintains a strong Wi-Fi signal. Use the included power adapter and cable to power the device.

What's in the box

Here is the camera

LED status description

Status Indicator Light	Operating mode description
Yellow	Camera is online
Blinking Blue	Video streaming in progress
Solid Green	Camera is booting / fault
Blinking Green	Camera is ready to setup

Set up your camera

Step 1: You can either scan the QR code or search for the "Botslab" app on the App Store or Google Play.

Scan the QR code to download Botslab APP

Install the camera

The camera is typically installed on a window pane. Prior to installation, check the lens view (see Botslab APP) and select a suitable location (the best location is an observed field of view, a height between 1.5m to 2.0m (5 ft to 6 ft), a generally unobstructed field of vision, a sturdy power cable is available to supply power to the camera, and that the location maintains a strong Wi-Fi signal. Use the included power adapter and cable to power the device.

What's in the box

Here is the camera

LED status description

Status Indicator Light	Operating mode description
Yellow	Camera is online
Blinking Blue	Video streaming in progress
Solid Green	Camera is booting / fault
Blinking Green	Camera is ready to setup

Set up your camera

Step 1: You can either scan the QR code or search for the "Botslab" app on the App Store or Google Play.

Scan the QR code to download Botslab APP

Install the camera

The camera is typically installed on a window pane. Prior to installation, check the lens view (see Botslab APP) and select a suitable location (the best location is an observed field of view, a height between 1.5m to 2.0m (5 ft to 6 ft), a generally unobstructed field of vision, a sturdy power cable is available to supply power to the camera, and that the location maintains a strong Wi-Fi signal. Use the included power adapter and cable to power the device.

What's in the box

Here is the camera

LED status description

Status Indicator Light	Operating mode description
Yellow	Camera is online
Blinking Blue	Video streaming in progress
Solid Green	Camera is booting / fault
Blinking Green	Camera is ready to setup

Set up your camera

Step 1: You can either scan the QR code or search for the "Botslab" app on the App Store or Google Play.

Scan the QR code to download Botslab APP

Install the camera

The camera is typically installed on a window pane. Prior to installation, check the lens view (see Botslab APP) and select a suitable location (the best location is an observed field of view, a height between 1.5m to 2.0m (5 ft to 6 ft), a generally unobstructed field of vision, a sturdy power cable is available to supply power to the camera, and that the location maintains a strong Wi-Fi signal. Use the included power adapter and cable to power the device.

What's in the box

Here is the camera

LED status description

Status Indicator Light	Operating mode description
Yellow	Camera is online
Blinking Blue	Video streaming in progress
Solid Green	Camera is booting / fault
Blinking Green	Camera is ready to setup

Set up your camera

Step 1: You can either scan the QR code or search for the "Botslab" app on the App Store or Google Play.

Scan the QR code to download Botslab APP

Install the camera

The camera is typically installed on a window pane. Prior to installation, check the lens view (

[illegible]

设计及变更记录 (Describe)	签名 (Name)	日期 (Date)
设计	敖南东	2025/12/2
调整内容	敖南东	2025/12/31
调整内容	敖南东	2026/01/22
变更IC机构	敖南东	2026/02/10