


Self-Powered Wireless Doorbell User Manual

Product Introduction:

The self-powered wireless doorbell, Generates power when pressed to transmit wireless signals. No Battery. No wiring. Simple installation. Eco-friendly.

Product Schematic:



Product Parameters:

Parameter	Transmitter	Receiver
Dimensions	L75*W40*H21mm	L89*W47*H26mm
Power Supply	Self-Powered	100V-250V 50/60Hz
Wattage		0.75W
Chime		60 types
Volume		≥50dB/1M
Distance	≥150 meters (open area)	
Frequency	433MHz	
Temperature	-20℃~+60℃	-10℃~+45℃

1

Installation Instructions:


1. Plug in the Receiver

Tips: It is recommended to plug the receiver at least 50cm above the ground, as placing it too close to the ground may affect signal strength.



2. Fix the Transmitter

Before fixing, test the remote control effect of the transmitter and choose a convenient position with good signal performance.



3. Press the transmitter to enjoy the convenience of the self-powered wireless doorbell.


Usage Instructions:

Pairing:

The set product is paired at the factory and can be used directly. To add a transmitter or receiver, follow the instructions below to perform one to many or many to one operations.

1. Power on the receiver, long press the ③ button until ① is steadily on, then release the button to enter pairing mode.
2. Press the transmitter, then Receiver ① blinks once to indicate successful pairing.

2



Reset pairing:


Power on the receiver, press and hold button ③ until indicator ① stays steadily on and then blinks 3 times, indicating that code clearing has succeeded.

Chime Change:

Short press button ③ to switch between Chimes until you find the one you want.

Volume Adjustment:

Short-press the ② to cycle through high, medium-high, medium-low, low, and mute modes.




3

AB door function (transmitter exclusive ringtone)

Bind a fixed chime to a specific transmitter, and the transmitter will always trigger a dedicated chime after binding, Not affected by the global settings of the receiver. Unbound transmitters still follow the current chime of the receiver.

1. Short press receiver ③ to switch to the target chime.
2. Press ②+③ simultaneously (for about 1 second), and release when you hear the "beep" prompt sound.
3. Press the target transmitter, and the exclusive chime binding is successful.



Troubleshooting:

Doorbell Not Ringing:

- A. Check if the receiver is plugged in and the socket is powered.
- B. Confirm pairing; try clearing codes and re-pairing.

Short Transmission Distance:

- A. Please avoid placing the transmitter and receiver near metal objects such as iron doors and windows to avoid affecting the transmission distance;
- B. Walls and ceilings can also affect transmission distance;
- C. Interference from other wireless devices.

4

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

5