

英文说明书

70*70mm 128g铜版纸对折

正面



IMPORTANT SAFETY INFORMATION:

Rest Go is intended to be used as a soothing on-the-go sound machine. Parents assume all responsibility for selecting volume and sound settings that are appropriate for their children. Never place against baby's ears or in a crib or bed. Always check with child's pediatrician prior to using any sound machine. Not a toy and not for teething. Do not leave the device charging next to your children. Never use in or near water, or if plastic housing is damaged or hot. Never disassemble. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Parameter specification

Model No: M9

Battery capacity: 1200mAh/3.7V/4.44Wh


Speaker size: Φ40/4Ω/3W

Play Time (Night light OFF) : About 15 hours

Play Time (Night light ON) : About 8 hours

Charging Time: About 1.5 hours

Storage time (fully Charged): 120 days




M9

User Manual

Thanks for using our wireless electronic products. To make good and full use of our products, please read the manual carefully before using . Notice: To avoid unnecessary troubles, please do NOT disassemble these products by yourself and please use the standard charger to charge.

反面

Product Overview



Track display

Timer display

Battery Level Display

Previous track

Next track

Night light

Power Switch/Play/Pause

Timer/Hold for Bluetooth

Volume down

Volume up

Button control

Hold on 1s: Power on

Hold on 3s: Power off

Tap once: Play/ Pause

Mode Switch: Tap once(1h/2h/4h/8h/OFF)

Hold on: Mode Switch (white noise mode/Bluetooth)

Night light: Click to switch 33%/66%/100%/OFF

Previous track:Tap once

Next track:Tap once

Volume up: Tap once

Volume down: Tap once

Track list

1 Brown Noise 1	16 Wheat field wind	30 Clock ticked
2 Brown Noise 2	17 Strong wind	31 Starlit sky
3 Brown Noise 3	18 Canyon breeze	32 Deep sea
4 White noise	19 Stream	33 Mother's heartbeat
5 Pink noise	20 Birds by stream	34 To pee pee
6 Insects sing	21 Campfire	35 Hmmm.
7 Countryside fields	22 Fireplace	36 Parenting music 1
8 Fan	23 Waves and gulls	37 Parenting music 2
9 Vintage fan	24 Soft waves	38 Parenting music 3
10 Industrial fan	25 Billows	39 Schubert's Lullaby
11 Light rain	26 Cicada chirp	40 Brahms's Lullaby
12 Moderate rain	27 Jungle birdsong	41 Handpan
13 Heavy rain	28 Rain & croak	42 Windowsill
14 Thunderstorm	29 Winter Train	43 Piano keys
15 Breeze		

Bluetooth Connection

1.Long press and hold the power switch to turn on.

2.Hold on the Bluetooth key to switch to Bluetooth mode and enter the waiting pairing state.



3.Turn on Bluetooth function on your phone and search for **【M9】** and connect it.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.