






NTNV-N41-PC2-30-30-M-DFT-QPSK-Outter_Full-3
0-1000-Ant1-PASS



NTNV-N41-PC2-30-30-M-DFT-QPSK-Outter_Full-1
000-3000-Ant1-PASS



NTNV-N41-PC2-30-30-M-DFT-QPSK-Outter_Full-3
000-18000-Ant1-PASS




NTNV-N41-PC2-30-30-M-DFT-QPSK-Outter_Full-1
8000-30000-Ant1-PASS





NTNV-N41-PC2-30-30-M-DFT-QPSK-Edge_1RB_
Left-30-1000-Ant1-PASS





NTNV-N41-PC2-30-30-M-DFT-QPSK-Edge_1RB_
Left-1000-3000-Ant1-PASS





NTNV-N41-PC2-30-30-H-DFT-QPSK-Outer_Full-3
0-1000-Ant1-PASSNTNV-N41-PC2-30-30-H-DFT-QPSK-Outer_Full-1
000-3000-Ant1-PASSNTNV-N41-PC2-30-30-H-DFT-QPSK-Outer_Full-3
000-18000-Ant1-PASSNTNV-N41-PC2-30-30-H-DFT-QPSK-Outer_Full-1
8000-30000-Ant1-PASSNTNV-N41-PC2-30-30-H-DFT-QPSK-Edge_1RB_
Left-30-1000-Ant1-PASSNTNV-N41-PC2-30-30-H-DFT-QPSK-Edge_1RB_
Left-1000-3000-Ant1-PASS












NTNV-N41-PC2-30-40-H-DFT-QPSK-Outter_Full-3
0-1000-Ant1-PASSNTNV-N41-PC2-30-40-H-DFT-QPSK-Outter_Full-1
000-3000-Ant1-PASSNTNV-N41-PC2-30-40-H-DFT-QPSK-Outter_Full-3
000-18000-Ant1-PASSNTNV-N41-PC2-30-40-H-DFT-QPSK-Outter_Full-1
8000-30000-Ant1-PASSNTNV-N41-PC2-30-40-H-DFT-QPSK-Edge_1RB_
Left-30-1000-Ant1-PASSNTNV-N41-PC2-30-40-H-DFT-QPSK-Edge_1RB_
Left-1000-3000-Ant1-PASS

