

GTX26 SMART WATCH

Operation Manual



Thanks for purchasing this product.
Please read this Manual carefully before use.

Model	GTX26	Screen Type	1.73" -AMOLED
Battery Capacity	3.85V/200mAh	Charging Voltage	5V±0.2v
Charging Time	2hours	Battery Life	5-7Day
Waterproof level	3ATM	Weight of Product	38.8g
Operating Temperature	-10°C-50°C	Bluetooth Version	5.3
Product Frequency	2402-2480MHz	Max. transmission Power Consumption	8.13




Scan the QR code
for more function information



Quick start guide

(EN)

1. Product overview



Physical button operation

Short press

- To return.
- To wake the screen when it is off.


Long press

- When powered off, press and hold for 2 seconds to power on.
- When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.




Note: Charge the watch to activate it before first use. The original power adapter must be used for charging.

Long press the button to turn on the watch.

Power Off

Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.



App downloads and pairing

1. App downloads

Download and install the "VeryFit" app on the App Store, Google Play or by scanning the QR code below.



2. Pairing

Turn on VeryFit app -> Activate Bluetooth connection on your phone -> Search on the app for the device to pair with (or scan the QR code on the device) -> Finish binding on the app (or on the device).

Screen operation

Swipe up/down


- To toggle through menu.
- To view long text/details.

Swipe left/right

- To toggle through menu.

(JP)

1. 製品概要



Physical button operation

Short press

- To return.
- To wake the screen when it is off.


Long press

- When powered off, press and hold for 2 seconds to power on.
- When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.



Note: Charge the watch to activate it before first use. The original power adapter must be used for charging.

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.

Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Long press the button to turn on the watch.

Power Off
Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Download and install the "VeryFit" app on the App Store, Google Play or by scanning the QR code below.

Turn on VeryFit app -> Activate Bluetooth connection on your phone -> Search on the app for the device to pair with (or scan the QR code on the device) -> Finish binding on the app (or on the device).

Swipe up/down
1. To toggle through menu.
2. To view long text/details.

Swipe left/right
1. To toggle through menu.

Tap the screen
1. To enter the menu.
2. To operate according to the prompts.

Tap and hold on the screen
1. To switch between watch faces.

Short press
1. To return.
2. To wake the screen when it is off.

Long press
1. When powered off, press and hold for 2 seconds to power on.
2. When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.

Turning on
Whilst the watch is off, it automatically turns on when you put it on charge.

Whilst the watch is off, it automatically turns on when you put it on charge.

クイックスタートガイド

(JP)

1. 製品概要



Physical button operation

Short press

- 戻る
- 画面がオフのときに起動する。


Long press

- デバイスの電源がオフのときに2秒間長押しすると、電源がオンになります。
- デバイスの電源がオンのときに2秒間長押しすると、シャットダウン/再起動画面が表示されます。8秒間長押しすると、ハードリセットが実行されます。

2. 電源オン/オフ

電源オン

ウォッチがオフになっている間、充電を開始すると自動的にオンになります。



注意: 初回使用前にウォッチを充電してから起動してください。充電には必ず純正の電源アダプターを使用してください。

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.

Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Long press the button to turn on the watch.

Power Off
Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Download and install the "VeryFit" app on the App Store, Google Play or by scanning the QR code below.

Turn on VeryFit app -> Activate Bluetooth connection on your phone -> Search on the app for the device to pair with (or scan the QR code on the device) -> Finish binding on the app (or on the device).

Swipe up/down
1. To toggle through menu.
2. To view long text/details.

Swipe left/right
1. To toggle through menu.

Tap the screen
1. To enter the menu.
2. To operate according to the prompts.

Tap and hold on the screen
1. To switch between watch faces.

Short press
1. To return.
2. To wake the screen when it is off.


Long press
1. When powered off, press and hold for 2 seconds to power on.
2. When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.

Turning on
Whilst the watch is off, it automatically turns on when you put it on charge.

Whilst the watch is off, it automatically turns on when you put it on charge.

(DE)

1. Produktübersicht



Physical button operation

Short press

- 戻る
- 画面がオフのときに起動する。


Long press

- デバイスの電源がオフのときに2秒間長押しすると、電源がオンになります。
- デバイスの電源がオンのときに2秒間長押しすると、シャットダウン/再起動画面が表示されます。8秒間長押しすると、ハードリセットが実行されます。

2. 電源オン/オフ

電源オン

ウォッチがオフになっている間、充電を開始すると自動的にオンになります。



注意: 初回使用前にウォッチを充電してから起動してください。充電には必ず純正の電源アダプターを使用してください。

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.

Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Long press the button to turn on the watch.

Power Off
Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Download and install the "VeryFit" app on the App Store, Google Play or by scanning the QR code below.

Turn on VeryFit app -> Activate Bluetooth connection on your phone -> Search on the app for the device to pair with (or scan the QR code on the device) -> Finish binding on the app (or on the device).

Swipe up/down
1. To toggle through menu.
2. To view long text/details.

Swipe left/right
1. To toggle through menu.

Tap the screen
1. To enter the menu.
2. To operate according to the prompts.

Tap and hold on the screen
1. To switch between watch faces.

Short press
1. To return.
2. To wake the screen when it is off.

Long press
1. When powered off, press and hold for 2 seconds to power on.
2. When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.


Turning on
Whilst the watch is off, it automatically turns on when you put it on charge.

Whilst the watch is off, it automatically turns on when you put it on charge.

Kurzanleitung

(DE)

1. Produktübersicht



Physical button operation

Short press

- 戻る
- 画面がオフのときに起動する。

Long press

- Im ausgeschalteten Zustand 2 Sekunden gedrückt halten, um den Bildschirm einzuschalten.
- Im eingeschalteten Zustand 2 Sekunden gedrückt halten, um den Bildschirm zum Ausschalten/Neustarten aufzurufen. 8 Sekunden gedrückt halten, um einen Neustart durchzuführen.

2. Einschalten/Ausschalten

Einschalten

Solange die Uhr ausgeschaltet ist, schaltet sie sich automatisch ein, wenn Sie aufgeladen wird.



Hinweis: Laden Sie die Uhr auf, um sie vor Erstgebrauch zu aktivieren. Zum Laden muss das Original-Netzteil verwendet werden.

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.

Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Long press the button to turn on the watch.

Power Off
Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Download and install the "VeryFit" app on the App Store, Google Play or by scanning the QR code below.

Turn on VeryFit app -> Activate Bluetooth connection on your phone -> Search on the app for the device to pair with (or scan the QR code on the device) -> Finish binding on the app (or on the device).

Swipe up/down
1. To toggle through menu.
2. To view long text/details.

Swipe left/right
1. To toggle through menu.

Tap the screen
1. To enter the menu.
2. To operate according to the prompts.

Tap and hold on the screen
1. To switch between watch faces.

Short press
1. To return.
2. To wake the screen when it is off.


Long press
1. When powered off, press and hold for 2 seconds to power on.
2. When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.

Turning on
Whilst the watch is off, it automatically turns on when you put it on charge.

Whilst the watch is off, it automatically turns on when you put it on charge.

(FR)

1. Synthèse du produit



Physical button operation

Short press

- 戻る
- 画面がオフのときに起動する。


Long press

- Im ausgeschalteten Zustand 2 Sekunden gedrückt halten, um den Bildschirm einzuschalten.
- Im eingeschalteten Zustand 2 Sekunden gedrückt halten, um den Bildschirm zum Ausschalten/Neustarten aufzurufen. 8 Sekunden gedrückt halten, um einen Neustart durchzuführen.

2. Einschalten/Ausschalten

Einschalten

Solange die Uhr ausgeschaltet ist, schaltet sie sich automatisch ein, wenn Sie aufgeladen wird.



Hinweis: Laden Sie die Uhr auf, um sie vor Erstgebrauch zu aktivieren. Zum Laden muss das Original-Netzteil verwendet werden.

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.

Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Long press the button to turn on the watch.

Power Off
Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Download and install the "VeryFit" app on the App Store, Google Play or by scanning the QR code below.

Turn on VeryFit app -> Activate Bluetooth connection on your phone -> Search on the app for the device to pair with (or scan the QR code on the device) -> Finish binding on the app (or on the device).

Swipe up/down
1. To toggle through menu.
2. To view long text/details.

Swipe left/right
1. To toggle through menu.

Tap the screen
1. To enter the menu.
2. To operate according to the prompts.

Tap and hold on the screen
1. To switch between watch faces.

Short press
1. To return.
2. To wake the screen when it is off.

Long press
1. When powered off, press and hold for 2 seconds to power on.
2. When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.


Turning on
Whilst the watch is off, it automatically turns on when you put it on charge.

Whilst the watch is off, it automatically turns on when you put it on charge.

Guide de démarrage rapide

(FR)

1. Synthèse du produit



Physical button operation

Short press

- 戻る
- 画面がオフのときに起動する。


Long press

- Im ausgeschalteten Zustand 2 Sekunden gedrückt halten, um den Bildschirm einzuschalten.
- Im eingeschalteten Zustand 2 Sekunden gedrückt halten, um den Bildschirm zum Ausschalten/Neustarten aufzurufen. 8 Sekunden gedrückt halten, um einen Neustart durchzuführen.

2. Einschalten/Ausschalten

Einschalten

Solange die Uhr ausgeschaltet ist, schaltet sie sich automatisch ein, wenn Sie aufgeladen wird.



Hinweis: Laden Sie die Uhr auf, um sie vor Erstgebrauch zu aktivieren. Zum Laden muss das Original-Netzteil verwendet werden.

2. Turning on/off

Turning on

Whilst the watch is off, it automatically turns on when you put it on charge.

Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Long press the button to turn on the watch.

Power Off
Press and hold for 2 seconds to access the power off/restart screen and choose to power off/restart your watch.

Download and install the "VeryFit" app on the App Store, Google Play or by scanning the QR code below.

Turn on VeryFit app -> Activate Bluetooth connection on your phone -> Search on the app for the device to pair with (or scan the QR code on the device) -> Finish binding on the app (or on the device).

Swipe up/down
1. To toggle through menu.
2. To view long text/details.

Swipe left/right
1. To toggle through menu.

Tap the screen
1. To enter the menu.
2. To operate according to the prompts.

Tap and hold on the screen
1. To switch between watch faces.

Short press
1. To return.
2. To wake the screen when it is off.


Long press
1. When powered off, press and hold for 2 seconds to power on.
2. When powered on, press and hold for 2 seconds to access the power off/restart screen. Press and hold for 8 seconds for a hard reboot.

Turning on
Whilst the watch is off, it automatically turns on when you put it on charge.

Whilst the watch is off, it automatically turns on when you put it on charge.

Appuyer sur l'écran
1. pour accéder au menu.
2. pour utiliser en fonction des messages.

Maintenir le doigt appuyé sur l'écran
1. pour alterner entre les cadrans de montre.



Caractéristiques

La GTX26 offre des fonctionnalités telles que l'étanchéité 3ATM, le GPS, un écran tactile intégral, une faible latence, 100 modes d'entraînement et de nombreux cadrans de montre personnalisables. Elle prend en charge le suivi de la fréquence cardiaque et la détection du stress tout au long de la journée, la mesure de l'oxygène sanguin et le suivi du sommeil, etc. Pour consulter le mode d'emploi et la FAQ relatifs à ces fonctionnalités, veuillez ouvrir l'application et accéder à la section « Guide utilisateur ».

Soin et entretien

Trois suggestions d'utilisation et d'entretien:

1. Gardez le produit propre;
 2. Gardez le produit au sec;
 3. Ne portez pas le produit de manière trop serrée;
- * N'utilisez pas de nettoyeurs ménagers lors du nettoyage du produit. Utilisez plutôt des nettoyeurs sans savon.
- * Pour les taches tenaces, il est recommandé de les enlever en les frottant à l'alcool.


Étanche : Ne convient pas à la plongée, à la baignade en mer ou à un sauna. Convient pour une utilisation dans les piscines, douches (eau froide) et peu profondes.

Consignes de sécurité

- N'exposez pas le produit et ses accessoires à des températures extrêmes, sinon cela pourrait être source de risques tels qu'un dysfonctionnement du produit, un incendie ou une explosion.
- Protégez le produit contre les chocs ou les secousses forts, afin de n'endommager ni le produit ni ses accessoires, et éviter ainsi les dysfonctionnements du produit.
- Ne démontez ni ne modifiez le produit et ses accessoires par vous-même. Contactez-nous pour le service après-vente en cas de dysfonctionnement du produit.

Guía de inicio rápido (ES)

1. Vista general de producto



Funcionamiento del botón físico

Pulsación corta

1. Para volver.
2. Para reactivar la pantalla cuando está apagada.


Pulsación larga

1. Con el dispositivo apagado, mantén pulsado durante 2 segundos para encenderlo.
2. Con el dispositivo encendido, mantén pulsado durante 2 segundos para acceder a la pantalla de apagado/reinicio. Mantén pulsado durante 8 segundos para un reinicio completo.

2. Encendido/apagado

Encendido

Si el reloj está apagado, se enciende automáticamente al ponerlo a cargar.




Nota: Cargue el reloj para activarlo antes de usarlo por primera vez. Se debe usar el adaptador de corriente original para cargar.

Mantenga pulsado el botón para encender el reloj.

Apagado

Mantén pulsado durante 2 segundos para acceder a la pantalla de apagado/reinicio y selecciona si quieres apagar o reiniciar el reloj.



Descarga de aplicaciones y vinculación

1. Descarga de aplicaciones

Descargue e instale la aplicación "VeryFit" de la App Store, Google Play o escaneando el código QR siguiente.



2. Vinculación

Abra la aplicación VeryFit. Active la conexión Bluetooth en su teléfono. En la aplicación, busque el dispositivo para vincularlo (o escanee el código QR en el dispositivo). Complete la vinculación en la aplicación (o en el dispositivo).

Funcionamiento de la pantalla

Deslizar hacia arriba/abajo


1. para desplazarse por el menú.
2. para ver textos largos/detalles.

Deslizar hacia la izquierda/derecha

1. para desplazarse por el menú.

Guida introduttiva (IT)

1. Panoramica prodotto



Funciones

El GTX26 cuenta con características como resistencia al agua de 3ATM, GPS, control táctil en pantalla completa, baja latencia, 100 modos de entrenamiento y múltiples esferas en la nube. Permite monitorizar la frecuencia cardíaca y el estrés durante el día, así como la detección de oxígeno en sangre y el sueño, entre otras funciones. Para consultar las instrucciones de uso y las preguntas frecuentes sobre estas funciones, abra la aplicación y vaya a la sección "Guía del usuario".

Cuidado y mantenimiento

Tres recomendaciones de uso y mantenimiento:

1. Mantenga el producto limpio;
2. Mantenga el producto seco;
3. No lleve el producto demasiado apretado;


- * No utilice limpiadores domésticos para limpiar el producto. En su lugar, utilice limpiadores sin jabón.
 - * Para eliminar manchas persistentes, se recomienda eliminarlas frotando con alcohol.
- Impermeable: No es apto para usar durante la conducción, nadando en el mar o en una sauna. Es apto para usar en piscinas, duchas (agua fría) y aguas poco profundas.

Instrucciones de seguridad

- No coloque el producto y sus accesorios en lugares con temperaturas extremas, de lo contrario, podrían producirse riesgos como fallos del producto, incendios o explosiones.
- Proteja el producto contra golpes o sacudidas fuertes para que el producto y sus accesorios no resulten dañados y así evitar fallos del producto.
- No desmonte ni modifique el producto y sus accesorios usted mismo. En caso de fallo del producto, póngase en contacto con nosotros o con el servicio postventa.

Guida introduttiva (IT)

1. Panoramica prodotto



Funcionamento del pulsante fisico

Pressione breve

1. Per tornare indietro.
2. Per riattivare lo schermo quando è spento.


Pressione prolungata

1. Da spento, tenere premuto per 2 secondi per accendere.
2. Da acceso, tenere premuto per 2 secondi per accedere alla schermata di spegnimento/riavvio. Tenere premuto per 8 secondi per un riavvio forzato.

2. Accensione/Spegnimento


Accensione

Quando l'orologio è spento, si accende automaticamente durante la ricarica.



Nota: ricaricare l'orologio per attivarlo prima del primo utilizzo. Per la ricarica deve essere utilizzato un alimentatore originale.

Premere a lungo il pulsante per accendere l'orologio.



Spegnimento

Tieni premuto per 2 secondi per accedere alla schermata di spegnimento/riavvio e scegliere se spegnere/riavviare l'orologio.

Download e associazione di app

1. Download di app

Scaricare e installare l'app "VeryFit" su App Store, Google Play o scansionando il codice QR qui sotto.



2. Associazione

Attivare l'app VeryFit -> Attivare la connessione Bluetooth sul telefono -> Cercare nell'app il dispositivo da associare (o scansionare il codice QR sul dispositivo) -> Terminare l'associazione sull'app (o sul dispositivo).

Funzionamento dello schermo

Scorrere verso l'alto/il basso

1. per scorrere il menu.
2. per visualizzare testo lungo/dettagli.

Scorrere verso sinistra/destra

1. per scorrere il menu.

Guida introduttiva (CN)

1. 产品概述



Funcionalità

GTX26 offre funzionalità come resistenza all'acqua fino a 3ATM, GPS, controllo touch a schermo intero, bassa latenza, 100 modalità di allenamento e diversi quadranti cloud. Supporta il monitoraggio della frequenza cardiaca e il rilevamento dello stress durante il giorno, il rilevamento dell'ossigeno nel sangue e il monitoraggio del sonno, ecc. Per istruzioni operative e domande frequenti su queste funzionalità, avviare l'app e accedere alla sezione "Guida utente".

Cura e manutenzione

Tre suggerimenti per l'uso e la manutenzione:

1. Mantenere il prodotto pulito;
2. Mantenere il dispositivo asciutto;
3. Non indossare il dispositivo troppo stretto;

- * Non utilizzare detergenti domestici per la pulizia del prodotto. Utilizzare invece detergenti privi di sapone.

- * In caso di macchie ostinate, si consiglia di rimuoverle strofinando con alcool.

Impermeabile: non adatto per l'uso durante le immersioni, il nuoto in mare o in sauna. Adatto per l'uso in piscine, docce (acqua fredda) e acque poco profonde.

Istruzioni di sicurezza

- Non posizionare il prodotto e i suoi accessori a temperature estreme, altrimenti potrebbero causarsi pericoli quali guasto del prodotto, incendio o esplosione.
- Proteggere il prodotto da forti urti o scosse, in modo da non danneggiare lo stesso e i suoi accessori, evitando così guasti.
- Non smontare o modificare da soli il prodotto e i suoi accessori. Contattarci per il servizio post-vendita in caso di guasto del prodotto.

快速入门指南 (CN)

1. 产品概述



物理按键操作说明

短按

1. 亮屏状态下，主表盘界面单击按键，进入应用列表。
2. 亮屏状态下，非主表盘非运动中界面，单击按键，返回主表盘。
3. 灭屏状态下，单击按键，亮屏。


长按

1. 关机状态下，长按2秒开机。
2. 开机状态下，长按2秒进入关机/重启界面。长按8秒强制重启。

2. 开机/关机

开机

如图所示连接磁吸充电头开始充电，如果手表处于关机状态，它将自动启动。




注意：在第一次给手表充电激活时，必须使用原厂电源适配器。

长按物理按键开机。

关机

1. 关机状态下，长按2秒开机。
2. 开机状态下，长按2秒进入关机/重启界面，选择关机/重启。



应用程序下载和配对

1. 应用程序下载

请在苹果应用商店、谷歌应用商店或者应用宝下载，或扫描下面的二维码下载并安装“VeryFit”应用程序。



2. 配对

打开“VeryFit”应用程序 -> 在您的手机上开启蓝牙连接 -> 在应用程序上搜索设备配对（或扫描设备上的二维码） -> 在应用程序（或设备上）上完成绑定。

屏幕操作

上/下滑动

1. 切换菜单。
2. 查看长文本/详细信息。

左/右滑动


1. 切换菜单。

点击屏幕

1. 进入菜单。
2. 根据提示进行操作。

长按屏幕

1. 更换表盘。



功能介绍

GTX26 具备 3ATM 防水、GPS、全屏触控、低延迟、100 种运动模式和多个云端表盘等功能特点。它支持全天心率监测和压力监测、血氧监测和睡眠监测等。有关这些功能的操作说明和常见问题解答，请打开应用程序并进入“用户指南”查看。

维护与保养

使用和维护建议：

1. 保持产品清洁；
2. 保持产品干燥；
3. 佩戴产品时不要戴的太紧；

- * 清洁产品时不要使用家用清洁剂，使用无肥皂的清洁剂代替。

- * 对于顽固的污渍，建议用酒精擦拭去除。

防水：不适合在潜水、海上游泳或桑拿时使用。适用于游泳池和浅滩中使用。

安全说明

- 请勿将产品及其附件放置在极端温度下，否则可能会导致产品故障、火灾或爆炸等危险。
- 保护产品不受强烈的冲击或震动，以免损坏产品及其附件，从而避免产品故障。
- 请勿自行拆卸或修改产品及其附件。如果产品出现故障，请联系我们进行售后服务。



The device meets the EU ROHS criterion. Please refer to IEC 62321, EU ROHS Directive 2011/65/EU and revised directive.

This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could avoid the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

The device has been evaluated to meet general RF exposure statement.
The device can be used in portable exposure condition without restriction
- Risk of explosion if the battery is replaced by an incorrect type;
- disposal of a battery into fire or a hot oven, or mechanically

crushing or cutting of a battery, that can result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

If you experience discomfort or skin irritation when wearing your smart watch, then we recommend you try cleaning your device. Sometimes residue or foreign materials build up around your device and may aggravate your skin. It's also possible that you are not wearing the watch correctly. We recommend making sure to clean and adjust your watch regularly for a more comfortable fit. Caution:

- If you experience skin irritation when wearing your watch, please refrain from wearing, and wait two to three days to see if your symptoms ease. If symptoms persist or worsen, please consult a physician.
- If you have eczema, allergies or asthma, you may be more likely to experience a skin irritation or allergy from a wearable device.

Wear and Care

Some users may experience skin irritation when using this product. To reduce the potential for irritation, please follow four simple wear and care tips: (1) keep it clean; (2) keep it dry; (3) do not wear it too tightly, and keep the wearing gap as one finger; (4) after long-term wearing, remove the device in time to relax the wrist; (5) after exercise, if your wrists sweat, please clean and dry your wrists and watches before wearing again. The residual sweat components will corrode the watch. It is recommended to regularly use soap or hand sanitizer to clean the watch. In case of skin allergy, please take off your watch and Seek medical advice in time.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
1)L'appareil ne doit pas produire de brouillage;
2)L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

*Do not attach the magnetic part of the charging cable to other metals to avoid short-circuiting the contacts of the charging cable.

SAR compliance is based on a separation distance of 0 mm between the unit and the body of the user
SAR compliance is based on a separation distance of 0 mm between the unit and the body of the user
La conformité du das est basée sur une distance de séparation de 0 mm entre l'unité et le corps de l'utilisateur

Responsible Party

Name and company of U.S. agent: Bridgeport Advisory LLC
Physical U.S. address of agent: 3330 W 38TH PL, CHICAGO, IL 60632, United States

FRN of U.S. agent: 0037566148

Email address of U.S. agent: yliu@bridgeportadv.com

Contact NO.: (708) 680-6688



爱 | 都 | 科 | 技

名称

GTX26说明书

材质

80G哑粉

尺寸

展开尺寸: 560X200mm
成品尺寸: 70X100mm

装订方式

8折页

颜色

四色双面印刷