


恭喜，您现在拥有了Rebel Ride - Sex Machine产品！为了使您的玩具保持最佳状态，请仔细阅读本用户手册，了解保养和清洁说明及充电说明。

Congratulations! You now have the Rebel Ride-Sex Machine product! To keep your toys in the best condition, please read this user manual carefully to understand the maintenance and cleaning instructions as well as the charging instructions.




电池充电

1. 遥控器USB充电端口位于背面，调整两点磁吸对准充电端口。
2. 当遥控器充电时，指示灯呼吸闪烁，充电完成后，指示灯常亮。
3. 充满电时间约60分钟。



Charging

1. The USB charging port of the remote control is located on the back. Adjust two magnetic points to align with the charging port.
2. When the remote control is charging, the indicator light will start to flash and breathe. After the charging is completed, the indicator light will remain on constantly.
3. The full charging time is approximately 60 minutes.






功能

使用配套的阳具套在伸缩杆上，在电源插口位置插上电源适配器12V插头，电源适配器插上100~220AC电源，按压电源按钮，按钮白色灯亮，此时产品处于通电状态。注意：在不使用的情况下，请将电源适配器插头拔出。

产品按钮说明

长按产品操作面板电源按钮2S，产品进入待机模式




遥控器按钮说明

注意：使用无线遥控器之前，请确保产品是开机状态

长按电源按钮2S可开启和关闭遥控器

单击“+”“-”按钮调整伸缩速度

单击“<”“>”按钮调整伸缩杆上下角度




Function

Put the matching harness on the telescopic rod, plug in the 12V plug of the power adapter at the power socket position, plug in the 100-220AC power supply of the power adapter, press the power button, the white light of the button will light up, and at this time, the product is in the powered state. Note: When not in use, please unplug the power

Product Button Instructions

Press and hold the power button on the product operation panel for 2 seconds, and the product will enter standby mode




Instructions for Remote control Buttons

Note: Before using the wireless remote control, please make sure the product is turned on

Press and hold the power button for 2 seconds to turn the remote control on and off

Click the "+" and "-" buttons to adjust the stretching speed

Click the "<" ">" button to adjust the up and down Angle of the telescopic rod





保养和清洁

我们只使用最好的硅胶。每次使用前后用肥皂和水清洁。用柔软干净的布擦干。请将本品保存在阴凉、干燥、清洁的地方。硅胶无孔且易于清洁。我们建议在本产品中使用水基或混合润滑剂。我们的遥控器是可以防水的。注意：请勿使用含酒精、汽油或丙酮的有机清洁剂清洁本产品。避免阳光直射。



Maintenance and cleaning

We only use the best silicone. Clean with soap and water before and after each use. Dry it with a soft and clean cloth. Please store this product in a cool, dry and clean place. Silicone is pore-free and easy to clean. We recommend using water-based or mixed lubricants in this product. Our prosthetics and remote controls are both waterproof. Attention: Do not clean this product with organic cleaners containing alcohol, gasoline or acetone. Avoid direct sunlight



安全

- 如有不适，请停止使用。
- 建议与水性润滑剂配合使用。
- 如果发现产品不光滑或损坏，请勿使用。
- 请放在儿童接触不到的地方。



SAFETY

- Stop using it when any discomfort occurs.
- It is recommended to use it with water-based lubricant.
- Do not use it if you find the product unsmooth or damaged.
- Keep out of reach of children.



警告

FCC :

1. 第15.19部分

本设备符合FCC规则第15部分。操作必须符合以下两个条件：(1) 本设备不得造成有害干扰；(2) 本设备必须接受接收到的任何干扰，包括可能导致不正常操作的干扰。

2. 第15.21部分

任何未经合规责任方明确批准的更改或修改都可能使用户无权操作设备。

3. 第15.105部分

根据FCC规则第15部分，本设备已经过测试，符合B类数字设备的限制。这些限制是为了在住宅装置中提供合理的保护，防止有害干扰。本设备产生、使用并能辐射射频能量，如果不按照说明书安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定的安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰，可以通过关闭和打开设备来确定，则鼓励用户尝试通过以下一种或多种方法来纠正干扰

措施：

- 重新定位或重新安置接收天线。
- 增加设备与接收机之间的距离。
- 将设备连接到与接收器连接的电路不同的插座上。
- 向经销商或有经验的广播/电视技术人员寻求帮助。

4. SAR :

FCC辐射暴露声明

本设备符合非受控环境的FCC辐射暴露限制。此发射机不得与任何其他天线或发射机一起放置或一起工作。



WARNING

FCC :

1. Part15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2. Part15.21

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

3. Part15.105

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

4. SAR :

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.