



AG66

SMART GLASSES


User's Manual

Precautions

- Prohibit charging in a waterlogged or humid environment.
- Please use the charging cable accompanying this product to charge.
- The material of this product is soft, please hold it gently and put it down, and it is forbidden to drop it; when you find the product broken, please pay attention to safety and avoid scratching your body.
- This product does not have waterproof function, it is strictly prohibited to let the product rain or soak in water.


※ This device is equipped with photo and video functionality. You are hereby notified that the use of this product for clandestine photography, surveillance, or any other invasive recording is strictly prohibited. Users must comply with all applicable local laws and regulations concerning privacy and recording. pls use this product in a lawful and ethical manner.

Appearance




To Remove the Lens

1. With both hands, place your index and middle fingers on the outer edge of the frame.
 2. Use both thumbs to press outward from the inside, pushing the lens out from the front of the glasses.
 3. Repeat the same steps for the other side.
- The lens is now detached from the front of the frame.




To Install the Lens

1. Align the lens with the frame from the inside.
2. With both hands, place your index and middle fingers on the outer edge of the frame. First, tilt and hook one side of the lens into the frame.
3. Then, use both thumbs to press the lens from the inside outward, pushing the lens into the frame.
4. Make minor adjustments to ensure it is properly seated. Repeat the same steps for the other side.



Key Definition



① Right Side Button:

Power On: Long press the button for 3 seconds to power on.

Power Off: Long press the button for 5 seconds to power off.

Take Photo: Short press the button.

Start Recording: Double-click the button to start.

Stop Recording: During recording, short press the button to end.

Start Video Recording: Long press the button for 2 seconds to start.

Stop Video Recording: During video recording, short press the button to end.

Incoming Call: Short press to answer; long press for 2 seconds to reject.

During Call: Short press once to hang up.

During AI Conversation: Short press to exit.

Reset to Factory Settings: Long press the button for 8 seconds.

② Touch Control Area:

Play/Pause Music: Single tap on the touch area.

Adjust Volume: Swipe forward to increase volume, swipe backward to decrease volume.

Next Track: Double-tap the touch area.

Previous Track: Triple-tap the touch area.

AI Voice:

English Wake Word: Fun Seek!

Connection instructions

- 1.To enable all features, connect your smart glasses to a smartphone via the "EYEVUE" app.
2. Download the app by: searching "EYEVUE" on Google Play or the App store, or scanning the QR code and selecting your OS version.



Open the installed app and follow the instructions to complete the registration;

Select [Home] and click [connect Device];

Select the name of the searched device[AG66];

When you hear the ding-dong sound, the connection is successful.

Warm tips

- This product supports taking photos and recording videos, but it consumes more power when doing so. When the battery level drops below 15%, the device will disable the photo and video functions. When the battery level drops below 20%, the device will suspend the data transmission to the mobile phone. All functions can be restored after charging.
- This product supports transmitting data to the mobile phone via Wi-Fi and saving the data. This can be achieved only when the mobile phone allows the APP to use the relevant permissions.



Do not use fast charging
Please use a 5V/1A adapter.




AG66
智能眼镜
使用指南

注意事项

- 禁止在有水渍或潮湿的环境下充电；
- 请使用本产品配套的充电线充电；
- 本产品材料较软，请轻拿轻放，严禁摔打。当发现产品有破损时，请注意安全，避免划伤身体。
- 本产品不具有防水功能，严禁让产品淋雨或者浸泡于水中。


※ 本设备配备照片与视频拍摄功能。特此通知，严禁使用本产品进行偷拍、监控或任何其他侵犯性录制。用户必须遵守所有关于隐私和录制的当地法律法规。请以合法、道德的方式使用本产品。

外观说明




镜片拆装

- 1、两只手同时用食指和中指抵住镜框的外边，两只大拇指在内往外挤压，使镜片从眼镜前面脱离，左右边同样操作。
- 2、镜片从眼镜前面脱离。




镜片安装

- 1、把镜片由内对齐镜框，两只手同时用食指和中指抵住镜框的外边，先把镜片的一边斜向套入镜框，再用两只大拇指压着镜片在内往外推，使镜片从眼镜由内向外挤压，把镜片推入镜框，再做轻微的调整，左右边同样操作。



按键定义说明



① 右侧按键：

开机，长按按键3秒开机
关机，长按按键5秒关机
拍照，短按按键；
录音，双击按键开启；
录音中，短按按键结束；
录像，长按按键2秒开始；
录像中，短按按键结束；
来电中，短按接听，长按2秒拒接；
通话中，短按1次挂断；
AI对话中短按按键可退出
恢复出厂设置，长按按键8秒，

② 触控区域：

播放/暂停音乐：单击触控区域；
调节音量：前滑调大音量，后滑调小音量；
切换下一首：双击触控区域；
切换上一首：三击触控区域；
AI语音
唤醒词为：Fun Seek!

连接说明

1. 要启用全部功能，请通过"EYEVUE"应用将您的智能眼镜连接到智能手机。
2. 下载应用方法：在 Google Play 或 App Store 中搜索 "EYEVUE"，或扫描二维码并选择您的操作系统版本。



打开安装的APP，根据提示完成注册



选择【首页】，点击【连接设备】



选择搜索到的设备名称【AG66】



听到叮咚声音，连接成功

温馨提示

- 本产品支持拍照和录像，但使用时功耗相对较高，在电量低于15%时，设备将停用拍照和录像功能，在电量低于20%时，设备将暂停传输数据到手机，充电后可恢复使用。
- 本产品支持wifi传输数据到手机并保存，需要手机允许APP使用相关权限后方可实现。



禁止使用快充充电
请使用5V/1A充电器

FCC Caution

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.