






正面

Wireless Charger Three-in-one Charger User Manual  (Please read the user manual carefully before using the product)	Wireless Charging Guide Please use the USB-A or USB-C Adapter that comes with the package or the quick charger 2.0 or 3.0 chargers with USB-A or USB-C ports are recommended. Charging with Cases  With metal trim With metal patch With credit cards Metal cases Phone cases over 5mm	PRODUCT DESCRIPTION  3-in-1 Wireless Charging  Charging Cable	The Meaning of Indicator Lights on Phone Wireless Chargers Blinking blue and green lights for 3s at the Power-on moment. ① Green Solid Light: Standby mode and stop charging ② Blue Solid Light : Charging mode ③ Blinking blue and green lights: FOD mode(Foreign body is detected or the phone is misaligned, ④ No light: Stop charging(please ensure the power adapter plug-in) Compatibility Sheet 1.Smartphone For Samsung Phone: Samsung Phone Galaxy S25 Ultra/S25+/S25/S24 Ultra/S24+/S24/S23 Ultra/S23+/S23/S22 Ultra/S22+/S22/S21 Ultra/S21+/S21/S20 Ultra/S20+/S20/S10+/S10/S9+/S9/S8+/S8/S7/S6 series; Galaxy Note20 Ultra 5G/Note20/10+/10/9/8/5 series; Galaxy Z Flip7 SE/7/5/4/3/Z Fold7/5/4/2 series For iPhone: iPhone 17, iPhone 17 Air, iPhone 17 Pro, iPhone 17 Pro Max, iPhone 16, iPhone 16 Plus, iPhone 16 Pro, iPhone 16 Pro Max, iPhone 15, iPhone 15 Plus, iPhone 15 Pro, iPhone 15 Pro Max, iPhone 14, iPhone 14 Plus, iPhone 14 Pro, iPhone 14 Pro Max, iPhone 13, iPhone 13 Pro, iPhone 13 Pro Max, iPhone 13 mini, iPhone 12, iPhone 12 mini, iPhone 12 Pro, iPhone 12 Pro Max, iPhone 11, iPhone 11 Pro, iPhone 11 Pro Max, iPhone XS, iPhone XS Max, iPhone XR, iPhone XR Max, iPhone 8, iPhone 8 Plus For Google: Google Pixel 6 /Pixel 6 Pro 2.Earbuds Samsung Galaxy Buds 3 Pro/2/2 Pro/Live/+/Pro series AirPods 2/3/Pro/Pro 2 3.Smart Watch Samsung Galaxy Watch7/Galaxy Watch Ultra/6/6 Classic/5/5 Pro/4/4 Classic/3/2/Active series	SPECIFICATION YIELD Model: WL305 Input: 5V/3A 9V/2A Output: Phone :15W/10W/7.5W/5W Earbuds:5W Watch :2.5W THE USE OF PRODUCT FOLDING  Press here and it will fold up.
--	---	--	---	---

反面

Package Contents Wireless Charger User Manual How to use the product 1. Charging the mobile phone: Put the mobile phone upright in the wireless charging area of mobile phone, and you can see the "Charging indicator" on the display of the mobile phone, showing that it is being charged properly. 2. Charge the watch: Place the watch in the watch wireless charging area, align the magnet, and the charging indication on the display on the watch lights up to indicate that it is charging. 3. Bluetooth headset charging: Place the Bluetooth headset flat on the wireless charging area (Note: Do not wear a silicone protective cover, otherwise it may lead to poor contact and failure to charge). Precautions for Use Please pay attention to the following issues, otherwise it may cause abnormal charging, high charging temperature, intermittent charging, or even not charging.	1. The watch charging is incompatible with devices other than Samsung watches, such as Apple Watches. 2. Do not use the wireless charger after splashing with water, as it may damage or deform the product due to a short circuit. 3. Do not pull the silicone part, otherwise it will easily damage the precision components under the silicone part and affect the charging. 4. Please put the phone/watch at the center of charge area. 5. We recommend fast charger adapter (9V/2A), which can charge three devices at the same time while maintaining the fastest speed. The 5V/2A charger can only provide a normal charging speed, which will be slower than that of a fast charger 6. The charging distance is 2-8 mm, please don't wear protective case which is over 3mm thick. 7. The watch has temperature control. When the temperature reaches 104 F, it will stop charging automatically. If the temperature is normal, it will continue to charge.	8. No metal or magnetic objects around 6cm of the back center of the phone during charging. 9. The lower temperature, the faster charging speed. The charging speed is faster in winter than in summer. 10. Please don't charge in high temperature and humid environments to avoid damage of circuit. 11. Put it at the place that children can't reach to avoid unnecessary accidents Troubleshooting 1. Update the device to the latest system. 2. Make sure your device that supports wireless charging. 3. Make sure to use the original charging cable and adapter. 4. Avoid thick device covers 5. Avoid high ambient temperature optimal temperature is 82-86°F.	6. When the phone or watch cannot be fully charged, try the following: Open[Settings]-[Battery Health]-[Turn off battery optimization]. 7. When the earphones are exhausted and cannot be charged, please take out the earphones and charge the storage compartment separately. 8. When the phone, earphones, and watch do not respond when placed, please check whether there are foreign objects around or if the adapter is plugged in correctly or not. ABOUT THE FCC This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This device complies with part 15 of the FCC: rules operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received including interference that may cause undesired operation.	FCC WARNING: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-- Reorient or relocate the receiving antenna.-- Increase the separation between the equipment and receiver.-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.-- Consult the dealer or an experienced radio/TV technician for help. FCC Radiation Exposure Statement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.
---	--	--	---	---