

Tablet

User Manual

(The power delivered by the charger must be between min 10 Watts required by the radio equipment, and max 30 Watts in order to achieve the maximum charging speed)

1. Turn On and Off

Power on: Long press the power button on the side of the phone. The screen will light up, and the phone will enter the powered-on state.

Power off: Long press the power button on the side of the phone, select the "Power off" option, and the phone will enter the powered-off state.

2. Screen Unlock

Slide to unlock: Slide your finger across the screen, and the phone will unlock, displaying the main interface.

3. Main Interface

The main interface of the phone displays icons for various applications. You can open the corresponding application by tapping the icon.

4. Make a Call and Send Text Messages

Make a call: Open the Phone application, tap the dial pad, enter the phone number, and tap the Dial button to make a call.

Send a text message: Open the Messages application, tap the "New Message" button, select the recipient, enter the message content, and tap the Send button to send the text message.

5. Surf the Internet and Download Applications

Surf the internet: Open the browser application, enter the URL, and tap the Go button to browse web content online.

Download applications: Open the App Store application, search for the required application, and tap Download (then Install) to download and install new applications.

6. Photo and Video Recording

Take a photo: Open the Camera application, adjust the shooting mode and settings, and tap the shutter button to take a photo.

Record a video: Open the Camera application, switch to video recording mode, and tap the Start Recording button to record a video.

7. Other Functions

The phone also includes some other common functions, including but not limited to:

Calendar: Record and manage schedules.

Alarm: Set timed reminders.

Contacts: Store and manage contact information.

Weather: View real-time weather information.

Navigation: Provide navigation functions to help users plan travel routes.

8. FAQ

8.1 How to connect to a wireless network?

Go to Settings, open the Wi-Fi option, search for available wireless networks, select the network you want to connect to, enter the password (if required), and you will be connected.

8.2 How to set a mobile phone ringtone?

Go to Settings, open the Sound settings, find the Ringtone option, and select a custom ringtone or one of the existing ringtones.

8.3 How to change the wallpaper of the phone?

Go to Settings, open the Wallpaper settings, and choose a picture from your album or select an existing wallpaper.

9. Safety Precautions

Do not expose the phone to high temperatures or humid environments, as this may damage the phone.

Do not scratch the phone screen with sharp objects.

Do not download unsafe applications, as this may lead to viruses or leakage of personal information.

Do not get the phone wet, as this will damage the phone's circuits.

The above is a brief description of the phone. Please read the user manual carefully for better use of the phone. If you have any questions, please contact the relevant after-sales service.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which thereceiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure

Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of this Device (FCC ID: 2BHHH-P42) has been tested against this SAR limit. SAR information on this can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for search. This device was tested for typical operations 0mm from the body. To maintain compliance with FCC RF exposure requirements, 0mm separation distance should be maintained to the user's bodies