

























Band41(2535-2655)-10MHz-16QAM-41190-50RB#0-P
ASS




Band41(2535-2655)-10MHz-16QAM-41190-50RB#0-P
ASS




Band41(2535-2655)-10MHz-16QAM-41190-50RB#0-P
ASS




Band41(2535-2655)-10MHz-16QAM-41190-50RB#0-P
ASS





Band41(2535-2655)-10MHz-16QAM-41190-50RB#0-P
ASS





Band41(2535-2655)-10MHz-16QAM-41190-50RB#0-P
ASS

















Band41(2535-2655)-15MHz-16QAM-40640-75RB#0-P
ASS




Band41(2535-2655)-15MHz-16QAM-40640-75RB#0-P
ASS




Band41(2535-2655)-15MHz-16QAM-40640-75RB#0-P
ASS




Band41(2535-2655)-15MHz-16QAM-40640-75RB#0-P
ASS




Band41(2535-2655)-15MHz-16QAM-40640-75RB#0-P
ASS




Band41(2535-2655)-15MHz-16QAM-40640-75RB#0-P
ASS




Band41(2535-2655)-15MHz-QPSK-41165-75RB#0-PA
SS




Band41(2535-2655)-15MHz-QPSK-41165-75RB#0-PA
SS




Band41(2535-2655)-15MHz-QPSK-41165-75RB#0-PA
SS




Band41(2535-2655)-15MHz-QPSK-41165-75RB#0-PA
SS




Band41(2535-2655)-15MHz-QPSK-41165-75RB#0-PA
SS



Band41(2535-2655)-15MHz-QPSK-41165-75RB#0-PA
SS







Shenzhen Anbotek Compliance Laboratory Limited

Any unauthorized modification, forgery, or falsification of this document constitutes a violation of law and is subject to legal penalties. If you have any questions, you may scan the QR code to download the report for verification or contact us via email.


Hotline: 400-003-0500 web: www.anbotek.com E-mail: service@anbotek.com




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-QPSK-40140-100RB#0-P
ASS




Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS




Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS




Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS




Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS




Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS




Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS



Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS





Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS




Band41(2535-2655)-20MHz-16QAM-40140-100RB#0-
PASS













---END---