

User Manual

Brand name: AI PRO

Model name: PRO 12500

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.




Remote Control

01—03




Focus

04 05



Connection & Key

06




HDMI

07




Shortcut

08 09



File Manager

10



Same screen

11—16




3D

17 18



WiFi

19



Bluetooth

20



Picture mode

21



Trapezoidal

22 23



general settings

24



Audio

25




Language

26



System

27




Upgrade

28



App upgrade

29




Bluetooth speaker

30


Remote Control

Instruction of Buttons



Note:1. Please keep the remote control aiming at the projector screen.
2.Please take out the battery if the remote control is not used for a long time.

How to pair the remote control



In the "Settings" section, turn on "Bluetooth" and enter Bluetooth pairing mode. Press and hold the "Left" and "Right" arrow keys on the remote control for 3 seconds. The remote control indicator light will start flashing and enter pairing mode. Select "BLE RMC_V2" from the device list to complete the pairing.

How to use the external mouse?




1. Left mouse button confirmation
2. Right click to return

Focus

Manual focus


1. Quick focus: Long press the button of “Focus+/-” on the remote control, the FOCUS icon will appear and rotate quickly on the projection interface.
2. Precise focus: Click the “Focus+/-” button on the remote control continuously, and the FOCUS icon on the projection interface will change according to the frequency of clicks.



Focus


Autofocus

1. Every time the machine is turned on or moved, it will automatically focus;
2. To disable the autofocus function, go to the "Settings" - "Ladder Correction" option and turn off the "Autofocus" switch;
3. If the autofocus is not clear, please use "Focus +/-" on the remote control to make slight adjustments;




Connection & Key

Touch buttons



USB2.0 Interface



HDMI

Connect External Multi-media Interface

Connect the HD cord to the projector and click HDMI on the home screen which will appear in sync within five seconds .


Notes: It can be combined with Amazon Fire TV Stick to connect the projector.

- 1.Plug the Fire TV device into projector HDMI port.
- 2.Check the Audio setting on your Amazon Fire TV or Fire Stick.
- 3.If you're still experiencing audio issues, try turning off Dolby Digital Plus:On your Amazon Fire TV or Fire Stick, go to Settings> Display & Sounds> Audio> Dolby Digital Output and then turn Dolby Digital Plus OFF.




Shortcuts Buttom

- 1 Click the "Menu" button to uninstall or move the application;




Shortcuts Bottom

- ② On the homepage interface, press the remote control "∧" to open the shortcut function pop-up window, select the clean icon, and you can clean the background memory



- ③ Click the mouse button to switch between mouse mode and remote control mode



File Explorer


The files accessed from the USB port can be opened through the resource manager



Airplay (iPhone)

iPhone AirPlay mirror operation guide


1. Turn on the WiFi function of the projector and connect it to WiFi
2. Connect your iPhone and projector to the same --WIFI-- network (Note that poor network connection can cause screen lag)



Airplay (iPhone)


iPhone AirPlay mirror operation guide

3. Click to open the projector's Airtray
4. Slide down your iPhone, open the control center of your phone, click on Airpalm Mirroring, and the device list will automatically search for projection devices within the same network
5. Select the name of the projector device that needs to be connected in the device list to successfully project the screen




Wired screen sharing (iPhone)

1. Click to open the projector's Airplay
2. It is best to use an original Apple data cable to connect the iPhone to the USB port of the projector.
3. The iPhone will pop up a "Trust" window. Please click on "Trust" and enter the unlock password to use the phone screen mirroring






Wireless screen sharing (Android phone)

- 1 Make sure your Android phone and projector open the WIFI.
- 2 Please click Miracast on the projection screen.




Wireless screen sharing (Android phone)

- 3 Open “More Connections or Screen Projection for Android Phone” on the mobile phone (there are a variety of models of Android mobile phones which may have different names, and the mobile phone to be referred is HUAWEI mobile phone).
- 4 The phone and projector will search for same model in a few seconds and connect successfully.



Wired screen sharing (Android phone)

1. Click to open the Airpalm projector, use your phone to scan the eshare app QR code displayed on the projector, download and install the software, and start the installed onesoftware
2. It is best to use an original Android data cable to connect the phone to the USB port of the projector.
3. The phone will pop up a relevant permission window, granting screen mirroring permission to start mirroring



How to play 3D movies



For the 3D glasses ,it supports LCD Active Shutter 3D glasses.

Do remember to charge the 3D glasses when you first use it.

For the video format there are 2 options:Side-by-side(SBS) and Top-and-Bottom(TB) format.

To select the correct video format,please refer to the following instructions:

- 1.Open the 3D video on the projector .
- 2.Please take out the remote control and press settings button on the remote control.
- 3.Click 3D button on the left side and choose SBS/TB for your video.





How to play 3D movies

Example:



For SBS video, you need to open 3D from settings interface and select the SBS option.

For TB video, you need to open 3D from settings interface and select the TB option.





WIFI Connection

Homepage>Settings>Wifi >Turn on wifi option






Bluetooth Connection

Homepage>Settings>Bluetooth>Open Bluetooth



Picture mode

1. Brightness mode: Standard / High/ Eco;
2. Color temperature: Cool / Warm / User defined;
3. Projection mode: Front/Rear/ Ceiling front/Ceiling rear;
4. Zoom: Global /Vertical /Horizontal /Rest;





Trapezoidal settings:

Trapezoidal Calibration: Automatic/manual trapezoidal Calibration

1. Manual Setup: Adjust the trapezoidal shape on the basis of the offset. After clicking to restore the default option, the initial state will be automatically reset.
2. Quadrangular Trapezium Calibration: The four angles of trapezoid can achieve the free adjustment, and click “OK” to switch to the next angle, then click the menu key to return to the default settings.



Note: Playing a 3D video may cause the manually set quadrangle trapezoid to be forced back to its original position, requiring manual resetting of the quadrangle trapezoid.



Trapezoidal settings:



Focus settings:

1. Autofocus: on/off
2. Focus calibration: When the autofocus is not clear, using the focus calibration function can make the autofocus more precise. Click on Settings - Ladder Settings - Focus Calibration to enter the focus calibration operation instruction interface. Follow the instructions to complete the focus calibration.





General settings

1. Time zone: General Settings > Time zone > Select your time zone ;
2. Input method: You can switch different input methods after installing other input methods ;
3. Fan setting: Automatic / manual.




Sound Settings

- 1、Key Tone: On / Off ;
- 2、Sound Effect: Standard/ Vivid ;
- 3、Boot Sound: On / Off.



Select language

Homepage>Settings>Language





System Settings

System upgrade:



1. Online upgrade /U disk upgrade
2. Restore factory settings: Select restore factory settings (Be cautious)
3. Device information:

Projector model/System version/ UI version/MCU version/ROM/RAM /Eth Mac.



Online Upgrade

1. Connect to an available WiFi network and ensure that the battery level is above 50%;
- 1 , Settings>System Settings>System Upgrade. Before you update ,please connect the power adapter and wifi , otherwise, the update will fail or the system will crash.
3. Please do not perform any other operations during the upgrade process. The system will automatically download updates. After entering the system, please wait for 5 minutes. After completing the system configuration, it can be used normally;
4. When clicking on system upgrade and it shows that the current version is the latest, there is no need to upgrade.



App Upgrade

When a red dot appears on the top status bar indicating an app upgrade, press the projector's "^" button to bring up the quick operation bar, select the app upgrade icon, and choose the app to upgrade. You can upgrade the app to the latest version.



Bluetooth Speaker Mode

1. Turn on the Bluetooth function in the settings;
2. Return to the home screen, press the projector's "^" button to bring up the quick operation bar, select the "Bluetooth Speaker" icon, and proceed with Bluetooth pairing;
3. After entering Bluetooth Speaker Mode, the light engine will stop working. Re-press the remote control power button or the machine power button to wake up the light engine and automatically disconnect the Bluetooth connection.



FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.