


ELECTRONIC PREDATOR GAME CALL

Operating Instructions



CZ01

ELECTRONIC PREDATOR GAME CALL




Requires use in conjunction with the remote control.

ELECTRONIC PREDATOR GAME CALL

Setup & Operation Instructions(call)

1. Add Batteries

Open battery panel on the bottom of the device, place 8 new AA batteries(not included) as indicated below, then close panel. Lithium batteries for best results in cold conditions. 1.5 volt AA batteries only. When storing the device for long periods of time, we recommend removing batteries from your decoy.



2. Turn Power Switch On

Slide Left switch to ON to activate Caller. Then you can select the sound buttons on the remote to activate different decoy sound.


Turn the Caller on. Slide Right switch to ON to activate Decoy Topper. Then you can select the DECOY button on the remote to deactivate/activate it. Right Knob controls rotation speed of the topper, turn left faster, turn right slower. (only with CZ01-A)

Turn the Caller on. Turn decoy topper on. Then slide Right switch to ON/L to activate LED light before topper for night time hunting. (only with CZ01-A)
When finished slide switch to OFF.

3. Connect Bluetooth

Turn the caller on, slide middle switch to Bluetooth mode, find call "Crixex" in the Bluetooth settings of your phone.

- 30 Proven Pre-loaded Game Calls
- Play 2 Sounds At The Same Time
- 400 Yard Non-line-of-sight Remote Range
- 30 Yard Bluetooth Range
- 8 Battery Compartments For Super Long Battery Life
- Features 2 Crixex Decoy Toppers



Sound Model| A

Coyote Female Invite
Coyote Female Howl
Coyote Male Invite
Coyote Male Howl
Coyote Pup Howl
Coyote Duet
Coyote Group Howl
Coyote Pup Frenzy
Coyote Whines
Coyote Distress
Coyote Fight 1
Coyote Fight 2
Coyote Pup Fight
Coyote Pup Distress 1
Coyote Pup Distress 2

Sound Model| B

Cottontail Distress 1
Cottontail Distress 2
Baby Cottontail Distress
Jack Rabbit Distress
Hare Distress
Woodpecker Distress
Flicker Distress
Baby Squirrel Distress
Fawn Distress 1
Fawn Distress 2
Red Fox Distress
Groundhog Distress
Mouse Distress
Raccoon Distress
Raccoon Fight

FCC STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARRANTIES OR REPAIRS

This device comes with a 12 months warranty. If there are any problems with the product, please feel free to contact us and our team is always ready to help.

Please note this warranty does not cover damages caused by misuse, improper handling or improper repairs performed by someone other than an authorized service contractor. The warranty does not include shipping costs, which will be borne by you.

NOTE

- 1.The product is not waterproof. Please do not place it in water or use it in rainy days.
- 2.The remote control backlight consumes a lot of power. We recommend that you turn it on when in use and turn it off immediately when not in use.
- 3.When using Bluetooth mode, we recommend that the Predator Caller and phone be no more than 10 yards apart when connecting. Once connected, it can achieve about a 30 yards bluetooth range.

For Any Technical Questions, Please Feel Free To Contact Us. We Will Provide You 24-Hour Online Customer Service.