


LED Matrix Panel




User Manual

Full color LED screen / Custom editing

Remote Control Functions



1. Download & Install App






Scan the QR code below to download and install app with your mobile phone, or enter Google Play/App Store and search for "Multic LED" to download



Scan the QR code and download the App


If you don't have App Store / Google Play, please click the third one to download from Local Server




2. App Authorization Permission

Firstly, Turn ON Bluetooth and Location



① Allow access to your location information



② Allow to find and connect to nearby devices



3. Connect The Device





Note :

1: When you open the APP for the first time, Please Allow to all permissions

2 : Please click to connect the device

3 : If Bluetooth cannot be searched on your Android phone, please check if you have turned on the GPS.

4. Text Editing



Input Text

Set text animation

Page Flip/Move Left/Move Right/Move Up/
Move Down/Snowfall/Bubbles/Blink

Change Text Color

Modify Text Background

Adjust Letter Spacing


Set Stay Duration (Seconds)

Set Play Times

Set Horizontal Alignment

Save to Playlist

5. Special Effects / DIY Color



Page Flip

Move Left

Move Right

Move Up


Move Down

Snowfall

Bubbles

Blink



Set Move Speed



Background color selection

Choose colors freely

6. DIY Animations



Preview



DIY Video

DIY GIF

Set playback count

Save to Playlist

7. DIY Graffiti



Drawing board

Drawing board zoom in/out


Undo Redo Brush Erase Delete

Choose colors freely

Settings Play Duration (seconds)



Save to Playlist

8. Clock



Time System / Date

9. Countdown




Time Selection

Start



Reset

10. Remote



Power Switch

11. Scoreboard



Reset

Scoreboard

Score +1


Score -1

Scoreboard


Score +1

Score -1

12. Boot Preset



Choice



Library



Text

Animation

Reset Boot Preset

Cancel

13. Settings



Screen Rotation

Clear Screen

Rename Device

Adjust Screen Brightness

Connection Password

Restore Factory Settings



Language Settings

Dynamic Background

Privacy Policy




App Update

14. Library



- Latest
- Recommended
- Car
- Driving
- Hotspot
- Warning
- Emoji
- Holiday
- Text
- Image
- Car Logo
- Creative
- Others

15. Playlist




Play Times (1-255)

Choice

Send
Select All
Delete

16. Music Rhythm



USB Interface Selection

Recommended	Original Android Phone Charger	OK
	Power Bank	OK
	Vehicle USB Interface 5V / 2A Vehicle Charger 5V / 2A	OK
Normal Use	Power Strip USB	Some content display may cause screen shutdown , Bluetooth connection errors, or a yellowish color
	IPhone Charger	
Do not Use	Computer / TV USB	1 . Some content will turn off the screen , the Bluetooth connection is wrong , and the color is yellow . 2 . It will cause damage to the USB interface , or the Voltage does not match . 3 . Do not use USB interface below 5V/2A.
	Car U Disk Interface	
	Non-Standard Phone Charger	1 . Burn out the chip and permanently damage the screen 2 . Heat , fire and other risks
	Modify USB Interface	

Reminder :

1.Any abnormal phenomena that occur during use may be related to incorrect selection of the USB interface .

2. If the problem still cannot be resolved , please contact customer service .

Operation Instructions for Factory Reset of the Device:

The device can be restored to its factory settings by continuously and quickly unplugging and plugging in the device's power supply or pressing the button switch five times. This is applicable when you forget the password set for the device, which leads to the inability to connect to the device. This method does not require App operation. You only need to unplug and plug in the power supply five times to complete the reset.

Perform the reset operation:

Repeat the following steps continuously for 5 times with an interval of ≤ 1 second.
Off→ On → Off→ On→ Off→ On→ Off→ On → Off→ On (5 times in total).

Observing the Device's Response:

If the device is not reset, you can try increasing the number of switch operations to 6 - 7 times.
After the device is automatically reset, the interface will return to the default state, indicating a successful reset.

Precautions:

- * Operation Frequency: The unplugging and plugging interval should be 1 -2 seconds. An interval that is too long or too short may render the operation ineffective.
- * Number of continuous Unplugging and plugging: The number of times should be strictly 5. Too few times will not trigger the reset.

Warning :

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

- a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate."
- b) The statement "Even used batteries may cause severe injury or death."
- c) The statement "Call a local poison control center for treatment information."
- d) A statement indicating the compatible battery type (e.g., LR44,CR2032).(LR44,CR2032). (LR44, CR2032).
- e) A statement indicating the nominal battery voltage, 3.7v ."
- f) The statement "Non-rechargeable batteries are not to be recharged."
- g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."

- a) The statement "Ensure the batteries are installed correctly according, to polarity (+ and -)."
- b) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- c) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations."
- d) The statement "Always completely secure the battery compartment. If the battery compartment does not close securely. stop using the product, remove the batteries, and keep them away from children."

