


正面

Multi-function mixer sound card

User's guidance



Support major live broadcast apps

Compatible with computer and mobile phone

Multi-function mixer sound card


To respected user:

This product is a professional recording live broadcast equipment that is very popular nowadays for web live broadcast, mobile K song and other platforms.The product with a built-in dual-core DSP digital chip can switch multiple scene modes arbitrarily and supports dual microphones, dual live broadcasts, dual headphones.Also,it has adjustable treble and bass, one-key dodge, one-key elimination of original sound, one-key noise reduction, multiple groups of sound change fine-tuning and other functions.It supports most live broadcast software, such as TikTok, Zynn, Singba, Wesing, Love Sing, Yingke, Huajiao, Nonolive and other live platforms.

About the usage guide

Our company has conducted a strict and careful check of the usage guide, but we cannot guarantee that the usage guide is completely free of errors and omissions.The pictures in this user guide are for reference only. If any individual pictures do not match the actual display of the product, please refer to the actual product.In order to provide better services, the company reserves the right to modify the products and content described in this user guide at any time without notice.

Connection diagram



Hardware Introduction

Hardware Introduction


I、Functional Area Introduction:

1. : Press this button lightly to enter the power on state.
2. :Lightly press this button to turn on or off the ear return function.
3. :Lightly press this button to mute the microphone sound, and long press again to unmute the microphone.
4. :By default, the "internal storage" is turned off when turned on. If you want to turn on the "internal storage", lightly press this button and the light will flash. This feature is used on the computer. (Turning off the internal speaker means turning off all sounds on the computer. In the live broadcast room, the other party cannot hear all the sounds on your computer, only the sound of the microphone.)
- 5.Avoid: Lightly press this button to turn on the dodge function light flashing. When the microphone sound is input, the accompaniment sound fades out or decreases, and the accompaniment returns to normal after the microphone sound ends; Lightly press this button again to turn off the dodge function.
- 6.Follow Singing: Lightly press this button to turn on and off the singing function; (Long press this button to turn on and off the original sound).
- 7.Autotune: Suitable for singing electronic music songs. Pressing this key lightly in electronic music mode can adjust the electronic music tone and provide voice prompts.
- 8.Mode:Lightly press this key to switch in sequence:Popular、Professional、Voice、RAP、Girtomale、Male to Girl、To child、Monster.
9. In BT mode, you can control the previous song, play pause, and next song; (Note: In the tone changing mode, it is for fine-tuning the tone, while in other modes it is for controlling the up and down tracks).

Hardware Introduction

10. Special effects: Short press one of the buttons to output an atmosphere sound effect during live streaming.
 - 11.Customization: Long press one of the buttons, and when you hear a prompt sound, you can enter the custom recording mode. Release it to automatically save the recording. (When long pressing this button again and hearing a prompt sound, it will automatically delete the previous recording content and re record). To delete a custom recording: Long press the noise reduction button to enter the deletion process. At this time, all custom indicator lights will flash, and once the deletion is successful, they will become constantly on.
 - 12.Noise suppression: The default noise reduction on light flashes, which can reduce microphone environmental noise and improve recording quality. Press this button lightly to turn off the noise reduction light and keep it on; (Long press this key to delete custom recorded content, and the corresponding indicator lights for all custom keys will flash. If the deletion is successful, the light will remain on.).
 - 13.Indicator light: Singing mode indicator light; Lightly press the mode button to select the mode, and the corresponding indicator light will flash.
 - 14.Indicator light: This indicator flashes when OTG is not connected.
 - 15.indicator light: If the OTG connection is successful, this indicator light will flash.
 - 16.Monitor Vol:Rotate in the "+" direction to increase headphone volume output, and rotate in the "-" direction to increase headphone volume output. The indicator light will change accordingly.
 - 17.Mic Echo:Rotate in the "+" direction to increase microphone reverberation intensity, and rotate in the "-" direction to decrease microphone reverberation intensity.
 - 18.Mic Vol:Rotate in the "+" direction to increase microphone volume input, and rotate in the "-" direction to decrease microphone volume input. The indicator light will change accordingly.
 - 19.Indicator light
- Charging indicator light: When charging, the indicator light turns red and the fully charged light turns off.

反面



II、Interface name

1. Live streaming: Connect your phone and sound card through a 3.5mm audio cable for live streaming and recording.
2. Mobile phone/computer: Supports Type-C data cable connection to 5V/1A power supply for charging and Connect to a computer or phone via Type-C and live stream while charging.
3. Earphones: Earphones connected to a 3.5mm interface.
4. Microphone: Can be connected to a 3.5mm interface microphone.

Product Specifications

III、Product parameters

Signal to noise ratio: 106dB
Output Power: 600mW
Whole machine power consumption: 5W
Rated input: 5V/1A
Recording: 16bit/48KHz,90dB signal to noise ratio
Replay: 16bit/48KHz,100dB signal to noise ratio
Distortion: 0.1%(recording), 0.005%(replay)
Battery capacity: 600MA

Interface type

Mic interface: 3.5mm		
Live streaming interface: 3.5mm	OTG charging interface: Type-C	Ear microphone interface: 3.5mm

- 1.This product is suitable for use in tropical climates.
- 2.The altitude area applicable to this product is determined by the power adapter finally selected.
- 3.If consumers use a power adapter to supply power, they should purchase a power adapter that has obtained CCC certification and meets the standard requirements.

Common problem troubleshooting

Common problem troubleshooting

- [1]The device does not work when it is turned on.
1)Please check if all cables are connected correctly.
2)Please check if the device has enough power, please charge it and try again [with battery version].
- [2]There is noise or no sound when using the headset.
1)Please try to re-plug the headset, and plug the headset before turning on the sound card.
2)Please check if the monitor switch is on.
3)Please use the original headset of the phone.
- [3]Noise is heard during live broadcast.
1)Turn down the microphone volume appropriately.
2)Check if the microphone and headset are fully inserted in the opposite position.
[4]No accompaniment can be heard during live broadcast.
1)Turn up the accompaniment volume.
2)Check if the accompaniment cable is fully inserted into the device and the accompaniment phone.
- [5]They cannot hear the reverb and accompaniment during the live broadcast.
1)Turn up the accompaniment volume.
2)Check if the accompaniment cable is fully inserted into the device and the accompaniment phone.
- [6]The sound of the microphone cannot be monitored.
1)Check if the microphone or headphones are connected properly.
2)Please check if the monitor switch is on.
- [7]The computer cannot recognize the sound card.
1)First connect the sound card to the computer, then restart the computer.

After purchasing this product, please read the following three guarantees regulations carefully to ensure that the product is effectively protected.

Unless otherwise noted, the user can enjoy a warranty period of 12 months for the purchased product due to its own quality problems (not product software failure) from the date of purchase.
.If users encounter product quality problems, they can request three guarantees from the designated service department of our company. If they need to be shipped, the user must bear the related costs of transportation.
.User must take the initiative to provide this valid warranty service certificate when requesting the three guarantees service.
.Additional services beyond the three-guarantee service of the product shall be charged in accordance with relevant regulations. The product warranty period after repair is three months from the date of pickup.
.The three-guarantee service provided by our company is limited to products with quality problems, and does not include compensation for losses caused by user accidents and any other indirect or direct losses.
.The user should take the initiative to fill in this voucher as required by the seller of purchase and keep it properly. Our company does not assume the consequences of not filling in this voucher as required, nor does it assume the seller's commitment to users beyond the warranty service regulations.

The following situations do not belong to the scope of the three guarantees. Our company reserves the right to provide services for products outside the scope of the three guarantees.

The product' s valid warranty certificate, original purchase certificate cannot be presented, or beyond the specified warranty period.
.The random information of the product is missing, such as the use guide, warranty card, data cable, product packaging and other accessories.
.Product failure or damage caused by operation that does not follow the instructions. Repair, disassemble, add or replace the original components without permission.
.The original serial number label is altered, worn, replaced, torn, etc.
.Product hardware damage, wear, and indirect software failure caused by the transportation process.
.Compatibility issues with current and future operating systems or product malfunctions or damage caused by this.
.Product performance failures and damages caused by force majeure such as normal wear, aging, improper placement, humidity, wrong connection, unstable voltage, external force, etc.
.The user personally has subjective requirements or objections to the quality, performance, function, feature, etc. listed or not listed in the user guide.

Warranty information

Dealer information

.Dealer's signature:
.Selling price:
.Sale date:

User information

.Customer's name: Tel:
.Address:

Repair record

.Fault description:

Note: Please fill in in detail, * is required, missing or false information will be deemed invalid.
This certificate is only used as a basis for providing three guarantees of services and does not have other legal effects. The maintenance record shall be subject to the maintenance certificate of the authorized service organization.

80*120mm

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.