

ThyFenno



PRODUCT PARAMETERS

LIGHT POWER	MIN 0.5W	MAX 3W
CHARGING POWER	5V	2A
COLOR TEMPERATURE	3000K	4500K 6000K
BATTERY CAPACITY	8000mAh	

【Warm Tips】

If you receive a product that is damaged or has missing accessories, please contact ThyFenno Customer Service, we will replace it with a new one.

USER MANUAL

ThyFenno 1T L4

Remote Control Battery Operated Wall Sconce






Note: Please read the user manual carefully before procoessing use and installation

INSTALLATION




Step 1:

Screw the crystal & stick.



Step 2:


According to the hole-distance of the mounting bracket, drill 2 holes and fix the mounting bracket on wall (Attention: Make sure the bracket is horizontal and steady on wall).



Step 3:

Hang the lamp on wall. Holding the lamp, point to the steel bar on the mounting bracket and stick in it. The lamp should be very steady on wall with hanging and magnetic suction synergy.

INSTRUCTION





Turn on/off the light

Dimming color temperature

Turn up/down brightness

Timing: 15/30/60mins

Option 1: Use the remote control



100%



50%



10%

Option 2: Short press the button to turn the light on/off and change the color temperature, long press the button to turn up/down the brightness.

CHARGING



Step1 :

Pull out the lamp.



Step2 :

Charged with a Type-C port. Blue light on the button on while charged and off after full-charged.(6 hours of charge)



NOTE

- ★ At first use, short press the light button twice to activate the product.
- ★ Be sure to securely tighten the panel to prevent droppings.
- ★ If the product can not be turned on or the light is weak, you can try to charge it first. If the product still do not work, please contact us for help.

ThyFenno

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.