


REMOTE CONTROL CAR MANUAL

Please read the instructions carefully before use
and keep them properly for future use.

1. Main parameters:

1. Frequency: 2.4GHz
2. Applicable age: 8 years old and above
3. Remote control distance: 25 meters
4. Driving speed: 8km/h
5. Play time: 25 minutes
6. Charging time: 1 hour
7. Remote control car battery: 3.7V rechargeable lithium battery
8. Remote control battery: "AA" 1.5V X 2 (not included)

2. Description of Function Buttons and Component Names:



3. Product Function Description:

1. As shown in the above figure, use a screwdriver to loosen the screw, open the battery cover, and correctly place it according to the battery polarity mark 2 AA batteries (to be purchased separately), then cover the battery cover and lock the screws.
2. Open the battery cover under the car and connect the 3.7V rechargeable lithium battery power plug correctly, with the positive pole facing the positive pole (red line), Negative pole to negative pole (black line), then put it into the battery box under the car, cover the battery cover, and lock the screws.
3. First, turn on the power switch of the remote control car. At this time, the lights of the remote control car are flashing and in the frequency check mode. Then turn on the power switch of the remote control car, At this point, the remote control car lights stop flashing and emit a startup sound, indicating successful code pairing. Press the throttle trigger to enter throttle mode, Three continuous throttle sounds, enter play mode.
4. Throttle: Forward/Backward (the vehicle speed can be controlled in full proportion by pressing the throttle force and stroke).
5. Wheel hub: Left turn/right turn (when turning, the simulated car's side lights flash and accompanied by a turning sound).
6. Sound button: Press the button briefly and the car will emit a horn sound; Press the button for 2 seconds to switch the car to silent mode; Press the button again for 2 seconds to switch the car to audio mode.
7. Bottom adjustment: When the car cannot drive in a straight line normally, the bottom adjustment should be adjusted in a deviated direction.
8. Play time: about 25 minutes; When the speed slows down, please replace the car battery in a timely manner; The surface where the battery is placed is not hot to charge the battery.
9. TPC charging model, please turn off the power switch of the car when charging, and insert one end of the TPC charging cable into the 5V adapter, Insert the other end into the car charging port, and the charging indicator light will turn on. When the charging indicator light goes out, it indicates that the battery is fully charged. (Note: When turning on the car power switch, it will not be able to charge. Please unplug the charging cable when charging is complete.)

⚠ WARNING:

- *Toy cars use 3.7V rechargeable lithium batteries; The remote control uses 2 1.5V "AA" batteries.
- *The product contains small parts that may pose a risk of ingestion or suffocation.
- *This product can only use the charging cable provided by the factory to charge the product battery.
- *Regularly check the charging cable, plug, casing, and other accessories. If any damage is found, stop using immediately until it is repaired.
- *The USB cable, battery box, and battery need to be plugged into the designated power source that matches the product logo.
- *Rechargeable batteries can only be charged under adult supervision.
- *Rechargeable batteries should be removed from toys before charging.
- *Non rechargeable batteries are not rechargeable.
- *The wiring terminal should not be disconnected.
- *The battery should be placed with the correct polarity.
- *Do not mix old and new or different types of batteries.
- *Exhausted batteries should be promptly removed.
- *If encountering thunderstorms, lightning or other weather conditions during remote control, please stop the remote control immediately.
- *Do not short-circuit, disassemble, modify, impact, squeeze, puncture, drop from a height, or put into fire the battery to avoid danger.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.