


Thank you for purchasing the Compressor Box. Used with Autel diagnostic tools (purchased separately), this product can be used to diagnose compressor's operating status on vehicles.


Our products are manufactured to a high standard and — when used according to these instructions and properly maintained — will provide years of trouble-free performance.

Product Description


Front View



Top View



Bottom View



1. Status LED — refer to Table 1-1 Status LED Description for details.
2. QD Socket — connects the adjustable strap with hook for hanging the Compressor Box.
3. USB Port — connects the AC tablet for firmware updates or data interaction when Bluetooth communication fails.
4. DB26 port — connects the main cable.

Table 1-1 Status LED Description

LED	Color	Description
Status LED	Green	- Lights green when the device is ready for use. - Flashes green when USB is communicating.
	Yellow	- Lights yellow during self-test and internal preparation. - Flashes yellow when the firmware is updating.
	Blue	- Lights blue when the device is connected via Bluetooth but there is no communication. - Flashes blue during Bluetooth communication.

Getting Started



WARNING: Before operating or maintaining this device, please read these instructions carefully, paying extra attention to the safety warnings and precautions. Use this device correctly and with care. Failure to do so may cause damage and/or personal injury and will void the product warranty.

1. After connecting the AC tablet with the VCI, tap **HVAC** on the AC tablet.



2. Select **Compressor Test** on the HVAC main menu.



3. Select **Special Tool Drive** on the Drive Selection screen.

4. Follow the on-screen cable connection diagram to connect the equipment and the prompts on the screen to perform the test. Tap Next to continue.

Compliance Information

Autel Intelligent Technology Corp., Ltd. hereby declares that the radio equipment type Compressor Box is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

<https://www.autel.com/download.jhtml>



NOTE: The illustrations in this guide are for reference only. Please refer to the actual product.

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction.