



EUT SETUP PHOTOS

CE - Front View




CE - Side View




RSE (9kHz-30MHz)



RSE - Front View (30 MHz-1 GHz)




RSE - Back View (30 MHz-1 GHz)



RSE - Front View (1 GHz-18 GHz)



RSE - Back View (1 GHz-18 GHz)



RSE - Front View (Above 18 GHz)



RSE - Back View (Above 18 GHz)

