


LCD Projector




※Quick Installation Guide※

Please read this manual carefully before use and keep it for future reference.

1. In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
2. Please use the original power adapter. The projector should work under specified rated power supply.
3. When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
4. Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
5. Regularly clean projector vents, or dust may cause cooling malfunction.
6. Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
7. Please handle with care during daily use.
8. Please cutoff the power if the projector is out of use for longtime.
9. Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure description

This manual is for reference only. It is subject to change without prior notice. reserves the right of final interpretation.




LENS




ROTATE

AIR INLET



Remote Component and Functions



Switching Applications

On the home screen, select "APPS" and press the OK button to view the installed applications.


Press any application icon to switch between them. All applications can be clearly distinguished by their icons.



Settings

On the home screen, select the "Settings" option and press the OK button to enter the settings screen.


From here, you can configure general, display, and system settings.



Network Settings

On the settings screen, select the WiFi icon and press OK to access the network settings.

To connect to a WiFi network, toggle the switch to turn on WiFi. Within seconds, a list of available networks will appear.



Select the SSID of the network you wish to connect to and press the OK button, then enter the password when prompted to establish the connection.


Bluetooth Settings

Connecting Bluetooth Headphones

On the settings screen, select the Bluetooth icon and press the OK button to open Bluetooth settings.

To pair a Bluetooth device, toggle the switch to enable Bluetooth. A list of available devices will shortly appear.


Select the device you wish to pair with and press the OK button. Once pairing is complete, the projector will connect successfully.



Language Settings

On the settings screen, select the Language icon and press the OK button to access the language options.

Choose your preferred language and press the OK button to confirm.



Time and Time Zone Settings

To adjust the date and time zone, select Time and Time Zone to access its settings.

Toggle the switch to enable time settings, then adjust the time zone as needed.





Projection Settings

In Display Settings, you can finely adjust the Trapezoid and Manual Keystone configurations to achieve the best image quality.

To adjust the Trapezoid Settings, select the second icon and press the OK button.


Then, toggle the switch to enable the function and follow the on-screen instructions to complete image calibration.



Signal Source


After connecting the projector to an external device, select the "Source" option on the home screen to access the input selection menu.

Choose the appropriate input source based on the connected device and press OK to confirm.




Other Settings

In System Settings, you can adjust the date and time, restart the device, view projector information, or update the firmware.




Android

Make sure your Android device is connected to the same Wi-Fi network as the projector. Then, follow these steps:
Home screen → My Apps → QuickShare → Follow the steps to connect.




Android Device:




Airplay

Make sure your iOS device (such as an iPhone or iPad) is connected to the same Wi-Fi network as the projector. Then, follow these steps: Home screen → My Apps → QuickShare → Turn on screen mirroring → Connect.



iOS Device:



Safety Instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive strong electromagnetic interference (large radar stations, power stations, substations), etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

Disclaim

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.

FCC Statement

1.This device complies with Part 15 of the FCC Rules,Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference.
- (2)This device must accept any interference receivedincluding interference that may cause undesired operation.

2.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.