REVOLT™

6+

SHARK WHEELIE MONSTER

User Manual

TG1033

2.4GHz Remote control

PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY BEFORE USE.

The materials, specifications, parts and packaging mentioned in this manual are for reference purposes only. We are not responsible for any changes made to this printed material, nor are we able to inform customers of any updates or changes. Please refer to our website: R3VOLT.COM for the latest information.

Important safety information

Thank you for buying this REVOLT item. To ensure that you operate the vehicle correctly, please read these instructions carefully before first use and store them in a safe place for future reference.

Safety information

*Keep the smaller-sized accessories out of the reach of children.
*Do not store batteries in a hot environment (e.g. near open flames or a heating device).
*Children must be supervised by an adult when operating the vehicle. The vehicle should always remain within the line of sight of the driver (or instructor).
*Do not recharge non-rechargeable batteries. When installing or changing the batteries, ensure that they are connected in the correct polarity. Do not mix old and new batteries or different types.
*Do not short circuit the battery terminals.
*If you do not plan to use the vehicle for at least 10 days, discharge the battery to 40%-50% (i.e. if the battery is fully charged, drive the vehicle for half of the total driving time). This helps to prolong the lifespan of the battery.
*You must only use the charging cable provided. Disconnect the charging cable from the vehicle before cleaning.
*Regularly inspect the charging cable's wires, plug socket, outer casing and other accessories to ensure they are not damaged. If there are any signs of damage, discontinue use immediately until repaired.
*After use, ensure that the vehicle and remote control are switched off and remove the batteries in the remote control.

*The packaging and this manual contain important information and should be kept in a safe place for future reference.

Repair and maintenance

*Clean the product regularly with a clean, soft cloth.
*Avoid exposing the product to direct sunlight or heat.
*Although this product is designed to drive on water, do not submerge the product in water, as it may damage the electronic components.
*Water may enter the product during play and should be dried throughly afterward.

About this product

Specifications

Remote controlled vehicle

Weight	686g (included battery)
Dimensions	25.5x20.5x19.5cm
Remote control range	15-20m
Charging time	about 140 mins
Operating time	15-20 mins
Battery	7.4V 500mAh rechargeble battery (included)

Remote control

Operating frequency	2.4 GHz
Battery Requirements	2xAA 1.5V batteries(not included)

Contents



Remote control X1 | RC Truck x 1 | 7.4V battery X1 | USB charging cable X1 | Instruction Manual x 1

Operation Instructions

1. Press button ① to ride wheelies on the back tyres.

2. Press button ② to ride wheelies on the front tyres.

3.Push both the left joystick and the right joystick forward simultaneously, and the car will move forward.

4.Push the left and right joysticks backward simultaneously, and the car will move backward.

5.Press the left joystick forward/ backward,and the car will move forward/backward turning right.

6.Press the right joystick forward/ backward,and the car will move forward/backward turning left.

Part Descriptions



Battery Installation

Remote control

1.Remove the battery cover on the remote control and load the AA batteries into the battery compartment according to the indicated polarity.
2.Replace the battery cover.

Battery Installation

RC Truck

1. Open the battery compartment cover at the base of the truck.
2. Disconnect the cable between the truck and battery.
3. Connect the charging cable with the battery's cable for charging.
4. Once the battery is fully charged, disconnect the charging cable, reconnect the battery cable and truck's cable inside the battery compartment.
5. Tightly secure the battery compartment cover back in place and tighten the screw.

Battery Charging Tips:



1.The new battery pack needs to be charged before first use.
2.Insert the plug of the battery pack to the port of the USB charging cable, and connect the USB charging cable plug to a power source.
3.The indicator light is "red" when charging, and "off" when fully charged. Do not overcharge.
Charging for too long will not increase the battery capacity.
4.Check the RC Truck, battery, charging cable, plugs and other parts regularly.

Powering Down:

1. When play has ended, turn off the power of the remote control first, then turn off the power of the truck.
2. It is recomended to remove the batteries from the remote control after play.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.
Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not / installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Decoration of Conformity Inserts：
"Hereby, GuangDong Syma model drone Industrial co, ltd, declares that this drone is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU."

GUANGDONG SYMA MODEL AIRCRAFT INDUSTRIAL CO., LTD.

Address: NO.2 WEST XINGYE ROAD LAIMEI INDUSTRIAL AREA CHENG HAI, Shantou, China.

Sales hotline: 0754-86980668, After-sales hotline: 0754-86395095

The manufacturer the right to the final interpretation of this instruction manual.