



6.5 Setup Photographs:


LNK100 CRM Test Setup




LNK100 CRB Test Setup



LNK100 SAB Test Setup




LNK100 SAM Test Setup




7.5 Setup Photographs:

LNK100 SAB Test Setup




8.5 Setup Photographs:

LNK100 SAB Test Setup




9.5 Setup Photographs:

LNK100 SAB Test Setup



10.5 Setup Photographs:

Test Setup, RE 9 kHz-30 MHz, Loop antenna on X-Axis




Test Setup, RE 9 kHz-30 MHz, Loop antenna on Y-Axis




Test Setup, RE 9 kHz-30 MHz, Loop antenna on Z-Axis




Test Setup, RE 30-1000 MHz



Test Setup, RE 1-18 GHz




Test Setup, RE 18-25 GHz



11.5 Setup Photographs:

Test Setup, RE 30-1000 MHz



Test Setup, RE 1-13 GHz

