折后尺寸：77x110mm 展开尺寸：77X540mm
材质：105G双铜，正反面单色印刷 ，折页

正面

maxpower



MPD207
USER MANUAL

ACCESSORIES

A: BT speaker
B: Type-C charging cable
C: User manual





PANEL FUNCTIONS



1.【▷】:Mode selection / Play / Pause :Long press to switch modes: USB,MicroSD,FM,BT; Short press to play/pause;Short press to start auto channel search under FM mode; When an incoming call arrives: short press to answer or hang up; double-tap to reject the call or redial the last number.
2.【 - 】:Volume Down / Previous Track :Long press to decrease the volume, short press to play the previous track; short press to switch to the previous channel under FM mode.
3.【 + 】:Volume Up / Next Track :Long press to increase volume, short press for next track; Short press to switch to the next channel under FM mode.
4.【 ☼ 】:RGB mode / TWS mode:Short press to switch light effects; there are five light modes in total;Long press to enter TWS mode.
5.【 ⏻ 】:Power on/off :Switch power on / power off.
6.【DC 5V】:Charging Port: It's for charging.
7.【TF】:Insert the TF card to play MP3 music.
8.【USB】:Music playback on USB stick.

OPERATIONS

1.Power On/Off

Just toggle the power switch.

2. BT Mode

1.When you turn on the MaxPower Speaker, it will already be in the BT mode and ready to pair to your mobile device/smart device.
2. Scan for BT device on your mobile phone. Please select "MPD207" on your mobile device.
3.Once paired, the volume and tracks can be controlled by your cellphone or your speaker control panel.



OPERATIONS

3. TWS Connection

1. When you turn on the Speaker, it will already be in the BT mode and ready to pair to your mobile device/smart device.

2.Long press the " ☼ " button on one (master) speaker. A prompt tone will sound right away, indicating the master has entered search mode with a 30-second pairing countdown.
When the two speakers connect via TWS successfully, both will play a prompt tone simultaneously, and the slave unit's blue light will stay solid on.
(If pairing fails, ensure the speaker is not connected to any previously paired Bluetooth devices.)

3.Once both the speakers are connected via TWS, then repeat the same process that you normally would use to connect them via BT from your cellphone.



OPERATIONS

4. Volume Control

1.Press and hold the + button to increase the volume.
2.Press and hold the - button to decrease the volume.



5. LED Lighting Mode

After turning on the device, short press the M key to switch the RGB lighting modes
(Mode 1, Mode 2, Mode 3, Mode 4, RGB-OFF)



OPERATIONS

6. Music Card

Insert the music card into the corresponding interface to play music MP3 is supported.



反面

OPERATIONS

7. Power Saving

Speaker will power off automatically to save battery when nothing is connected after 10 minutes.

8. Charging

Important note :
Preferably use supplied USB-C charging cable
Use an output source 5V/500MA (or above)
Charge when you hear low battery prompt tonefully charged.
The red indicator will be normally on while charging and switch off after



FUNCTION INSTRUCTIONS



LED lighting	Total 5 LED lighting modes
Status indicator	Power on/ TWS (blue indicator)
	Charging (red indicator normally on)
	Fully charged (red indicator off)

SPECIFICATIONS

Product Name	MPD207
Battery Capacity	3.7V/1500mAh
Playing Time	5-6hours(70% volume, LED lighting off) 6-8 hours(50% volume, LED lighting off)
Charging Time	2-4 hours
Charging Current	5V⎓500MA
Speaker Unit	10W
Product Size	115*115*133mm
Product Weight	g

FREQUENTLY ASKED QUESTIONS

Q1: What kind of charger should we use for the speaker?
A: All common USB chargers can be used, while we suggest the ones 5V/500mA or above 500mA.

Q2: What if there is noise or discontinuous sound during playing?
A: The speaker can be normally used within 10m under no obstruction environment.
If it is beyond 10m or with obstruction, there might be noise or discontinuous sound.

Q3: Why the speaker power off automatically after power on without any operation?
A：When there is no bluetooth pairing in 10 minutes, the speaker will shut down automatically to reduce power consumption.

Q4：Why does the speaker cannot connect the once-paired cellphone?
A: First, remove the speaker's paired name from the cellphone's Bluetooth list and then restart pairing.

Q5: When speaker can not be turned on or used normally.
A: Please charge it for some time, then long press power on button 10-30s to reset.

FREQUENTLY ASKED QUESTIONS

Notes:
1. Please read this manual carefully before use and keep it properly.
2. For the first use, please fully charge the product.
3. Pls use certificated adapter that has passed national safety certification.
4. If you do not use the product for a long time, be sure to charge it once within a month at least to maintain its performance.
5. Do not use this product in an extremely cold or hot environment, such as temperature beyond the range of 5-35℃. If use it beyond the above range, the product may stop automatically to protect the i nternal circuit.
6. When charging it in a high temperature environment, the product may automatically stop charging to protect the battery. At this time, the charging indicator usually ashes quickly to indicate that the charging environmental temperature or the product internal temperature is too high.
7. Storage environment temperature: -5~35℃ RH<70% (recommended 25℃±5).

Important safety instructions:
1. Do not disassemble or repair this speaker personally, otherwise it may cause product damage or personal injury.
2. Do not use it in dusty, humid, dry, and high-temperature environment.
3. Do not place this product near a heat source, or a place with direct sunlight, a lot of dust, or mechanical vibration.
4. In order to reduce the risk of fire, please do not cover this product with newspapers, tablecloths, curtains etc., during use.
5. When the product is damaged (such as the power cord or plug is damaged, liquid enters or objects fall into the device, unable to operate normally or falls), it must be repaired.
6. When the product is fully charged, do not connect it to the charger for further long time charging.
7. The maximum ambient temperature should not exceed 40℃.

*This speaker supports mobile phones/ tablets/ PCs etc. Here this User Manual isillustrated based on mobile phones.

Federal Communications Commission (FCC) Statement.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by Universal Electronics, Inc. may void the FCC authorization to operate this device.Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:This device complies with FCC RF radiation exposure limits set forth for anuncontrolled environment. The device is installed and operated withoutrestriction.
FCC ID：

maxpower

MADE IN CHINA