

CONTENTS

MY VERIZON

Manage your account online or from your device with My Verizon.

BASICS

How to use your new device—from charging the battery to taking a picture.

BACKING UP YOUR CONTENT

Give yourself peace of mind by backing up your files.

APPS AND FEATURES

It's a mobile world and it's yours to conquer—with music, video, web browsing, email and picture messaging, plus tools for navigation and family safeguards.

WELCOME

THANK YOU FOR CHOOSING VERIZON WIRELESS

You're now part of a growing movement that's about speed, signal and strength. So go ahead, make yourself heard.

This book will show you how to unleash the potential of your new device. Assistance is at your fingertips at **verizonwireless.com**. Customer Service is at your disposal at **1-800-922-0204** or at any Verizon Wireless Store. A comprehensive User Guide is available on demand—simply download one at **support.vzw.com/phones** or call **1-888-987-HELP (4357)** to order a copy.

NOTE: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.

IMPORTANT CUSTOMER INFORMATION

DATA PLANS AND FEATURES:

Content and Internet Access

Many services and applications offered through your device may be provided by third parties. Before you use, link to or download a service provided by a third party, or an application such as a non-Verizon Wireless location-based GPS-type service, chat room, marketplace or social network from your device, you should review the terms of such service or application and applicable privacy policy. Personal information you submit may be read, collected or used by the service or application provider and/or other users of those forums.

Verizon Wireless is not responsible for any information, content or services you access, download or use from the Internet. You are responsible for maintaining virus and other Internet security protections when accessing service. For additional information, visit the Verizon Content Policy at **responsibility.verizon.com/contentpolicy**.

Your Verizon Wireless Customer Agreement terms and conditions and certain other specially identified terms govern your use of any Verizon Wireless products and services.

IMPORTANT CUSTOMER INFORMATION

DRAFT

MY VERIZON

Save time. Save money. Register now at **verizonwireless.com/myverizon**.

- **Manage your account.** Quickly check your voice, text and data usage or make adjustments to your Plan at any time.
- **Get personalized support.** My Support answers your questions quickly.
- **Pay bills your way.** Go green and set up Paperless Billing, make a one-time payment, or use Auto Pay and never worry about missing a payment.
- **Much more.** Transfer your contacts in no time with Backup AssistantSM, move your media, pick your Friends & Family[®], or view email in one place from popular internet-based email accounts, including Yahoo![®], AOL[®], Gmail[®] and Windows Live.

BASICS

FEATURES

1. SIM CARD SLOT
2. 3.5 HEADPHONE JACK
3. SPEAKER
4. POWER/LOCK KEY
5. VOLUME KEY
6. WIDESCREEN HD
DISPLAY
7. CHARGER PORT
8. 2 MEGA PIXEL FRONT
FACING CAMERA/
CAMCORDER LENS
9. SPEAKER
10. 3 MEGA PIXEL
CAMERA/
CAMCORDER LENS
11. FLASH


FIRST STEPS

INSERTING YOUR 4G LTE SIM

Your SIM (Subscriber Identity Module) Card is a small rectangular plastic card that stores your phone number and important information about your wireless service.

To install your 4G LTE SIM Card:

1. Open the cover to the SIM card slot and carefully insert the 4G LTE SIM card with Verizon logo face up.
2. Push the SIM until it clicks into place.



CAUTION: Do not bend or scratch your 4G LTE SIM Card. Avoid exposing your SIM Card to static electricity, water or dirt. For additional information about 4G LTE SIM Cards, visit verizonwireless.com/4GSIM. The 4G LTE SIM Card **MUST** remain in the device when in use.

REMOVING YOUR 4G LTE SIM CARD


- Open the cover to the SIM card slot and carefully push the 4G LTE SIM card inward to release from the socket.

NOTE: Should your 4G LTE SIM Card be lost or damaged please call **1-800-922-0204** to speak with a Customer Service Representative. From outside the U.S. call **+1-908-559-4899** for **24/7** Global Support.


NOTE: The Verizon Wireless 4G LTE microSIM Card is compatible with some Verizon Wireless 4G LTE certified device. You can move the 4G LTE microSIM Card from one device to another and your wireless service will work seamlessly as long as you have a compatible device and service plan. To see which devices are compatible with your Verizon Wireless 4G LTE microSIM Card, visit verizonwireless.com/certifieddevice.

CHARGING YOUR DEVICE

1. Carefully slide the Outlet Connector into the Charging Head. Make sure the connection is secure.
2. Connect the USB cable to the Charging Head.



3. Insert the charger into the charger port at the bottom end of the tablet.



Incorrect

4. Plug the outlet connector into a compatible electrical outlet.

WARNING! Please use only an approved charging accessory to charge your device. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.

POWERING YOUR DEVICE ON/OFF

IMPORTANT: It's important to fully charge the battery before turning on your device.

To power on your device:

- Press and hold the **Power/Lock/Unlock button** on the left side of your tablet.



To power off your device:

1. Press and hold the **Power/Lock/Unlock button** until the Tablet options screen appears.
2. Touch **Power off** → OK.

LOCKING/UNLOCKING YOUR DEVICE

To lock the display:

- Press **Power/Lock** ( ).

To unlock the display:

- Press **Power/Lock** ( ) to wake the display, then drag  across the screen.

INITIAL DEVICE SETUP

When you turn on your wireless device for the first time, you have the option to quickly set up various accounts, such as Google™, Microsoft® Exchange ActiveSync®, other email accounts, and sign in to social networking sites. Simply follow the onscreen instructions to complete the initial setup of your wireless device.

1. Press and hold **Power/Lock** ( ) to turn it on.
2. Once you have received confirmation that your device is now active, touch **Proceed with setup process**.

3. Select a language and touch **Start**.
4. Turn off Google™ location services (if desired) and touch **Next**.
5. Touch Next to either follow the setup wizard to create or log in to your existing Google Account and go to the Home screen. Tap **Skip** to move on to the next step.
Record your Google Account information for future reference.

Username: _____@gmail.com

Password: _____

If you have an existing Google Account, your contacts from that account are then synced to your device.

TIP: Add additional accounts by doing the following: From the Home screen, touch **Apps** () → **Settings** () → **Accounts & sync** → **+ Add account** → select an email type and follow the prompts.

SETTING UP AN EMAIL ACCOUNT

1. To add additional email accounts, touch
Apps () → **Settings** () → **Accounts & sync** → **+Add account** (located in the upper right hand corner of the display).
 - Corporate is for Exchange server work email accounts.
 - Email is for most personal email accounts. For account details, contact the account provider.
 - Google is for adding another Gmail account.

SETTING UP A CORPORATE EMAIL ACCOUNT

1. To add additional email accounts, touch **Apps** () → **Email** ().
2. Enter your corporate email address and password and touch **Next**.
3. Select **Microsoft Exchange**.
4. Enter the correct **Domain**, **Password**, and **Server** information, then touch **Next**.
 - If your network requires SSL encryption, touch the **Accept all SSL certificates** field to place a checkmark in the box and activate this function.
5. Read the onscreen activation disclaimer and touch **OK**.
6. Adjust the various onscreen configuration fields and touch **Next**.
7. Identify your account with a unique name and provide the outgoing name text and then touch **Next**.

Note: If your exchange server requires this feature be active, leaving it unchecked can prevent connection.

HOME SCREEN

You'll see the home screen when you turn on the tablet or touch Home from a menu. The home screen gives you all your latest information in one place.



1. GOOGLE SEARCH
2. BACK
3. HOME
4. RECENT APPS
5. SCREEN CAPTURE
6. MINI APP TRAY

7. NOTIFICATION PANEL AND QUICK SETTINGS
8. CUSTOMIZATION
9. APPS
10. VOICE SEARCH

EXTENDED HOME SCREEN

The Home screen includes a total of five customizable panels. Flick left or right to see additional panels.



HOME SCREEN ICONS



Back: Touch to return to the previous screen or option.



Home: Touch to return to the Home screen.



Recent Apps: Touch to open a list of thumbnail images of apps recently used. Touch a thumbnail to open.



Screen capture: Touch to capture a picture of the current screen and saves it in the /Root/ScreenCapture folder.



Mini App Tray: Touch to display shortcuts to apps that you might need while working in other apps, such as your calendar, a memo pad, and a calculator. For more information, see page 28.



Google Search: Touch to search the web or your device.



Voice Search: Touch to search the web or your device by speaking.



Customization: Touch to display a sleek 3D customization page.



Applications: Touch to display the Applications panel.

CUSTOMIZING THE HOME SCREEN

ADDING WIDGETS

Widgets are self-contained applications that you can place on any screen to access your favorite features.



1. From the current screen, touch and hold an empty area of the screen. The **Widgets** tab is highlighted.
2. Touch a widget to add it to the highlighted Home screen or touch and hold the widget and drag it onto a desired Home screen.

NOTE: This same process can be used to add Widgets to other screens where screen space is available.

ADDING APPLICATIONS SHORTCUTS

Use App Shortcuts for quick access to applications or features, such as Email or other applications. Unlike Widgets, these are just shortcuts to onboard applications.



Adding Shortcuts to the screen

1. Navigate to the screen where you will place the shortcut.
2. Touch and hold an empty area of the screen.

3. Touch the **App shortcuts** tab, then touch an application to add it to the highlighted Home screen or touch and hold the shortcut and drag it onto a desired Home screen.
4. Touch  to return to the Home screen.

Adding App Shortcuts from the Apps Screen

1. From the Home screen, touch **Apps** () in the upper right corner of the display.
2. Touch and hold on an application icon until the Home screen selection area is displayed at the bottom of the screen.
3. Drag the application icon to the desired Home screen. The Home screen frame is highlighted.
4. Drag the application icon approximately where you want it on the Home screen.

CHANGING WALLPAPER

You can select a picture to display as the device's background screen or assign it to the Lock screen. Choose from an array of image sources such as: preloaded wallpaper images, live animated wallpapers, or select any photo you've previously stored in your Gallery.



1. From the current screen, touch and hold an empty area.
2. Touch the Wallpapers tab to choose an image source or assignment:
 - **Gallery:** Access the Gallery to choose a pictures taken with your device or picture downloaded to your device.

- Touch to display the **Set as** pop-up and then touch **Lock screen Wallpaper** or **Home screen Wallpaper**.
- Touch a picture to select it, then crop and resize it, if desired. Touch **Ok** to save the picture as wallpaper or touch **X** to cancel.
- **Live Wallpapers:** Choose from pre-loaded interactive animated wallpapers. Touch a wallpaper to see an example. If available, touch **Settings** to view options for the selection.
- Touch **Set wallpaper** to save your choice or touch **Cancel** to return to the Wallpaper menu.
- **Wallpapers:** Touch to display the **Set as** pop-up and then touch **Lock screen Wallpaper** or **Home screen Wallpaper**. Choose from pre-loaded wallpaper images.
- Touch an image to save it as wallpaper.
- Touch **Cancel** to return to the Wallpaper menu.

USING MORE FEATURES

More includes shortcuts to Browser bookmarks, Directions and Navigation, and an assortment of other useful items.




1. From the current screen, touch and hold on an empty area.
2. Touch **More** to view the additional widgets.
 - **Bookmark:** Launch a bookmarked web page.
 - **Contact:** View a contact you specify.
 - **Directions & Navigation:** Get directions and navigation from Google Maps.

- **Email account:** Access an Email account. Appears once an Email account is set up. If you have more than one Email account set up, touch the one to which you want to link.
- **Gmail label:** Access a Gmail label. Appears once a Gmail account is set up. Touch the label to which you want to link.
- **Latitude:** Locate your friends on a map and share or hide your location.
- **Music playlist:** Set up a link to a music playlist.
- **Settings:** Displays a list of Settings shortcuts. Touch an entry in the list.

NOTIFICATIONS

Notification icons appear in the System Bar, to the left of the Time when you receive a notification. Notifications indicate the arrival of Gmail, Email, alarms, calendar events, and so on. Tap a Notification icon for more detail. For example, tap the available Wi-Fi network icon to see available wireless connections.



Notifications icons

Time


Tap the Time field to open the Notifications list to view all of your current notifications. Tap a Notification in the list to display the item. For example, tap a Gmail entry to open the Gmail application and view the message.

Most apps that send notifications, such as Gmail and Google Talk, have their own settings, which you can use to configure whether and how they send notifications, whether they sound a ringtone, and so on. See the documentation for those apps for details.

STATUS DETAILS

To display the current date and time, battery status, and Wi-Fi connectivity status, open Status Details.

1. Touch the **Time** in the lower right corner to display the Quick Settings pop-up.




The Quick Settings are:

- **Mobile data:** Touch to enable or disable Mobile data.
- **Notifications:** Touch to enable or disable system and application notifications.
- **GPS:** Touch to enable or disable the device's GPS functions.

- **Sound / Vibration:** Touch to enable or disable sound mode. When sound is disabled, Vibration is enabled.
 - **Auto rotation:** Touch to enable or disable automatic rotation. When disabled, the screen does not rotate when you turn the tablet.
 - **Brightness slider:** Touch and drag the slider to set the brightness or tap AUTO to allow the device to set brightness automatically based on available light and battery charge status.
 - **Settings:** Touch to open the Settings menu.
2. Tap an Alert entry to display the details or tap X next to a notification to remove it.
 3. Close the Quick Settings by either tapping X in the upper right corner of the Quick Settings pop-up or any other part of the screen.

MINI APP TRAY

There are shortcuts available that link to apps that you might need while working in other apps, such as your calendar, a memo pad, and a calculator. In some cases, these shortcuts are actually links to the part of the app you need most and they contain link to the actual app where you can use other functions.



1. From any screen, tap (Mini App Tray) at the bottom, center of the screen.
2. Tap any of the following icons to display the associated application.




Task Manager: Displays the Task manager.




Calendar: Displays the calendar with today's date circled.




World Clock: Displays the time for your set locations.



Pen Memo: Displays the Pen memo app, which you can use to create and save a memo.



Calculator: Displays a basic calculator.



Music Player: Displays the music player.

SEARCH

Google Search

Search the internet, and your device, using the Google search engine.

1. From a Home screen, touch **Google** () in the upper left corner.
2. Use the keypad to enter search criteria. Suggestions display below the text entry area.
3. Touch a suggestion to search for that term.
 - or –
 - Touch **Go** to start the search.A browser window displays the search results.

Voice Search

Voice Search offers voice-activated Google searches.

Tip: Voice Search is also available on the Google Search widget, which appears on a Home screen by default.

1. From a Home screen, touch **Voice Search**



() in the upper left corner.

2. Touch **Speak now**, then speak your search criteria slowly and clearly. Google searches for the information and displays results.

DRAFT

REMOVING ICONS FROM THE HOME SCREEN

Touch and hold the icon until **Remove** (🗑️) appears at the top right corner of the screen, then drag the icon to the **Remove** (🗑️) to remove it.

RECENT APPS

Touch  to open thumbnail images of apps you have worked with recently. Touch a thumbnail to open. Touch  to close.



Recent Apps thumbnails

Close Recent Apps

APPS MENU

1. From the Home screen, touch **Apps** (☐☐☐☐) in the right corner of the display, to view your apps screen.
2. Touch **My apps** to view application downloads from Android Market.
3. Touch **Shop** to purchase or download free applications from Android Market.



CONNECTIONS

BLUETOOTH®

Bluetooth is a short-range wireless communications technology for exchanging information over a distance of about 30 feet. You don't need to line up the devices to send information with Bluetooth. If the devices are in range, you can exchange information between them, even if they are in different rooms.

Turning Bluetooth On or Off

From the Home screen, touch **Apps** () → **Settings** () → **Wireless & networks** → **Bluetooth** (touch Bluetooth to turn Bluetooth On or Off)

Pairing your device to a Bluetooth headset

To connect with a new device, you need to pair with it. You only need to do this once for each device—to connect again, just turn on the device.

1. Make sure the device you are pairing with is in discoverable mode.

Note: Refer to the guide that came with the device for details.

2. Touch **Apps** () → **Settings** () → **Wireless & networks** → **Bluetooth settings**.

3. Touch **Bluetooth** to turn on Bluetooth, if necessary.

4. Touch **Find nearby devices**.

5. Touch a device to connect.

6. If necessary, touch **Pair**, or enter the device passkey (0000) to connect to the device. When the device is connected, the Bluetooth indicator appears in the status panel.

NOTE: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

Supported Bluetooth Profiles

- **SPP:** Serial Port Profile (AT Commands)
- **A2DP:** Advanced Audio Distribution Profile
- **AVRCP:** Audio/Visual Remote Control Profile
- **OBEX:** Object Exchange Profiles (not all OBEX profiles supported)
- **OPP:** Object Push Profile (must support optional settings in profile)
- **GAVDP:** Generic Audio/Video Distribution Profile
- **AVDTP:** Audio/Visual Distribution Profile
- **AVCTP:** Audio/Visual Control Transport Protocol Profile
- **HID:** Human Interface Device

WI-FI

Wi-Fi (short for “wireless fidelity”) is a term used for certain types of Wireless Local Area Networks (WLAN). Wi-Fi communication requires access to an existing and accessible Wireless Access Point (WAP). These WAPs can either be Open (unsecured) as within most Hot Spots, or Secured (requiring knowledge of the Router name and password).

Turning Wi-Fi On or Off

By default, your device’s Wi-Fi feature is turned off (deactivated). Activating Wi-Fi allows your device to discover and connect to compatible in-range WAPs (Wireless Access Points).

- From the Home screen, touch **Apps** () → **Settings** () → **Wireless & networks** → **Wi-Fi** (touch Wi-Fi to turn Wi-Fi On or Off). Your table will automatically scan for available Wi-Fi networks.

Connecting to a Wi-Fi Network

1. From the Home screen, touch **Apps** () → **Settings** () → **Wireless & networks** → **Wi-Fi** (touch Wi-Fi to turn Wi-Fi On or Off). Your table will automatically scan for available Wi-Fi networks.
2. The network names and security settings (Open network or Secured with Wired Equivalent Privacy (WEP) of detected. Wi-Fi networks display in the Wi-Fi networks section.
3. Touch the network you wish to connect to.
NOTE: When you select an open network you are automatically connected.
4. Enter a wireless password (if necessary) and touch **Connect**.

CAMERA AND HIGH-DEFINITION VIDEO

TAKING PICTURES

1. From the Home screen, touch **Apps** () → **Camera** () to launch the camera.
2. Aim the camera lens at the desired object and touch  to capture the image.

RECORDING A VIDEO

1. From the Home screen, touch **Apps** () → **Camera** () → move the slider to **Camcorder** ().
2. Aim the camcorder lens at the desired object and touch  to record video. Touch  to stop and automatically save recording.

VIEWING A PICTURE OR VIDEO

1. From the Home screen, touch **Gallery** () and touch an **Album** to display items.
2. Touch the item you would like to view or play.

FRONT FACING CAMERA AND CAMCORDER

- In camera mode, touch  to switch to the front facing camera for video chat or self portraits.
- In camcorder mode, touch  to switch to the front facing camcorder to record a video of yourself.

APPS AND FEATURES

Make your device do more with music, ringtones, wallpapers, apps and games. Check the latest scores, keep up with Twitter™ and Facebook, even plan a vacation, we've got apps that help you do it all. For details and pricing, go to **verizonwireless.com**.

Data charges may apply.

DRAFT

USING ANDROID MARKET

Android Market™ provides direct access to useful applications and fun games which you can download and install.

NOTE: You need to be signed in to your Google Account to use Android Market.

DOWNLOADING APPS FROM ANDROID MARKET

1. From the Home screen, touch **Apps** () → **Market** ().
2. Browse through the categories, find an application you're interested in, and touch the name.
3. Read the application descriptions.
4. For free applications touch **Install**. To buy an application, touch **Buy** and follow the onscreen instructions to pay for the application.
5. Check the progress of the current download by opening the Notifications panel.

MEDIA HUB

Samsung Media Hub is your one stop for the hottest movie and TV content. With hundreds of titles available at your fingertips, entertaining on the go has never been easier. You can rent or purchase your favorite content and watch from the convenience of anywhere. Featuring the stunning viewing quality Samsung is known for, Samsung Media Hub is your gateway to mobile video like you've never experienced it before.

Browse the latest movies and TV shows, then rent or purchase the media for viewing on your phone.

NOTE: Purchased content can be shared by up to 5 Media Hub supporting devices. Movies are available the day after DVD release and TV shows the day after premiering.

NOTE: Media Hub service requires a Media Hub account, and depends on service availability. Media Hub content can only be downloaded with a WiFi or a 4G connection.

SURFING THE WEB

Take the Internet with you wherever you go. You can read the latest news, get the weather and follow your stocks.

LAUNCHING THE BROWSER

1. From the Home screen, touch **Browser**



NOTE: You should be signed in to your Google Account to sign into Google sites.

ENTERING A URL

1. From the Home screen, touch **Browser**
().
2. Touch the **URL** field at the top of the screen, then enter the URL using the virtual QWERTY keyboard.
3. As you enter characters, potential matches display. Continue entering characters, or touch a match to complete the URL, then touch **Go** to load the page.

ACCESSING THE BROWSER MENU

1. From the Home screen, touch **Browser** ().
2. While viewing a Web page, touch **Menu** () to access its available options.

VIDEO CHAT

Use Google Talk to chat with other Google Talk users.

LAUNCHING GOOGLE TALK

1. From the Home screen, touch **Talk** ().

NOTE: Talk requires that you have a Google account set prior to using this service.

2. Enter your account information and touch **Sign in**. The screen then displays your current information, user information, and acceptance status for both video and voice chats. The left of the screen indicates the status of your current friends.

INITIATING A VIDEO CHAT

1. From the Home screen, touch **Talk** ().

NOTE: Talk requires that you have a Google account set prior to using this service.

2. Touch the entry for your target friend.
3. To initiate the video chat session touch **Video Chat** (.
4. The recipient must then touch **Accept** on their device to complete the connection. The screen then displays two screens, the larger one being your recipient and the smaller one being a preview of your camera image.

INITIATING A VOICE CHAT

1. From the Home screen, touch **Talk** ().

2. Touch the entry for your target friend.
3. To initiate the voice chat session touch **Voice Chat** (.

E-READING

Use the Books app to read eBooks from the web-based Google Books service. Google eBooks is a new way to discover, buy, and enjoy your favorite books online and offline. You can read books online or mark them for availability offline, so you can read them when you have no Internet connection (such as on an airplane). You can also use Books as your starting point for browsing or searching for books on line.

1. From a Home screen, touch **Apps** () → **Books** ().
2. Touch the cover of a book to start reading. Once the book displays, sweep across the screen to turn the page or touch  for a table of contents. Touch  to set Show, Brightness, Text settings, and Line height.
3. Touch **Menu** () for these options:
 - **Make available offline:** Mark books to make them available offline. Touch below a book cover to mark it with a  pin and then touch **Done**. Just reverse this process to remove books from your device.

- **Accounts:** Set the account to use.
 - **Refresh:** If a book in your library does not appear on your device, use this option to update the display.
 - **Help:** Displays various Book help information. Touch **Help Center** to get additional Google Book information.
4. To add more books to your library, touch **Shop** in the Application bar.
- A pop-up displays the Android Market Terms of Service and the Google Books Terms of Service. Read each document and touch **Accept**.
- Browse the selection of Google eBooks, which are arranged in categories like Trending, Top Rated, Best Selling, and many more.
5. To find a book by title or author name, touch **Search** (🔍) on the Books main screen or touch **Shop** → **Search** (🔍).

DATA

Tap into a powerful stream of data—it's all in the palm of your hand.

EMAIL

Check email on the go with your internet-based Gmail® account, corporate or personal POP email.

VERIZON SAFEGUARDS

Your family; your call. Verizon safeguards give you peace of mind with Family Locator, Content Filters, Spam Controls, Usage Controls and more. Go to verizonwireless.com/familylocator, verizonwireless.com/spamcontrols, or verizonwireless.com/usagecontrols.

GETTING STARTED WITH LOCATION-BASED SERVICES (LBS)

To use Location-Based Services, you must first enable location services on your device:

- To set your location, touch **Apps** () → **Settings** () → **Location & security** → **Use GPS satellites and/or Use wireless networks**.

Your wireless device can determine its (and your) physical, geographical location ("Location Information") and can associate Location Information with other data. Additionally, certain applications, services and programs are capable of accessing, collecting, storing and using Location Information and disclosing Location Information to others. You should use caution when determining whether or not Location Information should be made available to others and you should review any applicable third party privacy policies before providing access. To limit potential unauthorized access to your Location Information, Verizon Wireless phones are preset to E911 only, which will only allow emergency response personnel to locate you if you dial **911** from your phone.

Other wireless devices (such as Broadband Data Cards or devices without a keypad or user interface) may or may not have such limitation and location settings available. By enabling location settings you are permitting third party access to Location Information through software, widgets or peripheral components you choose to download, add or attach to your wireless device or through web access, messaging capabilities or other means and you are authorizing Verizon Wireless to collect, use and disclose your Location Information as appropriate to provide you with any location services that you enabled.

TOTAL EQUIPMENT COVERAGE

Sign up for Total Equipment Coverage and if your device breaks, gets lost or stolen, or malfunctions after the manufacturer's warranty expires, you're covered.

Total Equipment Coverage combines Verizon Wireless Extended Warranty and Asurion's Wireless Phone Protection. For details, go to **verizonwireless.com/equipmentprotection**.

POWERING UP VERIZON 4G

Surf with a blazing fast wireless data connection when Verizon brings the new Verizon 4G Network to select U.S. markets, covering over 100 million people.

Visit **verizonwireless.com/4G** to sign up for the latest news on launch dates, devices and cities.

GO GLOBAL

Verizon Wireless keeps you connected around the corner and around the world. For up-to-date information on destinations and rates, go to **verizonwireless.com/vzglobal** and select from the following programs:

INTERNATIONAL ROAMING

Traveling outside of the U.S.? With any Verizon device you can stay connected in over 35 destinations including Canada, Mexico, China, Israel, Brazil and Jamaica. Dial ***611** from your device or call **1-800-922-0204** and speak with a Verizon Wireless representative to enable International Roaming. A full list of destinations and rates can be found at **verizonwireless.com/internationalroam**.

GLOBAL TRAVEL PROGRAM

Available in more than 220 voice countries, more than 200 data countries and more than 115 countries with 3G, this is the perfect short-term solution for the occasional or infrequent global traveler who needs to stay in touch when traveling outside of the U.S. to GSM locations. This program is ideal when your travel duration is less than 21 days. There is no rental fee or security deposit, and all charges will be applied to your current Verizon Wireless bill. For more information on the Global Travel Program, visit **verizonwireless.com/globaltravel**. To place an order, contact our Global Services Activation Specialists at **1-800-711-8300**.

Available for Verizon Wireless Postpay customers who own a CDMA phone or smartphone.

TOP 10 TIPS

- **Cinematic HD movie playback:** With Media Hub watch HD movies in HD, on your tablet's huge 10.1" widescreen display.
- **Games:** Gaming reaches a whole new level—rich graphics on an HD display, an accelerometer, and a gyroscope. Your tablet delivers it all at lightning-fast speeds with its powerful dual core processor, 1GB RAM and 4GLTE Verizon network.
- **eBooks:** Download your favorite books, magazines, and newspapers, and read them on the eReader.
- **Android Market™:** Android Market is your one-stop shop for books, apps, and games.
- **Desktop-like tabbed browsing:** Open multiple tabs in a single browser window, and switch between them in a flash.
- **Google Talk™:** Google Talk now has voice and video chat capabilities, allowing you to chat “face-to-face” with any Google Talk enabled device over Wi-Fi or 4G.

Health and safety information

Exposure to Radio Frequency (RF) Signals

Certification Information (SAR)

Your wireless device is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. government. These FCC exposure limits are derived from the recommendations of two expert organizations, the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy. The exposure limit set by the FCC for wireless mobile device employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless device to comply with a safety limit of 1.6 watts per kilogram (1.6 W/ kg). The FCC exposure limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each model device are performed in positions and locations as required by the FCC.

For typical operation, this model has been tested and meets the FCC RF exposure guidelines.

Non-compliance with the above restrictions may result in violation of FCC RF exposure guidelines.

SAR information on this and other model devices can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device FCC ID number for

[search, A3LSCHI815](#). Once you have the FCC ID number for a particular device, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular device. Additional product specific SAR information can also be obtained at www.fcc.gov/cgb/sar.

FCC Notice and Cautions

FCC Notice



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the device if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.

Cautions

Changes or modifications made in the radio device, not expressly approved by Samsung, will void the user's authority to operate the equipment.

The use of any unauthorized accessories may be dangerous and void the device warranty if said accessories cause damage or a defect to the device. Although your device is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

This device is capable of operating in 802.11a mode. For 802.11a devices operating in the frequency range of 5.15 - 5.25 GHz, they are restricted for indoor operations to reduce any potential harmful interference for Mobile Satellite Services (MSS) in the US. WIFI Access Points that are capable of allowing your device to operate in 802.11a mode (5.15 - 5.25 GHz band) are optimized for indoor use only. If your WIFI network is capable of operating in this mode, please restrict your WIFI use indoors to not violate federal regulations to protect Mobile Satellite Services.