

1. At the S Translator screen, tap the left voice button to verbally speak the selected language (corresponds to top field).
2. Wait a few seconds until the on-screen notification shows "Speak in..." then speak using the selected language.
3. Within a few seconds, confirm the translated text now appears in the other translation field.
4. Tap the selected  (**Speak**) button to translate using your selected input language and voice.
 - Example, if trying to speak in English and get a Spanish translation, tap the **Speak (English (US))** button and wait for the text to appear on-screen.
5. Press  for additional options. Choose from: TTS readout speed, Auto readout, and Help.

S Voice

Launches your phone's built-in voice recognition system that allows you to initiate several common tasks without having to touch the device.

This is a voice recognition application used to activate a wide variety of functions on your device. This is a natural language recognition application.

This goes beyond the Google Search Voice Actions feature that simply recognizes Google commands and search terms. You can ask it questions (Is it raining in Dallas?) or give it commands (Show me where to find cheap gas).

- From the Home screen, tap  (Apps) →  (Samsung) →  (S Voice).

Using S Voice

1. From the Home screen, tap  (Apps) →  (Samsung) →  (S Voice).
2. Read the on-screen disclaimer information and tap **Confirm** to continue.
3. Review the Terms of Service and tap **Agree** to continue.

DRAFT
Internal Use Only

4. Navigate through the following on-screen tutorial screens by reading the information and tapping **Next**, or tap **Skip** to continue without reading the information.
5. Wake up the application by repeating the phrase **Hi Galaxy**.

Note: The wake-up command/phrase can be changed from “Hi Galaxy” to anything else.

6. Tap  (**Speak**) if the device does not hear you or to give it a command.

Example 1:

- I want to find the best pizza online.
- Tap  and say “Find me the best Pizza”. This launches an Internet search.

Example 2:

- I want to go to Cambridge.
- Tap  and say “Navigate to Cambridge”. This launches the Map application and indicates where this is in relation to your current position.

Samsung Apps

Allows you to easily download an abundance of applications that are directly compatible with your device. This includes games, news, reference, social networking, navigation, and more. Samsung Apps makes your Smartphone smarter.

Note: Access to this feature requires that you already be logged in to your Samsung account application. For more information, refer to “*Creating a Samsung Account*” on page 303.

1. Confirm you are currently signed into your Samsung account.
2. From the Home screen, tap  (**Apps**) →  (**Samsung Apps**).
3. If prompted, read the Disclaimer, Terms and conditions, and Privacy policy and tap **Accept**.
4. Follow the on-screen instructions.

DRAFT
Internal Use Only

Samsung Hub

Samsung Hub makes it easy to find, sample, and purchase movies, TV shows, books, games, and music, in one user-friendly location. With hundreds of titles available, entertaining your family on-the-go has never been easier. You can rent or purchase your favorite content and watch from any location. Samsung Hub is your gateway to mobile entertainment.

You must have an active Samsung Account to purchase and rent content via Samsung Hub.

Note: Samsung Hub usage is based on service availability.

Important! You must be using an active Wi-Fi/4G/LTE connection to preview and download a media file. The internal memory acts as a storage location for your downloaded rental or purchase.

Important! The Samsung account manages the access information (username/password) to several applications, such as Samsung Link, Chat On, and Samsung Hub.

Creating a New Samsung Hub Account

Before you can rent or buy media, you must first create an account. Enter the required information.

1. Confirm you have already logged in to your Samsung account.
2. From the Home screen, tap  (Apps) →  (Samsung Hub).
3. When prompted to connect via mobile networks, select either **Cancel** or **Connect**.
4. If notified your Samsung account is not yet active or verified, tap **OK**. You must be signed in to your Samsung account to use the application's various features.

Tip: In some cases it might be necessary to sign in to your Samsung account via the application. Press  and then select **Sign in**.

Note: Your Samsung Hub account is managed by the Samsung account application. This application manages your user profile information.

Using Samsung Hub

The main Samsung Hub screen provides an overview of all the available categories on one page such as: Music, Video, Books, and Games. The overview page also displays recently added media that you can rent or purchase.

1. From the Home screen, tap  (Apps) →



(Samsung Hub).

- The **OVERVIEW** screen (landing page) displays an main access for all available categories and recently available content for purchase or rental.
2. Scroll across the screen to select from the following available pages:
 - **MUSIC**: displays featured Music content available for purchase/stream from the Music store & Radio. This page also allows you to search for new content, or navigate directly to the Music store page by clicking on the "Music" link at the top of the page.
 - **VIDEO**: displays featured film and TV content available for purchase/rent from the video store. This page also allows you to search for new content, or navigate directly to the Movie & TV store page by clicking the "Video" link at the top of the page.

- **BOOKS**: displays featured Book content available for purchase from the Book store. This page also allows you to search for new content, or navigate directly to the Book store page by clicking the "Books" link at the top of the page.
 - **GAMES**: displays featured Game content available from the Game store. This page also allows you to search for new content, or navigate directly to the Game store page by clicking the "Games" link at the top of the page.
3. To purchase or view featured content in more detail, tap on any content (Thumbnail or text) to navigate to the product detail page.
 4. Depending on the content, you can either purchase, rent, or stream the content directly from the product detail page.
 5. Choose a payment method, then follow the on-screen instructions.

Samsung Hub Notices

- Any media item (Media Content) may be rented or purchased after you create an account in Samsung Hub.
- Media Content that is purchased and downloaded may be viewed concurrently on up to five (5) devices with Samsung Hub (or “the service”) that are also registered to the same account.
- You may remove a device from your account no more than once every 90 days.
- You may remove Media Content from a device as many times as you’d like. You will have the ability to re-download the Media Content later subject to content re-download availability and content provider permissions.
- You may need network coverage to access Media Content you have acquired through the Service.
- You can use 3G, 4G, or Wi-Fi connectivity to download Media Content.
- Unlike purchased Media Content, rented Media Content will be viewable on only 1 device in your account at a time.
- Media Content is downloaded and saved to your authorized device's SD card. No SD Card included out of box.

- Your Media Content may pause/stop or not download in networks where there is a weak signal.
- You may begin watching downloaded Media Content as soon as a) license acquisition has occurred and b) sufficient amount of the Media Content has been buffered.
- You must finish watching Media Content within the time limit set out for each piece of content (which may be as short as 24 consecutive hours).
 - Stopping, pausing or restarting rented Media Content does not extend the available viewing time.
 - In no event will rented Media Content be available for a period of more than thirty (30) days (or shorter on a title-by-title basis) after the Media Content has been rented (e.g., if you begin viewing rented Media Content on the 29th day after the rental transaction, but do not finish viewing the entire title, that rented Media Content may not be available for the entire twenty-four (24) consecutive hour period if such period would extend the viewable time beyond the thirty (30) day rental window).
- Unless otherwise restricted by the Content Providers, you can download Media Content to your TV using HDMI connections; otherwise, you cannot play Media Content downloaded from your mobile device output.

Samsung Link

This application wirelessly synchronizes your Samsung mobile phone with your TV, streams content and even keeps tabs on who calls or sends text messages with real-time, on-screen monitoring. Samsung's Samsung Link makes staying connected easy.

Allows users to share their in-device media content with other external devices using DLNA certified™ (Digital Living Network Alliance) Devices. These external devices must also be DLNA-compliant. Wi-Fi capability can be provided to TVs via a digital multimedia streamer.

AllShare/Samsung Link Definitions:

Samsung Link/ AllShare Play

This new feature builds on the previous AllShare Play functionality. It includes features such as Web storage integration and social networking integration. This is a Web service that requires using a Samsung account.

Group Play

A subset feature of Samsung Link, this allows you to mirror photos and multimedia presentations with other members of your current Wi-Fi group. Users must be on the same Wi-Fi and provide an access code to join the group.

AllShare Cast (with Hub accessory)

This feature functions with an external AllShareCast Hub to fully mirror what is currently displayed on your device to the external TV.

Important! You must first connect both of your communicating devices to the same Wi-Fi and be using an active/registered Samsung account prior to using this application.

For more information, refer to “*Wi-Fi settings*” on page 237.

For more information, refer to “*Creating a Samsung Account*” on page 303.

DRAFT
Internal Use Only

Important! The Samsung account manages the access information (username/password) to several applications, such as Samsung Link.

1. Confirm you have already logged in to your Samsung account.
2. From the Home screen, tap  (Apps) →  (Samsung) →  (Samsung Link).
3. If prompted with an on-screen notification about no Wi-Fi detected, tap **Cancel** (to continue by using your network connection) or **Connect** to continue.
4. Tap **Sign in**.
5. If prompted to log into your Samsung account, tap **Sign in** and follow the on-screen instructions.

Note: If the main screen still shows a Sign in box, close the application and restart it.

6. Follow the on-screen prompts.

7. Tap  to reveal the DEVICES & STORAGE list, scroll down the screen. The DEVICES & STORAGE list contains two separate streaming media options:
 - **Registered devices** allows you to stream/share selected multimedia content from your device to DLNA compliant device connected to the same Wireless Access Point.
 - **Registered storage:** allows you to receive and playback media stored externally (server, laptop, etc.) directly on your device by allowing you to add a Web storage service for streaming content.

Configuring Samsung Link Settings

The Samsung Link™ application must first be configured prior to its initial use. You must setup parameters such as connected Wi-Fi, Items to share, source server address, and external device acceptance rights.

1. From the Home screen, tap  (Apps) →  (Samsung) →  (Samsung Link).
2. Press  and then tap **Settings** and configure the following settings as desired:
 - **Registered storage:** allows you to add a Web storage location. Without a storage service/location added, you will not be able to use Samsung Link.

- **Save to:** allows you to save your media to your internal phone memory or to an SD card.
- **Auto upload:** allows you to enable automatic upload of images from your device to those storage locations specified within the Web storage list. Move the slider to the on position to activate the feature.
- **Video optimization:** allows you to setup the video quality for streamed video content. Move the slider to the on position to activate the feature.
- **Password lock:** allows you to restrict access to Samsung Link by requiring a user enter the currently active and associated Samsung account password. Move the slider to the on position to activate the feature.
- **My account:** displays Samsung account information.
- **Customer support:** allows you to contact the Samsung Link team via a new email from an available email account.
- **About this service:** displays application information.

Setting Up Web Storage

Web storage services allow you to use storage space to store your files and share them on the “Cloud”.

Note: If you are using another Web storage service, log into that service first before using Samsung Link.

1. From the Home screen, tap  (Apps) →  (Samsung) →  (Samsung Link).
2. Tap   → Add storage.

Note: When adding storage, an N Drive is added.

3. Choose from: SugarSync, Dropbox, or SkyDrive.
– or –
Press  and then tap **Settings → Registered storage → Add storage.**
4. Follow the on-screen instructions to register or log into your cloud service.
5. Once the process is successfully completed, the Web storage icon or name appears in the Web storage area of the main screen.

6. From the main screen, select a connected device and then tap on the media that you would like to share.
- A file with  in the upper-left indicates it is stored remotely on a Web storage location. Selecting this media causes your device to access the file currently stored on your services' servers.

To de-register Web storage service:

1. From the Samsung Link application, press  and then tap **Settings** → **Registered storage**.
2. Select **Delete** → **Delete**.
3. Select a current storage service and tap **OK**.

Sharing Media via Samsung Link to a Target Device

Important! Make sure all communicating devices are connected to the same Wi-Fi.

1. Launch AllShare Play/Samsung Link on the target device (such as an Internet TV, Samsung Tablet, etc..).
2. From the Home screen, tap  (**Apps**) →  (**Samsung**) →  (**Samsung Link**).

Note: You must be signed in to your Samsung Account before you can use this feature.

3. Tap  and select your device name from the **Registered devices** area.
4. Tap an available category tab (Pictures, Music, Movies, Files, or Info) and select a file.
 - A file with  in the upper-left indicates it is stored remotely on a Web storage location. Selecting this media causes your device to access the file currently stored on your services' servers.

DRAFT
Internal Use Only

5. Tap an available on-screen file, image, or video to place a green check mark alongside it.
6. Tap  (**Stream to connected devices**) and select an available target device to begin streaming.
7. On a target device (ex: Internet TV) select the on-screen **Allow** button to continue.

Note: At this stage your device is requesting access to share media with the external source.

8. Confirm  (**Samsung Link Controller enabled**) appears in the Notification area at the top of the device to indicate you are using your device as the media source.

Scrapbook

This application allows you to combine documents, images, and music into a digital scrapbook.

1. From the Home screen, tap  (**Apps**) →  (**Scrapbook**).
2. Tap **Start** and follow the on-screen tutorials.

Settings

This icon navigates to the sound and phone settings for your phone. It includes such settings as: display, security, memory, and any extra settings associated with your phone.

- From the Home screen, tap  (**Apps**) →  (**Settings**).

— or —

From the Home screen press  and then tap **Settings**.

For more information, refer to “*Changing Your Settings*” on page 235.

SketchBook for Galaxy

This application allows you to explore your imagination through sketches using Autodesk SketchBook application and S Pen.

1. From the Home screen, tap  (**Apps**) →  (**Galaxy Plus**) →  (**SketchBook for Galaxy**).
2. Follow the on-screen tutorials.

DRAFT
Internal Use Only

Spotify

This application gives you instant access to millions of songs on your device. Try the service for free, or on a paid basis.

1. From the Home screen, tap  (Apps) →  (Galaxy Plus) →  (Spotify).
2. Tap either **Try for free** or **Log in here**.
3. Follow the on-screen instructions.

Story Album

With Story Album, you can create a digital Album of your story in media. Special moments will be on a timeline, and if you wish, you can have your album published as a hard copy.

1. From the Home screen, tap  (Apps) →  (Samsung) →  (Story Album).
2. Read the introductory information and tap **Next**.
3. Tap **Start** to begin your Story Album.
4. Follow the on-screen instructions.
5. Press  and then tap **Help** for additional information.

T-Mobile My Account

This application provides you online access to account information such as your current activity, billing information, service plans, downloads, and other information.

Note: Wi-Fi connection must be disabled prior to use, this application requires use of a T-Mobile network connection.

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (T-Mobile My Account).
2. If prompted, follow the on-screen information for what's new in the app.

Note: Some features may require you to log into your account.

3. The application screen provides several available options:
 - **Account Info** provides access to account-specific features such as: Notifications.
 - **Device Support** provides details about your current billing summary.

- **Notifications** provides about both your current plan, other available plans and other related services.
- **MobileLife FamilyWhere** provides links to other T-Mobile related information.

T-Mobile Name ID

Allows you to modify the on-screen Caller ID information. Name ID identifies unknown callers by Name, City, and State.

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (T-Mobile Name ID).
2. Choose an on-screen option.

T-Mobile TV

T-Mobile TV is an application that allows you to get live TV and Video on Demand.

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (T-Mobile TV). The T-Mobile Terms and Conditions page displays.

Note: A data plan is required to use this feature. Charges may apply. Please contact your service provider for further details.

2. Tap **Accept** if you accept the Terms and Conditions.
– or –
Tap **Exit** to close the application.

Note: T-Mobile TV must be initialized over a cellular network before it can be used. During this initial registration process, any Wi-Fi connections must be disabled.

3. Tap **Disable Wi-Fi** if you currently have an active Wi-Fi connection.

DRAFT
Internal Use Only

4. Tap **Start Trial** to begin a free 30-day trial of the service.
– or –
Tap **OK** to keep viewing the free content or **Purchase Options** to buy the paid features.
5. Tap any of the following categories to begin viewing: **Home, Live TV, TV Shows, Favorites, Help, Search, Browse, More Info, or Live Channels.**

TripAdvisor

With the TripAdvisor, you can plan and have your perfect trip. With over 75 million reviews and opinions by travelers, it is easy to find the best hotels, restaurants, and fun things to do.

1. From the Home screen, tap  (**Apps**) →  (**Galaxy Plus**) →  (**TripAdvisor**).
2. Sign in with your Samsung Account if you have not already done so.
3. Follow the on-screen instructions to use TripAdvisor.
4. Press  for additional options.

Video

The Video player application plays video files stored locally.

Using Video

The Video application plays video files stored on the SD card. This device is able to playback DivX videos.

1. From the Home screen, tap  (**Apps**) →  (**Video**). A list of available videos displays in the Video list.
2. Tap a video file to begin viewing.

Sharing Videos

1. From the Home screen, tap  (**Apps**) →  (**Video**). After a few seconds, each on-screen video begins to cycle through a preview of the first five seconds of the clip.
2. Press  and then tap **Share via**.
3. Select either individual videos or tap **Select all**.
4. Press  and then tap **Done** to complete the process or **Cancel** to quit.

DRAFT
Internal Use Only

5. Select a sharing option. Choose from: Add to Dropbox, Bluetooth, ChatON, Email, Evernote - Create Note, Gmail, Google+, Messages, Picassa, S Note, Scrapbook, Wi-Fi Direct, or YouTube.

Additional Video Features

1. From the Home screen, tap  (Apps) →  (Video).
2. Press  and then tap an available option:
 - **Sort by:** allows you to sort current videos by Title, Date, Size, or Type.
 - **View as:** allows you to display the on-screen video images as either a List, Thumbnail, or Folders.
 - **Share via:** allows you to share a selected video with external sources.
 - **Delete:** allows you to delete selected videos.
 - **Edit:** allows you to edit a selected video file.
 - **Auto play next:** slows you to play videos consecutively. Once a video ends, the next available video begins to play.
 - **Information:** provides on-screen information about the application.

- **Settings:** allows you to configure application functions such as: Default storage, Auto update apps, and About services.
- **Help:** displays an on-screen set of application-related Help topics.

Using Picture-In-Picture

This feature can be used during playback of supported video types via either the Gallery, Play Videos, or Video player.

Note: Some applications might not allow this video to remain active in the foreground (ex: Camera/Camcorder screen).

This feature allows you to continue to view your video as a background operation while you multi-task and do other things, such as surf the Internet, access your Contacts list, look for a picture, etc..

1. From the Home screen, tap  (Apps).
2. Tap the desired video playback application.
3. Tap the desired video to begin playback.

DRAFT
Internal Use Only

Note: The Picture-In-Picture feature only works when using the Video player application. Other video players (ex: YouTube), do not support this feature.

4. As playback is initiated, locate and tap  (**Picture-in-Picture**) from the bottom-right of the playback screen. Your current video is then sent to foreground of any new page and most application screens.
5. The video disappears from the screen once it ends.

DivX Overview

This device is able to playback DivX videos. DivX Certified® to play DivX® video up to HD 720p, including premium content. If you try to play DivX VOD content not authorized for your device, the message “Authorization Error” will be displayed and your content will not play. Learn more at www.divx.com/vod.

Your device must first be registered to playback protected or purchased DivX content. DRM-free or unprotected content does not required DivX VOD registration.

Locating Your VOD Registration Number

1. From the main **Settings** page, tap **More** tab → **About device** → **Legal information** → **License settings** → **DivX® VOD** → **Register**.
2. Write down your Registration code.
3. Tap **OK**.

Register Your DivX Device for VOD Playback of Purchased Movies

To play purchased DivX movies on your device, you will first need to complete a one-time registration using both your device and your computer.

1. Write down the DivX registration code that appears on-screen. Copy this 8 or 10-digit number down.
2. Verify you have the latest DivX software running on your computer. Download the free player (for your computer) from www.divx.com.
3. Open the DivX Player on your computer and from within the **VOD** menu, select **Register a DivX Certified Device..**

DRAFT
Internal Use Only

4. You are prompted to log in or create a DivX account if your account information has not already been saved in DivX Player.
5. Follow the instructions in DivX Player to enter the registration code from step 2 and create a device nickname (ex: "Pat or Pat's Device").
6. Select a location on your computer to download the DivX registration video with the same title as your device nickname (ex: Pat.divx).
7. Follow the on-screen instructions to download the file and initiate the transfer process. You will need to place this video file onto your device and play it back.
8. Connect your device to the computer via USB and transfer this video.
9. From the **Registration** screen (Transfer), click Transfer Video now and select the location of the microSD card or **USB** (the device) as the target destination for the registration video (created in step 6) and click **Start**.
– or –
Locate the created file, copy and paste it into the new drive letter corresponding to your device's storage location.
10. From the Home screen, tap  (**Apps**) →  (**Samsung**) →  (**My Files**).
11. Locate your registration DivX video file and tap the file to play it. Once you play the registration file on your device, your registration is complete.
12. Return to the DivX VOD Manager screen (from within your computer's DivX Player) and confirm both your computer and your new device appears in the list of registered DivX devices.

DRAFT

Internal Use Only

Important! There is no special registration or configuration necessary to playback DRM-free DivX movies. Registration of your device is only required for playback of protected DivX material.

Visual Voicemail

Visual Voicemail enables users to view a list of people who left a voicemail message, and listen to the any message they want without being limited to chronological order.

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Visual Voicemail).
2. Read the on-screen information and tap **Next**. If this is your first time using the service, you may be prompted to enter a PIN code.

Note: You must subscribe to the Visual Voicemail service to use this feature. Charges may apply. Please contact your service provider for further details.

3. Tap an on-screen voicemail message to play it back.

To check Visual Voicemail messages:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Visual Voicemail).
2. Tap the voicemail message you want to play.
3. Tap  (Play).

To delete Visual Voicemail messages:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Visual Voicemail).
2. Tap the voicemail message you want to delete.
3. Tap  (Delete) → OK.

DRAFT
Internal Use Only

Voice Recorder

The Voice Recorder allows you to record an audio file up to one minute long and then immediately send it as a message.

1. From the Home screen, tap  (**Apps**) →  (**Samsung**) →  (**Voice Recorder**).
2. Tap  (**Record**) to record an audio file.
3. Tap  (**Stop**) to stop recording. The file automatically saves to the Voice list.
4. Tap  (**Pause**) to pause the recording of an audio file.
5. Tap  (**Cancel**) to cancel the recording of an audio file.
6. Tap  (**Bookmark**) to bookmark the current recording.
7. Tap  (**List**) to display a list of current recordings.
8. Tap  (**Recording quality**) to adjust the recording quality. Choose from: Normal or High quality recording.

9. From the Recorded files page, press  and then select one of the following:
 - **Share via** and select a method in which to share this audio file. Selections are: Add to Dropbox, Bluetooth, ChatON, Email, Evernote - Create Note, Gmail, Messages, or Wi-Fi Direct. Refer to each specific section, depending on the method you selected to send this voice recording.
 - **Delete**: allows you to delete 1 or more voice recordings. Tap the recordings to delete and tap **Delete**.
 - **Change category**: allows you to assign the currently selected recording to a user-created category entry.
 - **Sort by**: allows you to sort the current list by either: Date (most recent), Date (oldest), Name, or Category.
 - **Search**: allows you to search for key terms within the existing list.
 - **Manage categories**: allows you to existing user-created category entries.

DRAFT
Internal Use Only

- **Settings:** the following settings are available:
 - **Storage:** allows you to choose where your recordings will be saved. Select between Phone or memory card.
 - **Recording quality:** allows you to set the recording quality to High or Normal.
 - **Contextual filename:** (requires GPS tagging) allows you to adjust the filename based on contextual information such as your current GPS location.
 - **Default name:** allows you to choose the name prefix for your recordings. For example, if your Default name is Voice, your recordings would be named Voice 001, Voice 002, Voice 003, etc.
 - **Noise reduction:** allows you to activate/deactivate background noise suppression.
 - **Logo display:** allows you to display a custom logo on the recording screen.
 - **Language:** allows you to select an available language for use with the voice memos.
 - **Channel:** allows you to assign recording mode to either Mono or Stereo.
 - **Skip interval:** allows you to assign a skip length.

- **End:** allows you to exit the application.

Voice Search

Launches the Google Now application that is used for voice to text Internet searching.

1. From the Home screen, tap  (Apps) →  (Google) →  (Voice Search).
2. When prompted, speak into the built-in microphone.
3. Use the on-screen options to find a matching search term.

VPN Client

This is a full-featured VPN Client that provides support for the latest IPSec VPN standards and provides interoperability with support for all major VPN Gateways.

1. From the Home screen, tap  (Apps) →  (Samsung) →  (VPN Client).
2. Follow the on-screen instructions to configure the VPN Client.
 - Options include: Add VPN Connection or My VPN Connections.

WatchON

Important! Before initiating use, verify you have an active Internet connection available (either mobile network or Wi-Fi connection).

Note: Before beginning your initial WatchON application setup, confirm your TV is turned off.

Using WatchON

For more information, refer to www.samsungwatchon.com.

Initial Configuration

1. Sign into your Samsung account.
2. From the Home screen, tap  (Apps) →  (Samsung) →  (WatchON).

Note: If you are not connected to an active Wi-Fi, you may be prompted to continue the set up process via a mobile network. Click **Connect** to proceed.

3. Select your desired country or region for your TV Guide's source listing.

4. Enter your current zip code and tap **Done**. This zip code must correspond to the location of your desired TV and set top box.
5. From the **Find your TV service** screen, select a service provider from the available channel listing.
6. From the **Personalize** screen, you can either follow the on-screen prompts to personalize your desired content or tap **Skip** to continue without customizing your content.
7. Read the on-screen Peel Disclaimer agreement and tap **Agree** to complete the set up process.

Customizing Your Remote

1. From the top of the main screen, tap  (Remote Control) → **Set Up Now**.
2. From the **Select your TV brand** screen, tap your TV's manufacturer name.
 - If you have a brand of TV not listed or you are using a projector, select from one of the following two options. Choose from either **Show other brands** or **I have a home projector**.

3. Aim your device at the TV and tap  (**Power**) to confirm the set up process completed successfully and the correct TV IR codes were selected.

Note: The process of the initial TV activation can take up to 10 seconds. Please do not press the button again.

4. If the TV turned on, tap **Yes, this code works**.

– or –

If the TV did not turn on after tapping  (**Power**) and waiting 10 seconds, tap **No, test next code** or **Send this code again**.

5. From the **Select your channel source** screen, select the entry that corresponds to your current channel control method:

- **Set-top Box:** selected when changing channels is done via a receiver box. Channels are not changed via the TV remote but rather through the receiver/box.
- **My xxx TV:** selected when a signal is fed directly into the TV and no box is used. Channels are changed directly on the TV by using the TV remote and not a box's remote.

Note: Try matching your current channel selection method.

6. Select the Satellite Box Brand from the available list. For example, DirectTV®.
- If your brand does not appear in the list, tap **Show other brands** and follow the on-screen instructions.

Important! You must configure your set top box for IR communication with your device. If you do not select **More info** below and follow the on-screen instructions you may not be able to properly use the application.

7. When prompted to Enable IR, tap **More info** to learn how to configure your set top box to receive and respond to IR controls.
8. Only after completing the IR setup process and programming your box, press  (**Back**).

Note: This IR programming of your set top box is a one-time process and once successful should not need to be repeated.

9. If prompted to personalize your experience, follow the on-screen instructions.

Using WatchON

To change channels:

1. Sign into your Samsung account.
2. From the Home screen, tap  (Apps) →  (Samsung) →  (WatchON).
3. From the top of the main screen, tap  (Remote Control). This launches an on-screen remote control.
 - **Easy remote**: provides the most common used control features. Scroll down to view additional functions.
4. In a single motion touch and drag up from the bottom-right of the screen to access additional remote tabs Choose from one of the following:
 - **TV**: provides access to control functions specific to your TV.
 - **[Set top box]**: displays customized control specific to your configured set top box. Ex: satellite dish remote control functions.

5. From the remote screen press  and then tap  (**Change room**) to choose from different receivers/boxes in different rooms. Ex: Living Room box, Bedroom box, etc..
6. Press  (**Back**) to return to the main menu.

Locating your favorite programming:

1. Sign into your Samsung account.
2. From the main WatchON screen, tap  (**Combined View**) to reveal available media categories.
3. Select an available category.
– or –

Tap **Channel Guide** to display on your TV an on-screen listing of available set top box shows.

For additional information on the WatchON application, press  and then select **Help**.

DRAFT
Internal Use Only

WatchOn Settings

- From the main WatchON screen, press  and then select an available on-screen option:
 - **Change room:** allows you to select a previously configured room.
 - **Edit channels:** allows you to add or remove channels from your custom list. Press and hold a channel number to update the channel entry.
 - **Settings:** provides access to the Samsung WatchON settings menu.
 - **About:** displays on-screen information about the application.
 - **Help:** displays on-screen help information.

Personalize WatchON

You can personalize your application to do things such as show content only from your selected media categories, or add an additional room's set top box.

To configure your Just for you settings:

The Just for you option displays available content matching your activated media categories. These categories can be configured during your initial set up or at any later time.

1. Sign into your Samsung account.
2. From the main WatchON screen, tap  
(Combined View) → **Just for you**.
3. From the **On TV** tab, press  and then select **Settings**.
4. Access parameters such as **Basic info**, **Genres** and **Sports** to then configure and enable those parameters you would like to show in the Just for you tab.

DRAFT
Internal Use Only

To add a new room:

Your device can be used to control boxes/receivers from several rooms. You could go from controlling your set top box in your living room and then move into your bedroom to do the same.

1. Sign into your Samsung account.
2. From the main WatchON screen, tap the **On TV** tab
3. Press  and then select **Settings → Add room**.
4. Name the new room and tap **Next**.
5. Enter your current zip code and tap **Done**. This zip code must correspond to the location of your desired TV and set top box.

Follow the steps from page 224 to complete the process.

YouTube

YouTube is a video sharing website on which users can upload and share videos, and view them in MPEG-4 format.

1. From the Home screen, tap  (**Apps**) →  (**YouTube**).
2. Tap the search field  to search for specific videos, scroll down to browse through the main page thumbnails, or scroll to the bottom to explore additional options.
3. To view a video, tap an available preview thumbnail or tap the title link.

To configure YouTube Settings:

- Press  and then tap **Settings** and configure the following parameters:
 - **General**
 - **High quality on mobile**, when enabled, allows you to start all videos in high quality mode while you are connected to a mobile network.
 - **Caption font size** allows you to set the font size used by on-screen captions. Choose from: Small, Medium, Large, or Huge.

DRAFT
Internal Use Only

- **Uploads** specifies network preferences for uploads.
- **Content localization** allows you to prioritize channels and videos from a specific country or region.
- **Improve YouTube** allows you to anonymously send YouTube information to help improve the application.

• **Connected TVs**

- Allows you to pair your device to a wireless TV running a YouTube application. Options include Add a TV and Edit TVs.

• **Search**

- **Clear search history** allows you to clear previous YouTube searches from showing up in the YouTube search box.
- **Never remember history** allows you to force YouTube to never store search history information.
- **SafeSearch filtering** allows you to configure block settings for videos containing restricted content. This option blocks these videos from appearing within your search results. Choose from: Don't filter, Moderate, or Strict.

• **Preloading**

- **Preload subscriptions** allows you to preload (or go get videos while on Wi-Fi and charging) your subscription videos.

- **Preload watch later** allows you to enable the preload function on selected videos so you can watch them later. Read the data usage information and tap **OK** to accept the terms.

Note: Preloading YouTube videos will use some of your device's storage space and may result in additional charges if your Wi-Fi plan is not unlimited.

• **About**

- **Help** provides answers to most YouTube questions.
- **Feedback** allows you to provide user feedback to YouTube.
- **Google Mobile Terms of Service**
- **YouTube Terms of Service**
- **Google Mobile Privacy Policy**
- **YouTube Privacy Policy**
- **Open source licenses**
- **App version** displays the software version for the current YouTube application.

To watch a high quality video:

- Press  and then tap **Settings → General → High quality on mobile**.

Section 9: Connections

PC Connections

You can connect your device to a PC using an optional PC data cable using various USB connection modes.

Media device (MTP): allows you to transfer media files in Windows, or using an Android file transfer on a Mac.

Camera (PTP): allows you to transfer photos using the camera software, and transfer any files onto a PC that does not support MTP.

Kies: allows you to manage music, movies and photos. You can also backup precious contacts and calendars, download apps and podcasts and automatically upgrade device firmware. Kies conveniently syncs your life across all your devices.

Note: To sync your device to your computer it is highly recommended that you install Samsung Kies which is available at <http://www.samsung.com/kies> (for Windows/Mac).

Note: If you are a Windows XP user, ensure that you have Windows XP Service Pack 3 or higher installed on your computer. Also, ensure that you have Samsung Kies 2.0 or Windows Media Player 10 or higher installed on your computer.

Connecting as a Storage Device

You can connect your device to a PC as a removable disk and access the file directory. If you insert a memory card in the device, you can also access the files directory from the memory card by using the device as a memory card reader.

Note: The file directory of the memory card displays as a removable disk, separate from the internal memory.

1. Connect the USB cable to the device and connect the cable to the computer. After a few seconds, a pop-up window displays on the PC when connected.
2. Open the folder to view files.
3. Copy files from the PC to the memory card.

USB Tethering

This option allows you to share your device's mobile data connection via a direct USB connection between your device and a single computer. The Mobile HotSpot connectivity is a wireless version of this same functionality and allows you to provide Internet connectivity to multiple devices.

Note: You can not mount your device's microSD card to your computer while using the USB tethering feature. If additional software or USB drivers are required, navigate to: <http://www.samsung.com/us/support/downloads>.

To connect using USB Tethering:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
– or –

From the Home screen, press  and then tap **Settings** →  (Connections tab) → **Tethering and Mobile HotSpot**.

2. Plug in the USB cable between your computer and your device.

3. Tap **USB tethering** from the Tethering menu. This places a green check mark next to the entry and activates the feature. A Tethering or HotSpot active notification briefly appears on the screen.

Look for the Tethering active icon  in the Status bar area of the screen.

4. Read the on-screen notification regarding data use and tap **OK**.

To disconnect tethering:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
2. Tap **USB tethering** from the Tethering menu to remove the check mark and deactivate the feature.
3. Remove the USB cable from the device.

Mobile HotSpot

This feature allows you to turn your device into a Wi-Fi hotspot. The feature works best when used in conjunction with 4G/LTE data services (although 3G service can also be used).

The Mobile HotSpot connectivity is a wireless version of this same functionality and allows you to provide Internet connectivity to multiple devices.

Important! The Mobile HotSpot service cannot be active when device is connected to Wi-Fi. Please disconnect your Wi-Fi connection prior to active this service.

Note: You must have a tethering plan on your account in order to use the Mobile HotSpot. You cannot use data on the device while using Mobile HotSpot.

To activate the Mobile HotSpot service:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
– or –

From the Home screen, press  and then tap **Settings** →  (Connections tab) → **Tethering and Mobile HotSpot**.

2. In a single motion touch and slide the **Mobile HotSpot** slider to the right to turn it on.
3. Edit the **Network SSID** name and then write it down.
4. Enable the **Broadcast network name (SSID)** field if you would like to broadcast your SSID name to nearby devices.
5. Verify the **Security** field is set to **WPA2 PSK**.
6. Enter a new password then write it down.
– Additional options include Show password and Show advanced options.
7. Tap **Save** to store the new settings.
8. Confirm the Mobile HotSpot active icon  appears at the top of the screen.

DRAFT
Internal Use Only

Note: By default, the connection is not secured.

Note: Using your Mobile HotSpot drains your device's battery much faster. The best way to keep using the device as a HotSpot is by connecting to a Charger.

To connect to the HotSpot:

1. Enable Wi-Fi (wireless) functionality on your target device (laptop, media device, etc.).
2. Scan for Wi-Fi networks from the external device and select your device's Mobile HotSpot name from the network list.
 - The SSID name for your device's hotspot is determined by what you entered into the **Network SSID** field.
 - You can change the name by tapping **Configure** → **Network SSID** and changing the entry.
3. Select this HotSpot and follow your on-screen instructions to complete the connection.
4. Launch your Web browser to confirm you have an Internet connection.

To change the Portable HotSpot password:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
2. Tap **Mobile HotSpot** → **Configure**.
3. Tap the **Security** field and select **WPA2 PSK**.
4. With security enabled, delete the previous password and enter a new one into the **Password** field.

Important! The more complex the password, the harder it will be for intruders to break your security. It is recommended that you not use names, birthdays, or other personal information.

5. Tap **Save** to store the new settings.

To manage connected devices:

This feature allows you to provide MAC filtering on your device. This is similar to a “VIP list” where only device on the list are allowed access.

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
2. Tap **Mobile HotSpot** → **Allowed devices**.
3. Tap  (Add new device) to add devices to the allowed for connection list.
4. Enter the Device name and Mac address.
5. Tap **OK** to save the new device.

DRAFT
Internal Use Only

Section 10: Changing Your Settings

This section explains the device settings for your device. It includes such settings as: display, security, memory, and any extra settings associated with your device.

Accessing the Settings Tabs

- From the Home screen, tap  (Apps) →  (Settings).
— or —

Press  →  and then tap **Settings**.
The four available tabs are then displayed. The previous Settings list is now broken down into four available tabs described below.

Settings Tabs - Overview

The Settings are divided into 4 main groups. When the Settings screen displays, the following tabs are located at the top of the screen:



Connections:

This tab allows you to see all of settings related to the connection of your device to external sources. Features include: Wi-Fi, Bluetooth, Tethering and Mobile HotSpot, Airplane mode, Data usage, Location services More networks (Mobile networks, VPN, and Wi-Fi Calling), NFC, S Beam, Nearby devices, and Screen Mirroring.



Device:

This tab provides access to display configuration and customization features. Features include: Sound, Display, Multi window, LED indicator, Lock screen, Wallpaper, Font, Notification panel, Easy mode, Accessibility, Call, and Blocking mode.

DRAFT
Internal Use Only



Controls:

This tab provides both the ability to alter input parameters such as: Language and input, Voice control, Hands-free mode, S Pen, One-handed operation, Air gesture, Air view, Air command, Motions, Palm motion, Smart screen, and High touch sensitivity.



General:

This tab provides access to the remaining set of device settings not listed under the other tabs. These include: Accounts, Cloud, Backup and reset, Date and time, Accessory, Application manager, Battery, Power saving mode, Storage, Security, and About device.

Note: The settings for your device are described below using the order in which they appear in the Settings menu. Functions found under the Connections tab are listed first, followed by My device, Accounts, and More tabs.

Wi-Fi Settings

This section describes the Wi-Fi settings.

About Wi-Fi

Wi-Fi (short for "wireless fidelity") is a term used for certain types of Wireless Local Area Networks (WLAN). Wi-Fi communication requires access to an existing and accessible Wireless Access Point (WAP). These WAPs can either be Open (unsecured) as within most Hot Spots, or Secured (requiring knowledge of the Router name and password).

Note: After you complete a connection to an active Wi-Fi network, the Wi-Fi Calling feature will automatically be enabled.

Activating Wi-Fi

1. From the Home screen, press  and then tap **Settings** →  (**Connections** tab).
2. In a single motion touch and slide the **Wi-Fi** slider to the right to turn it on . The device scans for available in-range wireless networks and displays them under Wi-Fi networks on the same screen.

DRAFT

Internal Use Only

Deactivating Wi-Fi

1. From the Home screen, press  and then tap **Settings** → **Connections** tab.
2. In a single motion touch and slide the **Wi-Fi** slider to the left to turn it off.
– or –
Activate and Deactivate Wi-Fi from the Notification bar.

Note: Use of wireless data connections such as Wi-Fi and Bluetooth can reduce battery life and use times.

Connecting to a Wi-Fi Network

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Wi-Fi**.
The network names and security settings (Open network or Secured with WEP) of detected Wi-Fi networks display in the Wi-Fi networks section.
2. Tap the network you wish to connect to.

Note: When you select an open network you are automatically connected.

3. Enter a wireless password (if necessary).
4. Tap **Connect**.

Wi-Fi Status Indicators

The following icons indicate the Wi-Fi connection status:



Displays when Wi-Fi is connected, active, and communicating with a Wireless Access Point (WAP).



Displays when Wi-Fi is active and there is an available open wireless network.

Wi-Fi settings

Once set up for Wi-Fi connectivity, your device automatically uses Wi-Fi, when available, for all your mobile services.

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**. Configure the settings as desired.

The available Wi-Fi connection are displayed with a security type displayed next to them.

Network Notification

By default, when Wi-Fi is on, you receive notifications in the Status bar anytime your phone detects an available Wi-Fi network. You can deactivate this feature if you do not want to receive notifications.

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Tap **Network notification**. A check mark displayed next to the feature indicates Network notification is active.
4. Tap **Network notification** again to remove the check mark and deactivate this feature.

Passpoint

Wi-Fi CERTIFIED Passpoint™ allows users connect to Wi-Fi hotspot networks by simplifying the process of connecting to the correct network. In addition, this connection type provides WPA2™ security protection for safe data communication. Mobile devices, such as handsets and tablets, that are certified for Passpoint can still be used in existing hotspots. Users on passpoint-enabled hotspots, will also enjoy Wi-Fi roaming.

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. In a single motion touch and slide the **Passpoint** slider to the right to turn it on.
4. Tap the **Passpoint** field and begin the on-screen process of connecting to a compatible AP.

Sorting your Wi-Fi Entry List

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Tap the **Sort by** field and select either **Alphabet** or **RSSI**.

Keep Wi-Fi on During Sleep

By default, when your device enters a sleep mode, your Wi-Fi connection stays on all the time. If the feature is **Never** enabled during sleep that current data usage is taken over by your SIM and its network connection.

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced** → **Keep Wi-Fi on during sleep**.
3. Select an available option:
 - **Always**: maintains your current active Wi-Fi connection even during sleep.
 - **Only when plugged in**: maintains the active Wi-Fi connection only when the device detects it is connected to a power supply. This reduces the drain on your device's battery.
 - **Never (increase data usage)**: shuts off the current Wi-Fi connection during sleep and diverts any current data usage to the cellular network connection.

Allow scanning

Allows the Google location service and other apps to scan for networks, even when Wi-Fi is turned off.

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Tap the **Always allow scanning** field to activate or deactivate the feature.

Auto Network selection

Allows the device to automatically switch between Wi-Fi network or cellular network.

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Tap the **Auto network switch** to activate the feature that would allow the device to connect to the best available signal connection.

DRAFT
Internal Use Only

Install certificates

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Tap **Install certificates** and follow the on-screen instructions.

Finding your Wi-Fi Address Information

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  and then tap **Advanced**.
3. Locate the MAC Address and IP Address information at the bottom of the screen.
 - **MAC address:** view your device's MAC address, required when connecting to some secured networks (not configurable).
 - **IP address:** view your device's IP address.

Manually Adding a Wi-Fi Network

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi** → **Add Wi-Fi network**.
2. Enter the Network SSID (the name of your Wireless Access Point).
3. Tap the **Security** field and select a security option. This must match the current security setting on your target WAP (Wireless Access Point).
4. Enter your WAP's password if the WAP is secure.
5. Tap **Connect** to store the new information and connect to the target WAP.

Note: An SSID is a unique key which identifies a wireless LAN. Its purpose is to stop other wireless equipment from accessing your LAN — whether accidentally or intentionally. To communicate, wireless devices must be configured with the same SSID.

DRAFT

Internal Use Only

WPS Push Button

The WPS (Wi-Fi Protected Setup) feature (sometimes associated with a physical or on-screen button on most WAPs) allows you to pair your device and WAP without the need for entering a passcode. This process is similar to Wi-Fi Direct pairing.

In this case, once the WPS feature is active on your WAP, your device can then detect it and then immediately pair to it.

Note: WPS-capable routers appear in the Wi-Fi list of available devices with the term **(WPS available)** below their name.

To pair your device using WPS:

1. Follow the WPS activation instructions specific to your Wireless Access Point.
2. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
3. Press  then tap **WPS push button**.
4. Once the connection is complete, confirm the external router now appears in the Wi-Fi list as connected.

WPS PIN Entry

If a WPS Push Button does not work, there is an alternative WPS connection method where you would use a device generated PIN number to establish the connection. This number is then entered into your WAP's WPS client PIN field to complete the connection.

To pair your device using WPS PIN:

1. From the main **Settings** page, tap **Connections** tab → **Wi-Fi**.
2. Press  then tap **WPS PIN entry**.
3. Write down the generate PIN number and enter it into your Wi-Fi Router's client PIN field.
4. Once the connection is complete, confirm the external router now appears in the Wi-Fi list as connected.

DRAFT
Internal Use Only

Wi-Fi Direct Setup and Settings

You can configure your device to connect directly with other Wi-Fi capable devices. This is an easy way to transfer data between devices. These devices must be enabled for Wi-Fi direct communication. This connection is direct and not via a HotSpot or WAP.



Displays when Wi-Fi Direct is active and communicating.

Note: Activating this feature will disconnect your current Wi-Fi network connection.

To activate your connection:

1. From the main **Settings** page, tap **Connections** tab.
2. In a single motion touch and slide the **Wi-Fi** slider to the right to turn it on. The slider color indicates the activation status.
3. Tap **Wi-Fi Direct**.
4. Tap **Scan** and select the single device name to begin the connection process to another Wi-Fi Direct compatible device.
– or –

Tap **Multi-connect** → **Scan** and select all the device names to begin the connection process to these Wi-Fi Direct compatible devices.

Note: The target device must also have Wi-Fi Direct service active and running before it can be detected by your device.

DRAFT
Internal Use Only

5. Tap **Done**. The direct connection is then established. Confirm  appears in the Status bar.
6. When prompted to complete the connection, the recipient should tap **OK**. Your status field now reads “Connected” and your connected device is listed within the Wi-Fi Direct devices listing.

Bluetooth settings

About Bluetooth

Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car kits, and Bluetooth-enabled handhelds, computers, printers, and wireless devices. The Bluetooth communication range is usually up to approximately 30 feet.

Turning Bluetooth On and Off

To turn Bluetooth on:

1. From the Home screen, press  and then tap **Settings** →  (**Connections** tab).

2. In a single motion touch and slide the **Bluetooth** slider to the right to turn it on.
The slider color indicates the activation status. When active,  displays in the Status area.

To turn Bluetooth off:

1. From the Home screen, press  and then tap **Settings**.
2. In a single motion touch and slide the **Bluetooth** slider to the left to turn it off.

Note: Bluetooth must be enabled prior to use.

Bluetooth Status Indicators

The following icons show your Bluetooth connection status at a glance:



Displays when Bluetooth is active.



Displays when Bluetooth is connected (paired) and communicating.

Internal Use Only

Bluetooth Settings

The Bluetooth settings menu allows you to set up many of the characteristics of your device's Bluetooth service, including:

- Entering or changing the name your device uses for Bluetooth communication and description
- Setting your device's visibility (or "discoverability") for other Bluetooth devices
- Displaying your device's Bluetooth address

To access the Bluetooth Settings menu:

1. From the Home screen, press  and then tap **Settings** → **Connections** tab → **Bluetooth**.
2. Verify Bluetooth is active (indicated by ).
3. Press  and tap the **Visibility timeout**, **Received files**, and **Help** fields to set the options.

Changing the Device Name

1. From the Home screen, press  and then tap **Settings** →  (General tab) → **About device**.
2. Tap the **Device name** field and use the on-screen keyboard to edit the current device name.
3. Tap  to erase the current device name and enter a new name for this device using the keyboard.
4. Tap **OK** to confirm your setting.

DRAFT

Internal Use Only

Activating Visibility

1. From the main **Settings** page, tap **Connections** tab → **Bluetooth**.
2. Verify your Bluetooth is active.
3. From the top of the Bluetooth settings page, toggle the state of the visibility check mark. Activating this feature enabled your device visible allows other devices to pair and communicate.

Note: Your device visibility is based on the time set within the Visible time-out field (2 Minutes, 5 Minutes, 1 Hour, or Never timeout). Press  (**Menu**) → **Visibility timeout**. This value appears as a countdown within this **Visibility timeout** field.

Scanning for Devices

This option allows you to scan for active Bluetooth devices so you can pair with them.

1. From the main **Settings** page, tap **Connections** tab → **Bluetooth**.

2. From the bottom of the Bluetooth settings page, tap **Scan** to search for visible external Bluetooth-compatible devices such as headsets, devices, printers, and computers.

Important! Some Bluetooth devices are secured and require a PIN number to confirm and pair with them.

3. Enter a PIN to pair with the device, if one is required, and tap **OK**.

Scanning for Received Files

This option allows you to scan for active Bluetooth devices so you can pair with them.

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, press  and then tap **Received files**.

DRAFT
Internal Use Only

Pairing Bluetooth Devices

The Bluetooth pairing process allows you to establish trusted connections between your device and another Bluetooth device. When you pair devices, they share a passkey, allowing for fast, secure connections while bypassing the discovery and authentication process.

Note: Pairing between two Bluetooth devices is a one-time process. Once pairing is established the devices continue to recognize their partnership and exchange information without entering a passcode.

To pair your device with another Bluetooth device:

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, tap the **Visibility** field (shown by the device name).
Your device must be visible to successfully pair with an external device. This is shown by a green check mark.
3. Tap **Scan**. Your device displays a list of discovered in-range Bluetooth devices.
4. Tap a device from the list to initiate pairing.
5. Enter the passkey or PIN code, if needed, and tap **OK**.

6. The external device must accept the connection and enter your device's PIN code.

Once successfully paired to an external device,  displays in the Status area.

Note: Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth-compatible devices.

Important! If callers can not hear you during a call while using a paired Bluetooth headset (with built-in microphone), verify the **Call audio** option is enabled within the entry's Bluetooth Settings page.

Configuring Bluetooth Device Settings

Some connected Bluetooth devices are capable of more than just functioning as a headphone, but also have built in microphones for picking up voice. Although both functions are detected by the device and activated, there might be times when you need to change or update these settings for Phone and Media Audio:

- I can hear the other person but they can't hear me...
 - I want to use my Bluetooth device only as a headphone
1. Verify Bluetooth is active.
 2. From the Bluetooth settings page, tap  (Settings).
 3. Toggle the **Call audio** field to activate/de-activate the Bluetooth device's on-board microphone.
 4. Toggle the **Media audio** field to activate/de-activate the Bluetooth device's headset functions.

Note: If callers can not hear you during a call while using a paired Bluetooth headset (with built-in microphone), verify the **Call audio** option is enabled within the entry's Bluetooth Settings page.

Disconnecting a Paired Bluetooth Device

Disconnecting a paired device breaks the connection between the device and your phone, but retains the knowledge of the pairing. At a later point when you wish to reconnect the device, there is no need to setup the connection information again.

1. Verify your Bluetooth is active.
2. From the Bluetooth settings page, tap the previously paired device (from the bottom of the page).
3. Tap **OK** to confirm disconnection.

Note: Disconnections are manually done but often occur automatically if the paired device goes out of range of your phone or it is powered off.

Deleting a Paired Bluetooth Device

Deleting a device from your list removes its “connection record” and upon reconnection would require that you re-enter all the previous pairing information.

1. Verify Bluetooth is active.
2. From the Bluetooth settings page, tap  (Settings) → **Unpair** to delete the paired device.

Sending Contacts via Bluetooth

Depending on your paired devices' settings and capabilities, you may be able to send pictures, Contact information, or other items using a Bluetooth connection.

Note: Prior to using this feature, Bluetooth must first be enabled on both your phone and the external device, and the recipient's device must be visible.

1. Verify your Bluetooth is active and your phone is visible.
2. From the Home screen, tap  (**Contacts**).
3. Touch and hold the entry from the list to display the on-screen context menu.
4. Tap **Share via → Bluetooth** and select a paired external Bluetooth device.

Note: The external Bluetooth device must be visible and communicating for the pairing to be successful.

5. A Bluetooth share notification displays in your notifications list.

Tethering and Mobile HotSpot

This section covers procedures for both the Mobile HotSpot and USB tethering functionality.

Mobile HotSpot

This feature allows you to turn your device into a Wi-Fi hotspot. The feature works best when used in conjunction with 4G/LTE data services (although 3G service can also be used).

The Mobile HotSpot connectivity is a wireless version of this same functionality and allows you to provide Internet connectivity to multiple devices.

Important! The Mobile HotSpot service cannot be active when device is connected to Wi-Fi. Please disconnect your Wi-Fi connection prior to active this service.

Note: You must have a tethering plan on your account in order to use the Mobile HotSpot. You cannot use data on the device while using Mobile HotSpot.

DRAFT
Internal Use Only

To activate the Mobile HotSpot service:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
— or —

From the Home screen, press  and then tap **Settings** →  (Connections tab) → **Tethering and Mobile HotSpot** → **Mobile HotSpot**.

2. In a single motion touch and slide the **Mobile HotSpot** slider to the right to turn it on.
3. Edit the **Network SSID** name and then write it down.
4. Enable the **Broadcast network name (SSID)** field if you would like to broadcast your SSID name to nearby devices.
5. Verify the **Security** field is set to **WPA2 PSK**.
6. Enter a new password then write it down.
 - Additional options include Show password and Show advanced options.
7. Tap **Save** to store the new settings.
8. Confirm the Mobile HotSpot active icon  appears at the top of the screen.

Note: Using your Mobile HotSpot drains your device's battery much faster. The best way to keep using the device as a HotSpot is by connecting to a Charger.

To connect to the HotSpot:

1. Enable Wi-Fi (wireless) functionality on your target device (laptop, media device, etc.).
2. Scan for Wi-Fi networks from the external device and select your device's Mobile HotSpot name from the network list.
 - The SSID name for your device's hotspot is determined by what you entered into the **Network SSID** field.
 - You can change the name by tapping **Configure** → **Network SSID** and changing the entry.
3. Select this HotSpot and follow your on-screen instructions to complete the connection.
4. Launch your Web browser to confirm you have an Internet connection.

To change the Portable HotSpot password:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
2. Tap **Mobile HotSpot** → **Configure**.
3. Tap the **Security** field and select **WPA2 PSK**.
4. With security enabled, delete the previous password and enter a new one into the **Password** field.

Important! The more complex the password, the harder it will be for intruders to break your security. It is recommended that you not use names, birthdays, or other personal information.

5. Tap **Save** to store the new settings.

To manage connected devices:

This feature allows you to provide MAC filtering on your device. This is similar to a “VIP list” where only device on the list are allowed access.

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
2. Tap **Mobile HotSpot** → **Allowed devices**.
3. Tap  (**Add new device**) to add devices to the allowed for connection list.
4. Enter the Device name and Mac address.
5. Tap **OK** to save the new device.

DRAFT

Internal Use Only

Transmit Power Mode

You can select a transmission parameter for the HotSpot. You can choose to select an option that either maximizes your battery life or extends the range of the HotSpot coverage.

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot) → Transmit power mode.
2. Select an available option.
 - **Maximize battery life:** increases your battery life by reducing the power used for HotSpot transmission. This option reduces the transmission range.
 - **Maximize hotspot range:** increases the range of your transmission while at the same time decreasing battery life.

USB Tethering

This option allows you to share your device's mobile data connection via a direct USB connection between your device and a single computer. The Mobile HotSpot connectivity is a wireless version of this same functionality and allows you to provide Internet connectivity to multiple devices.

Note: You can not mount your device's microSD card to your computer while using the USB tethering feature. If additional software or USB drivers are required, navigate to: <http://www.samsung.com/us/support/downloads>.

DRAFT
Internal Use Only

To connect using USB Tethering:

1. From the Home screen, tap  (Apps) →  (T-Mobile) →  (Mobile HotSpot).
– or –

From the Home screen, press  and then tap

Settings →  (Connections tab) → **Tethering and Mobile HotSpot** → **Mobile HotSpot**.

2. Plug in the USB cable between your computer and your device.
3. Tap **USB tethering** from the Tethering menu. This places a green check mark next to the entry and activates the feature. A Tethering or HotSpot active notification briefly appears on the screen.
Look for the Tethering active icon  in the Status bar area of the screen.
4. Read the on-screen notification regarding data use and tap **OK**.

To disconnect tethering:

1. From the Home screen, tap  (Apps) →  (Mobile HotSpot).
2. Tap **USB tethering** from the Tethering menu to remove the check mark and deactivate the feature.
3. Remove the USB cable from the device.

Airplane Mode

This mode allows you to use many of your device's features, such as Camera, Games, and more, when you are in an airplane or in any other area where making or receiving calls or data is prohibited.

Important! When your device is in Airplane mode, it cannot send or receive any calls or access online information or applications.

1. From the main **Settings** page, tap **Connections** tab → **More networks**.
2. In a single motion touch and slide the **Airplane mode** slider to the right to turn it on.
3. Tap **OK**. The Airplane mode icon  is displayed at the top of your screen.

Data Usage

Monitor and manage your device's data usage capabilities.

Features include activation/deactivation of network data usage, set mobile data usage for a set period of time, and view application data usage.

- From the Home screen, press  and then tap **Settings** →  (**Connections** tab) → **Data usage**.

To activate/deactivate Mobile data usage:

1. From the main **Settings** page, tap **Connections** tab → **Data usage**.
2. Tap the **Mobile data** field to activate the feature. A green check mark indicates the feature is active.
3. Tap the **Mobile data** field again to deactivate the feature.

To set a mobile data limit:

1. From the main **Settings** page, tap **Connections** tab → **Data usage**.
2. Place a check mark in the **Set mobile data limit** field.
3. Read the on-screen disclaimer info and tap **OK**.

4. Touch and drag the far right ends of the Red or Orange horizontal lines to manually adjust both the Warning and Maximum data limits.
5. Touch and drag the bottom grey vertical lines to adjust the time frames.
6. Tap the **Data usage cycle** button and select either the current cycle or define your own by selecting **Change cycle**.
7. Press  and then select from the available on-screen options:
 - **Data roaming** allows you to connect to your service provider's partner networks and access data services when you are out of your service providers area of coverage. For more information, refer to "*Data Roaming*" on page 255.
 - **Restrict background data** prevents background data usage. This can help prevent over usage of your data minutes.
 - **Auto sync data** allows the device to automatically sync information and updates with your various services.
 - **Show Wi-Fi usage** activates an additional Wi-Fi tab that shows you your Wi-Fi data usage.

8. **Mobile hotspots** allows you to select available Wi-Fi networks that can service as mobile hotspots. Place a check mark on those entries you wish to use.

Location Services

The Location services allows you to configure the device's location services.

Important! The more location determining functions are enabled, the more accurate the determination will be of your position.

1. From the Home screen, press  and then tap **Settings** →  (Connections tab) → **Location services**.
2. Tap any of the following options to create a checkmark and activate the service:
 - **Access to my location:** allows apps that have asked your permission to use your location information. Tap the ON/OFF slider to turn it on.
 - **Use GPS satellites:** allows applications to use GPS to pinpoint your location.

- **Use wireless networks:** allows applications to use data from mobile networks and Wi-Fi to help determine your location.
- **My places:** allows you to add location information for your Home, Office, and Car.

Enabling the GPS Satellites

1. From the main **Settings** page, tap **Connections** tab → **Location services**.
2. Tap **Use GPS satellites** to enable the GPS satellite.

Using Wireless Networks

Before you use applications such as Google Maps and find your location or search for places of interest, you must enable the Use wireless networks option.

1. From the main **Settings** page, tap **Connections** tab → **Location services**.
2. Tap **Use wireless networks** to allow apps to use data from sources such as Wi-Fi and mobile networks to provide a better approximation of your current location.

DRAFT
Internal Use Only

Enabling My Places

1. From the main **Settings** page, tap **Connections** tab → **Location services**.
2. Tap **My places** to enable the storage of your favorite locations.

More Networks

This tab displays additional wireless and network information.

- From the Home screen, press  and then tap **Settings** →  (Connections tab) → **More networks**.

Mobile networks

Before you use applications such as Google Maps and find your location or search for places of interest, you must enable the Mobile networks options.

- From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks**.

The following options display:

Use mobile data

Allows you to activate mobile data usage on your device.

- From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Mobile data**.

Data Roaming

Data roaming allows you to connect to your service provider's partner networks and access data services when you are out of your service providers area of coverage.

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks**.
2. Tap **Data roaming** to connect to data services while roaming outside your network.
– or –

Tap **Data roaming** again to remove the green check mark and deactivate the feature.

DRAFT
Internal Use Only

Access Point Names

To access a wireless access point:

- From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Access Point Names**. A list of the Access point names display. The active access point displays a bright green, filled circle to the right of the name.

Network mode

You can configure your device to either automatically select the LTE option (LTE/GSM/WCDMA (auto connect) [by default]), GSM/WCDMA (auto connect), GSM only, or WCDMA only.

- From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Network mode**.
 - **LTE/WCDMA/GSM (auto connect)** is the default network mode option. This selection allows the device to choose the fastest connection from among the available connection speeds, including LTE.
 - **WCDMA/GSM (auto connect)** allows you to exclude the LTE network and choose from only 4G, 3G, and 2G networks.
 - **WCDMA only** restricts your connection to only the 3G network.
 - **GSM only** restricts your connection to only the 2G network.

Using the LTE Network Option

To confirm you are always using the fastest possible connection, the device has an automatic detection method where it finds both the fastest and most stable connection/communication method from among this selected set (LTE/4G/3G/2G).

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Network mode**.
2. Tap **LTE/WCDMA/GSM (auto connect)**. A selection indicator displays next to this option to show that it is active. This is the default mode for this device.

Using the WCDMA/GSM Option

If you wish to not use LTE but still require a fast connection using the standard 3G/2G network speed, follow these instructions to connect to these network types.

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Network mode**.
2. Tap **WCDMA/GSM (auto connect)**. A selection indicator displays next to this option to show that it is active. This is the default mode for this device.

Using the WCDMA - 3G Only Network

This option uses a 3G connection only.

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Network mode**.
2. Tap **WCDMA only**. A check mark displays next to this option to indicate that it is active. Connecting to 3G networks slows the data transfer speed and time.

Using the 2G - GSM Only Network

If you are not using applications that require a faster network speed (any application that accesses the network or uses a browser), using the 2G only (WCDMA) network saves battery life.

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Network mode**.
2. Tap **GSM only**. A check mark displays next to this option to indicate that it is active. Connecting to 2G networks slows the data transfer speed and time.

Network Operators

Using this feature you can view the current network connection. You can also scan and select a network operator manually, or set the network selection to Automatic.

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks**.
2. Tap **Network operators**. The current network connection displays at the bottom of the list.

Important! You must deactivate data service prior to searching for an available network.

3. Tap **Search now** to manually search for a network.
4. Tap **Select automatically** to automatically select a network connection.

Note: Connecting to 2G networks slows the data transfer speed and time.

DRAFT
Internal Use Only

Default Setup Options

Your phone default is set to Automatic (to automatically search for an available network. You can set this option to Manual to select a network each time you connect.

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **Mobile networks** → **Network operators**.
2. Tap **Default setup**.
3. Tap **Automatic** to allow the device to automatically select a network.
– or –
Tap **Manual** to locate and connect to a network manually.

VPN settings

The VPN settings menu allows you to set up and manage Virtual Private Networks (VPNs).

Note: Before using VPN, you must first set up a screen unlock PIN or password. For more information, refer to “*Security*” on page 316.

Adding a VPN

Before you add a VPN you must determine which VPN protocol to use: PPTP, L2TP/IPSec PSK, L2TP/IPSec RSA, IPSec Xauth PSK, IPSec Xauth RSA, IPSec Hybrid RSA.

Important! Before you can use a VPN you must establish and configure one.

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **VPN**.
2. If prompted, read the screen lock information and follow the on-screen steps to setup an unlock PIN or password.
3. Tap  (Add VPN network).

4. In the form that appears, fill in the information provided by your network administrator.
5. Tap **Save**.

Note: Similar setup process can be used for all available VPN types.

Connecting to a VPN

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **VPN**.
2. Tap the VPN entry you want to connect to.
3. Enter any requested credentials into the pop-up that opens.
4. Tap **Connect**.

Edit a VPN

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **VPN**.
2. Touch and hold the VPN that you want to edit.
3. In the pop-up that opens, select **Edit network**.
4. Make the desired VPN setting changes.
5. Tap **Save**.

Delete a VPN

1. From the main **Settings** page, tap **Connections** tab → **More networks** → **VPN**.
2. Touch and hold the VPN that you want to delete.
3. Tap **Delete network** within the pop-up that opens up.

Wi-Fi Calling

Wi-Fi Calling is a free feature for T-Mobile customers using this device with the new SIM card. Wi-Fi Calling is an excellent solution for coverage issues in and around the home or wherever cellular coverage is limited. Minutes used while connected to the Wi-Fi network count against available rate plan minutes.

The benefits of Wi-Fi Calling include the following:

- Wi-Fi Calling provides a coverage option to improve upon your current in-home coverage experience
- Wi-Fi Calling works anywhere there is a Wi-Fi signal available

Important! A new micro SIM card must be installed within the device prior to using this feature. Wi-Fi must first be active and communicating prior to launching Wi-Fi Calling.

Note: This feature is active by default. If you are in an active Wi-Fi call and go out of range of your Wi-Fi, the call will be dropped.

Note: To avoid international data roaming fees when using Wi-Fi calling when outside the United States, the Data Roaming feature on your device must be turned off.

Note: With certain rate plans, minutes used while connected to the Wi-Fi network count against available rate plan minutes.

Important! If you are not using a new ISIM card, you will receive an **Error: ERxx Invalid SIM** message. You must be using a new ISIM card to use this feature.

Activating Wi-Fi Calling

1. Ensure that the **Wi-Fi connected** icon  displays on the Status Bar.
 - If prompted with an on-screen “Did you know your phone can make calls over Wi-Fi” popup, tap **Learn** and follow the remaining on-screen instructions. Tap **Next** → **Done**.
2. From the main **Settings** page, tap **Connections** tab → **More networks**.
3. Locate the **Wi-Fi Calling** field and in a single motion touch and slide  to the right to turn it on.
4. If  (**Missing 911 Address**) displays in the Status Bar, follow these steps to provide 911 an address for emergency situations:
 - Log into my.t-mobile.com.
 - Click on **Profile** and edit the **Edit customer information**.
 - Enter your emergency location information and complete the online registration.
5. From the main **Settings** page, tap **Connections** tab → **More networks** → **Wi-Fi Calling**.

DRAFT
Internal Use Only

6. Tap **Connection Preferences** and select a preference for use by the Wi-Fi Calling feature:
 - **Wi-Fi Preferred:** Wi-Fi network is preferred over cellular network when making calls. Calling requires you to stay in the Wi-Fi range.
 - **Cellular Network Preferred:** The cellular network is preferred over a Wi-Fi network when making calls.
 - **Never use Cellular Network:** Use only Wi-Fi for calls. Do not use Cellular Network, even if available.
7. Tap **OK** to save the setting.
8. From the main **Settings** page, tap **Connections** tab → **More networks**.
9. Tap **Wi-Fi Calling** slider to toggle off the feature, then tap it again to reactivate the feature and re-register your device with the T-Mobile Network.
10. Confirm  (**Wi-Fi Calling Ready**) displays in the Status Bar.

Launching Wi-Fi Calling

Note: Verify you are currently connected to a Wireless Access Point.

1. Ensure that the **Wi-Fi connected** icon displays on the status bar.
2. Confirm  (**Wi-Fi Calling Ready**) displays in the Status Bar.
3. Use the phone Dialer, Logs, or Contacts list to make a call.
4. Go to the dialer and make a call. Make sure  (**Wi-Fi Calling in use**) appears during the call.

DRAFT

Internal Use Only

When	Action	Then
	Displays on the screen status bar.	You are connected to the T-Mobile network and can make Wi-Fi calls.
	Displays on the screen status bar.	The Wi-Fi Calling feature is active and in use within an active call.
	Does not display on the screen status bar.	You are charged normal calling rates. For more information, refer to <i>"Activating Wi-Fi Calling"</i> on page 260.
	Displays on the screen status bar.	There is an error in the use or 911 registration of the Wi-Fi Calling feature.

While Wi-Fi Calling mode is active, the call button shows a Wi-Fi indicator .

When Wi-Fi Calling is disabled, the call button goes back to show normal operation .

Near Field Communication

This feature is used to read and exchange tags. When used in conjunction with Android Beam, your device can be used to beam application content when NFC-capable devices are touched.

1. From the main **Settings** page, tap **Connections** tab.
2. Tap the **NFC** field and verify the feature is active (indicated by .

Android Beam

When Android Beam is activated, you can beam app content to another NFC-capable device by holding the devices close together. You can beam browser pages, YouTube videos, contacts, and more.

1. From the main **Settings** page, tap **Connections** tab → **NFC → Android Beam**.
2. Tap the **OFF / ON** icon to turn Android Beam on.
3. Touch the back of your device with another NFC-capable device and the content is transferred.

S Beam

This feature (when activated via NFC) allows you to beam large files directly to another compatible device that is in direct contact. These files can be larger, such as Videos, HD pictures, and other large files. You can beam images and videos from your gallery, music files from your music player, and more.

1. From the main **Settings** page, tap **Connections** tab.
2. Verify the NFC feature is active.
3. Tap **S Beam** and make sure the feature is turned on.
4. If not already active, in a single motion touch and slide the **S Beam** slider to the right to turn it on.
5. Complete the transfer process between the two NFC-enabled devices by placing them back to back.

This feature can come in very handy to quickly share pictures between users with compatible S Beam devices. For more information, refer to “*Using S Beam to Share Pictures*” on page 136.

Nearby Devices

This option allows you to share your media files with nearby devices using DLNA and connected to the same Wi-Fi.

1. Connect to a Wi-Fi network. For more information, refer to “*Connecting to a Wi-Fi Network*” on page 237.
2. From the main **Settings** page, tap **Connections** tab → **Nearby devices**.
3. Tap the **Nearby devices** field to turn File sharing on. A green check mark indicates the feature is active. Once active,  (**Nearby devices**) appears at the top of the screen.
4. At the Nearby devices prompt, tap **OK**.
5. Tap **Shared contents**, then check the media you would like to share. Tap **OK**.
6. Tap **Allowed devices list**, then select the connected devices you would like to allow.
7. Tap **Not-allowed devices list**, then select the connected devices you would like to not allow.
8. Tap **Download to**, then select the destination of any downloaded (shared) content. Choose from USB storage (Device) or SD card.

9. Tap **Upload from other devices**, then select the actions you'll take when you upload content from other devices. Choose from either Always accept, Always ask, or Always reject.

Screen Mirroring

With feature enabled, you can wirelessly mirror what is currently displayed on your device's screen with an external TV via devices such as the AllShare Cast Hub®.

Note: Screen mirroring can only be done with a compatible wireless TV or one enabled with the AllShare Cast Hub.

For more information, refer to “*AllShare Cast Hub*” on page 143.

1. From the main **Settings** page, tap **Connections** tab → **Screen Mirroring**.
2. In a single motion touch and slide the **Screen Mirroring** slider to the right to turn it on. The slider color indicates the activation status.

Note: This feature allows a connection between your device and the optional AllShare Cast Hub, via a shared Wi-Fi Direct connection. The AllShare Cast Hub then allows the communicating TV to mirror what is being shown on the device's display.

For more information, refer to “*AllShare Cast Hub*” on page 143.

DRAFT
Internal Use Only

Sound Settings

From this menu you can control the sounds on the phone as well as configure the display settings.

- From the Home screen, press  and then tap **Settings** →  (Device tab) → **Sound**.

The following options display:

Silent mode via Device Options Screen

Silent mode is convenient when you wish to stop the phone from making noise, in a theater for example. In Silent Mode the speaker is muted and the phone only vibrates to notify you of incoming calls, or other functions that normally have a defined tone or sound as an alert.

1. From the Home screen, press and hold  (Power/End) until the **Device options** screen displays.
2. Tap either **Mute**, **Vibrate**, or **Sound** from the Device options screen to activate or deactivate these features (the current mode displays).

Adjusting the Volume Settings

The Volume menu now provides access to various volume settings within one on-screen popup menu.

1. From the main **Settings** page, tap **Device** tab → **Sound** → **Volume**.
2. Touch and drag the on-screen slider to assign the volume settings for any of the following volume levels.
 - **Music, video, games, and other media**, **Ringtone**, **Notifications** or **System**.
3. Tap **OK** to assign the volume levels.

Vibration intensity

Vibration intensity allows you to select how intense the vibration is for different options.

1. From the main **Settings** page, tap **Device** tab → **Sound** → **Vibration intensity**.
2. Touch and drag the slider to adjust the Vibration intensity for **Incoming call**, **Notification**, and **Haptic feedback**.
3. Tap **OK** to assign the vibration levels.

DRAFT
Internal Use Only

Setup the Ringtones

This option allows you to set the ringtone.

1. From the main **Settings** page, tap **Device** tab → **Sound** → **Ringtones**.
2. Tap a ringtone from the available list. The ringtone briefly plays when selected.
3. Tap **Add** to locate a compatible media file that can be used as a ringtone.
4. Tap **OK** to assign a ringer.

Setup the Vibration

This option allows you to set your device to vibrate and ring.

1. From the main **Settings** page, tap **General** tab → **Sound** → **Vibrations**.
2. Select a vibration pattern and tap **OK**.

– or –

Tap **Create** to then use an on-screen touch circle to create your own custom vibration pattern. Tap **Save** to store the new vibration pattern.

Default Notification Sound

This option allows you to set the ringtone that will sound for notifications and alarms.

1. From the main **Settings** page, tap **Device** tab → **Sound**.
2. Tap **Default notification sound**.
3. Select a ringtone and tap **OK**.

Setting up Vibration When Ringing

This option allows you to enable your phone to vibrate when a call is incoming.

1. From the main **Settings** page, tap **Device** tab → **Sound**.
2. Tap the **Vibrate when ringing** field to activate the feature.

DRAFT
Internal Use Only

Audible System Tone Settings

These options are used when you use the dialing pad, make a screen selection, lock your screen, or tap the screen. Each time you press a key or make a selection the selected tone sounds.

1. From the main **Settings** page, tap **Device** tab → **Sound**.
2. Tap **Dialing keypad tone** to activate a tone when you use on-screen keys. A check mark displayed next to these features indicates active status.
3. Tap **Touch sounds** to activate a tone when you touch the screen. A check mark displayed next to this feature indicates active status.
4. Tap **Screen lock sound** to activate a tone when you use the Lock screen. A check mark displayed next to this feature indicates active status.
5. Tap **Haptic feedback** to activate the a vibration when you press soft keys on certain screens. A check mark displayed next to the feature indicates this feature is active.

Audio Output

This sound feature configures the audio output.

1. From the main **Settings** page, tap **Device** tab → **Sound** → **Audio output**.
2. Choose from either Stereo or Surround.

Adapt sound

The Adapt sound feature allows you to customize your call sounds.

1. From the main **Settings** page, tap **Device** tab → **Sound** → **Adapt Sound**.
2. Read the instructions and tap **Start**.
3. Follow the on-screen instructions to set up your personal call sound.

DRAFT
Internal Use Only

Display Settings

From this menu you can control the sounds on the phone as well as configure the display settings.

1. From the Home screen, press  and then tap **Settings** →  (Device tab) → **Display**.
2. Configure the following screen display settings:
 - **Brightness** allows you to configure the LCD Brightness levels.
 - Tap **Automatic brightness** to allow the device to self-adjust and tap **OK**.
 - or —
 - Touch and slide the on-screen slider to adjust the level and tap **OK**.
 - **Screen timeout**: allows you to adjust the delay time before the screen automatically turns off. Make an available selection. Choices include: 15 seconds, 30 seconds, 1 minute, 2 minutes, 5 minutes, and 10 minutes.
 - **Touch key light duration**: allows you to adjust the delay before the Touch key light automatically turns off.
 - **Screen mode**: allows you to select from several different color modes.

- **Reading mode**: allows you to activate an optimized reading mode for selected applications. This menu allows you to assign available applications (such as Calculator, Camera, Contacts, etc...) for enhancement using the Reader mode.
- **Auto adjust screen tone**: adjusts the phone's LCD brightness level to automatically adjust and conserve battery power.
- **Daydream**: allows you to control what your screen does when your device is docked or sleeping. Tap the adjacent OFF / ON icon to turn it on. Follow the on-screen instructions.
- **Auto rotate screen** when enabled, this feature, allows the device to automatically switch from portrait to landscape orientation and vice versa. When this setting is disabled, the device displays in portrait mode only.
- **Show battery percentage** when enabled, displays of battery charge percentage atop the battery icon at the top of the screen.
- **Edit after screen capture** when enabled, this feature takes you to the Edit screen after capturing a screen image.

DRAFT
Internal Use Only

Multi window

This option to enable/disable the automatic Multi window feature.

1. From the Home screen, press  and then tap **Settings** →  (Device tab).
2. Tap the **Multi window** field to toggle the activation status.

LED Indicator

This option allows you to turn on your LED lights for charging, missed events, and incoming notifications. The light will turn on by default unless you turn them off.

1. From the Home screen, press  and then tap **Settings** →  (Device tab) → **LED indicator**.
2. Tap the following LED indicator options to turn them on or off:
 - **Charging:** LED lights up when the device is connected to the charger.
 - **Low battery:** LED lights up when the battery level is low.
 - **Notifications:** LED lights up when you have missed calls, messages, or application events.

- **Voice recording:** LED lights up when you are recording voice.
The LED only lights up when the screen is off.

Lock Screen

This menu contains features that allows you to configure the device's security parameters.

Screen Unlock Pattern Overview

To secure data and limit phone access, set the phone to require a screen unlock pattern each time you turn on the device, or every time the phone wakes up from sleep mode (when the screen automatically turns off).

- From the main **Settings** page, tap **Device tab** → **Lock screen** → **Screen lock**.

The Screen lock menu allows to choose from a variety of locking features such as:

- **Swipe:** Swipe the screen to unlock it.
- **Signature:** Draw your signature on-screen to unlock the device.
- **Pattern:** A screen unlock pattern is a touch gesture you create and use to unlock your device. Follow the prompts to create or change your screen unlock pattern.
- **PIN:** Select a PIN to use for unlocking the screen.

- **Password:** Create a password for unlocking the screen.
- **None:** No pattern, PIN, or password is required. The screen will never lock.

Swipe options

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Configure one of the following options.
 - **Multiple widgets** allows you to display multiple widgets on your lock screen. Appears as an options after a lock mode is enabled.
 - **Clock widget options** allows you to show the dual clock on the lock screen, adjust the Clock size, and show the date.
 - **Shortcuts** sets shortcuts to appear at the bottom of the Lock screen. Touch and slide the slider to the right to turn it on.
 - **Personal message** allows you to enter a customized personalized message that is displayed on the lock screen.
 - **Owner information** allows you enter text to display on the lock screen.
 - **Unlock effect** sets the effect you receive when unlocking the device. You can select None or Light effect.

- **Ink effect** sets the coloring for the on-screen ink used in writing/drawing.
- **Wake up in lock screen** requires that you say a command to wake-up your phone.
- **Action Memo on lock screen** allows you to open the Action Memo when double tapping the lock screen with S Pen.
- **Help text** shows help information on the Lock screen.

Using Swipe

This feature is the least secure locking method and only requires that a user swipe the screen to unlock the device.

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Tap **Screen lock** → **Swipe**.

Using a Signature to Unlock

This feature uses a recognized on-screen signature to unlock the device.

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Tap **Screen lock** → **Signature**.
3. Remove your S Pen.
4. From the Register Signature screen, draw a signature or symbol within the drawing area.
5. Wait for the device to notify you that the signature was registered and tap **Continue**.
6. Repeat the process two more times to confirm the new signature or pattern.
7. Enter a backup PIN and tap **Continue**.
8. Repeat the process to re-confirm the PIN.

Setting an Unlock Pattern

Creating a screen unlock pattern increases security on the phone. When you enable the User visible pattern field, you will draw an unlock pattern on the screen whenever you want to unlock the phone's buttons or touch screen. When you activate the User tactile feedback field, you feel vibration as feedback while drawing the pattern.

The feature is now paired with a backup PIN code that acts as a backup to the pattern lock. If you forget your pattern, you can regain access to the device by entering a PIN code.

Note: Make sure the Require Pattern field is activated.

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Tap **Screen lock** → **Pattern**.
3. Draw your pattern by touching your first on-screen point. Then, **without removing your finger from the screen, drag your finger over adjacent points until the gray trace line overlaps each point** and they are highlighted with a green circle.

DRAFT
Internal Use Only

4. When you have connected at least four dots in a vertical, horizontal or diagonal direction, lift your finger from the screen and tap **Continue**.
5. Confirm the new pattern by redrawing it and then tapping **Confirm**. The Unlock pattern is set.
6. Enter the backup PIN code and tap **Continue**.
7. Reenter the PIN to reconfirm the previous entry and tap **OK**.

Changing the Screen Lock Pattern

This feature allows you to change the previously stored unlock pattern and update it if necessary. This process is similar to changing your password from time to time.

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Tap **Screen lock**.
3. Retrace your current pattern on the screen.
4. Tap **Pattern** and repeat steps 3 - 7 from the previous section.

Deleting the Screen Lock Pattern

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Tap **Screen lock**.
3. Retrace your current pattern on the screen.
4. Tap **None**.

Pattern options

Once an unlock pattern is enabled, additional options are available:

- **Clock widget options** allows you to show the dual clock on the lock screen, adjust the Clock size, and show the date.
- **Personal message** allows you to enter a customized personalized message that is displayed on the lock screen.
- **Owner information** allows you enter text to display on the lock screen.
- **Make pattern visible** allows you to see the pattern as you draw it.
- **Unlock effect** allows you to assign an effect to the unlock screen. Choose from: None, Oil paint, or Watercolor.
- **Lock automatically** allows you to set a time-out for lock screen.

- **Lock instantly with power key** allows you to lock the screen by pressing  ①.
- **Action Memo on lock screen** allows you to open the Action Memo when double tapping the lock screen with S Pen.

What If I Forget my Pattern?

If you forget your device's lock pattern, you can unlock your device or reset it using your Google™ Account credentials. When you enter the wrong unlock pattern too many times, you should see an option at the bottom of the screen that says **Forgot pattern?** Follow these steps to use either your PIN or email address.

Important! You can only enter an incorrect lock pattern 5 times before the device is locked.

Important! If you are unsuccessful in retrieving your lock pattern or unlocking your device, please contact T-Mobile for assistance.

To unlock your device with a PIN code:

1. Tap **Forgot pattern?** (located at the bottom of the screen).
2. Scroll down and tap the **Type PIN code** field and use the on-screen keypad to enter the backup PIN code you setup when you created your lock pattern.
3. Tap **OK**.
4. If you have forgotten your current pattern, tap **Pattern** from the Screen unlock settings menu and follow the procedures outlined in *"Setting an Unlock Pattern"* on page 271 to create a new pattern.

To unlock your device using your Google account:

1. Tap **Forgot pattern?** (located at the bottom of the screen).
2. Tap the **Username (email)** and **Password** fields, use the on-screen keyboard to enter your Google Account credentials, and tap **Sign in** to complete the login process.

DRAFT
Internal Use Only

3. If you have forgotten your Google Account credentials, visit the Google website to recover them. If you still cannot get your Google Account credentials, contact your wireless carrier for additional options.

PIN Lock and Unlock

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Tap **Screen lock** → **PIN**.
3. Enter a PIN number using the numeric keypad and touch **Continue** to confirm the password.
4. Confirm the PIN by re-entering it and tap **OK** to confirm. Your phone now requires you to enter this PIN number in order to unlock the phone.

Password Lock and Unlock

1. From the main **Settings** page, tap **Device** tab → **Lock screen**.
2. Tap **Screen lock**.
3. Tap **Password**.
4. Enter a password using the keypad and tap **Continue** to confirm the password.

5. Confirm the password by re-entering it and tap **OK** to confirm.

Wallpaper

To assign a wallpaper:

The Wallpaper settings option allows you to set the Wallpaper for your Home screen, Lock screen, or both.

1. From the Home screen, press  and then tap **Settings** →  (**Device** tab) → **Wallpaper**.
2. Select an available option to change its current wallpaper.

For more information, refer to “*Managing Wallpapers*” on page 38.

Font

This function adjusts the delay time before the screen automatically turns off.

1. From the Home screen, press  and then tap **Settings** →  (Device tab) → **Font**.
2. Adjust an available on-screen option to adjust either the font style and size.
 - **Font style:** sets the fonts used on the LCD display. Selections are: **Default font**, **Choco cooky**, **Cool jazz**, **Rosemary**, **Samsung Sans** or **Get fonts online**. Tap **Get fonts online** to download additional fonts.
 - **Font size:** allows you to select which size of font is displayed.

Notification Panel

This feature allows you to set the brightness of your notification panel and also select the quick setting buttons that you want to display at the top of the notification panel (page 32).

1. From the Home screen, press  and then tap **Settings** →  (Device tab) → **Notification panel**.
2. Enable the **Brightness adjustment** field to activate the ability to adjust the screen brightness via the notification panel.

To customize the notification panel quick access buttons:

1. Access the Notification Panel screen.
 - The set of buttons within the Notification panel area are those that are available within the Notifications panel. They provide quick access to available features. These can be customized by the user.
2. Replace existing notification panel buttons by:
 - In a single motion, touch and drag an available button from the bottom of the screen into a location within the Notification panel area.

DRAFT
Internal Use Only

- One of the 10 default buttons is then replaced with the new selection.

3. Tap **Reset** to restore the Notification Panel buttons to their original configuration.

Easy Mode

This application allows you to leave your display using the default layout of **Standard mode** or provide an easier user experience for the first-time smartphone users using **Easy mode**.

1. From the Home screen, press  and then tap **Settings** →  (Device tab) → **Easy mode**.
2. Activate the feature by moving the activation slider (indicated by ).

Accessibility Settings

This service lets you enable and disable downloaded accessibility applications that aid in navigating your Android device, such as TalkBack (uses synthesized speech to describe the results of actions), KickBack (provides haptic feedback for actions), and SoundBack (plays sounds for various actions). Also lets you enable use of the power key to end calls.

1. From the Home screen, press  and then tap **Settings** →  (Device tab) → **Accessibility**.

Note: Initially, it might be necessary to download accessibility applications from the Play Store.

2. Select the **Auto rotate screen** field to activate this feature which automatically rotates an available screen.
3. Tap **Screen timeout** to timeout the accessibility feature after a defined amount of time.
4. Tap **Lock automatically** to lock the screen automatically after a selected amount of time.

DRAFT
Internal Use Only

Note: The Lock automatically function is only available if your device is already using the screen lock feature.

5. Select the **Speak passwords** field to activate this feature which reads out password information.
6. Select **Answering/ending calls** field to select the methods you can use to answer and end a call.
7. Tap **Easy touch mode** allows you to easily tap the screen to stop snooze alarms, calendar events and timers, and accept/reject incoming calls.
8. Tap **Show shortcut** allows you to press and hold  (Power/End) to use the accessibility shortcut under the Device options screen.
9. Tap **Manage accessibility** to save and update your accessibility settings or share them with another device. You can export your settings, import a previously saved file, or share your file with another device.

10. Tap **TalkBack** to activate the feature.

Note: TalkBack, when installed and enabled, speaks feedback to help blind and low-vision users.

Important! TalkBack can collect all of the text you enter, except passwords, including personal data and credit card numbers. It may also log your user interface interactions with the device.

11. Tap the **Font size** field to change the size of the fonts used on the device within menus, options, etc..
Choose from: Tiny, Small, Normal, Large, or Huge.
12. Enable **Magnification gestures** to use exaggerated gestures such as triple-tapping, double pinching, and dragging two fingers across the screen.
13. Tap the **Negative colors** field to reverse the display of on-screen colors from White text on a Black background to Black text on a White background.

DRAFT

Internal Use Only

14. Select **Color adjustment** to allow you to adjust the display colors if you are color blind and have difficulty reading the display because of the colors. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.
15. Select **Notification reminder** to allow the device to play a beep when you have unread notifications.
16. Tap **Accessibility shortcut** to allow you to quickly enable accessibility features in 2 quick steps. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.
17. Tap the **Text-to-speech options** field to configure the text to speech configuration parameters.
18. Tap the **Enhance web accessibility** field to allow apps to install scripts from Google that make their Web content more accessible.
19. Use the **Sound balance** field to allow you to use the slider to set the Left and Right balance when using a stereo device.
20. Tap the **Mono audio** field to enable stereo audio to be compressed into a single mono audio stream for use with a single earbud/earphone.
21. Tap the **Turn off all sounds** field to mute every sound made by the device during taps, selections, notifications, etc..
22. Tap the **Hearing aids** field to improve the sound quality of your device for use with hearing aids.
23. Tap **Flash notification** to allows you to set your camera light to blink whenever you receive a notification.
24. Enable the **Assistant menu** to allow you to improve the device accessibility for users with reduced dexterity. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.
25. Tap the **Press and hold delay** field to select a time interval for this action. Choose from: Short (0.5), Medium (1.0 second), Long (1.5 seconds), or Custom.

DRAFT
Internal Use Only

26. Enable **Interaction control** to allow you to enable or disable motions and screen timeout. You can also block areas of the screen from touch interaction. Touch and slide the slider to the right to turn it on. Follow the on-screen instructions.

Call Settings

To access the Call settings menu:

1. From the Home screen, tap .
 2. Press  and then tap **Call settings**.
- or —

From the Home screen, press  and then tap **Settings** →  (Device tab) → **Call**.

Configuring General Call Settings

Configure the general call settings using this option.

1. From the Home screen, press  and then tap **Settings** →  (Device tab) → **Call**.
2. Tap one of the following options:
 - **Call rejection**: allows you to manage your rejection mode and rejection list.

- **Auto reject mode**: sets the phone to automatically reject incoming calls or messages.
- **Auto reject list**: provides access to current rejection entries and numbers.
- **Set up call rejection messages**: allows you to manage both existing rejection messages and create new ones.
- **Answering/ending calls**: allows you to manage the settings for answering and ending calls.
 - **The home key answers calls** allows you to press  to answer the phone.
 - **Voice control** allows you to answer incoming voice calls using voice.
 - **The power key ends calls** allows you to press the power key to end the current call.
- **Turn off screen during calls**: allows you to force the screen to turn off during an active call.

DRAFT
Internal Use Only

- **Call alerts:** allows you to assign call alert tones and activate call alerts and vibration.
 - **Call vibrations:** vibrates the phone when the called party answers. Choose from: Answer vibration or Call-end vibration.
 - **Call status tones:** assigns sounds settings during the call. Choose from: Call connect tone, Minute minder, and Call end tone.
 - **Alerts on call:** selects whether alarm and message notification is turned off during a call.
- **Incoming call notifications:** when enabled, shows notification pop ups for incoming voice calls when the screen is on.
- **Call accessories:** allows you to assign headset settings during incoming calls.
 - **Automatic answering** configures the device to automatically answer and incoming call when a headset is detected.
 - **Automatic answering timer** configures the time delay before the device automatically accepts the incoming call.
 - **Outgoing call conditions** configures the connected Bluetooth device to make outbound calls within one of two settings: Even when device locked or Only when device unlocked.

- **Wi-Fi Calling:** Allows you to both activate/deactivate the Wi-Fi Calling feature and configure its settings. For more information, refer to “*Wi-Fi Calling*” on page 259.

Note: If the Wi-Fi Calling feature is active and connected, the Call forwarding feature is greyed-out and inaccessible.

- **Additional settings:** allows you to configure additional call settings. For more information, refer to “*Configuring Additional Voice Call Settings*” on page 283.
- **Ringtones and keypad tones:** allows you to manage your device's ringtones and vibratory features. Choose from: Ringtones, Vibrations, Vibrate when ringing, and Keypad tones (used when the keypad is pressed).
- **Personalize call sound:** allows you to enable the personalize call sound function within an active call. You can adjust the audio by enabling selecting an audio preset.
- **Noise reduction:** allows you to enable suppression of background audio.
- **Increase volume in pocket:** enables the ringtone volume to be increased when the device is in a pocket or bag.
- **Voicemail service:** allows you to assign the service.

- **Voicemail settings:** displays the settings for the voicemail.
- **Sound:** assigns your device's ringtone.
- **Vibrate:** configures the vibrate settings.
- **TTY mode:** allows you to configure the TTY settings. For more information, refer to *"TTY Mode"* on page 287.
- **Hearing Aids:** allows you to enable/disable hearing aid compatibility. For more information, refer to *"HAC Mode"* on page 288.

Call rejection

1. From the main **Call settings** page, tap **Call rejection** → **Auto reject mode** and tap one of the following options:
 - **All numbers:** to reject all calls.
 - **Auto reject numbers:** to reject all calls in your Reject list.
2. Tap **Auto reject list**.
3. Tap  to manually add numbers to the Reject list.
4. Tap **Unknown** to create a check mark and automatically reject all calls that are not in your Contacts list.

Set reject messages

1. From the main **Call settings** page, tap **Set up call rejection messages**.
2. Tap  to manually add a reject message.
— or —

Tap one of the pre-written messages to be displayed when you want the call to be rejected. You can edit the message if desired.

3. Tap **Save** to save the reject message.

Answering/ending calls

1. From the main **Call settings** page, tap **Answering/ending calls**.
2. Select any of the following options:
 - **The home key answers calls** allows you to press  to answer the phone.
 - **Voice control** allows you to answer incoming voice calls using voice.
 - **The power key ends calls** allows you to press the power key to end the current call.

DRAFT
Internal Use Only

Turn off screen during calls

This option turns on the proximity sensor during calls so that your phone will know to turn the screen off to save power.

- From the main **Call settings** page, tap **Turn off screen during calls** to create a check mark and enable the feature.

Call alerts

1. From the main **Call settings** page, tap **Call alerts**.
2. Tap **Call vibrations** to enable your phone to vibrate when the called party answers the phone.
 - Choose from: Answer vibration or Call-end vibration.
3. Tap **Call status tones** to set the sound settings during a call then tap **OK**.
 - Choose from: Call connect tone, Minute minder, and Call end tone.
4. Tap **Alerts on call** to turn off alarm and message notifications during a call.

Incoming Call Notifications

When enabled, shows notification pop ups for incoming voice calls when the screen is on.

1. From the main **Call settings** page, tap **Call alerts**.
2. Place a check mark in the **Incoming call notifications** field to activate the feature.

Accessory settings for call

1. From the main **Call settings** page, tap **Call accessories**.
2. The following options are available:
 - **Automatic answering**: configures the device to automatically answer and incoming call when a headset is detected.
 - **Automatic answering timer**: configures the time delay before the device automatically accepts the incoming call.
 - **Outgoing call conditions**: allows you to make calls even when the device is locked.

DRAFT
Internal Use Only

Wi-Fi Calling

Wi-Fi Calling is a free feature for T-Mobile customers using this device with the new SIM card. Wi-Fi Calling is an excellent solution for coverage issues in and around the home or wherever cellular coverage is limited. Minutes used while connected to the Wi-Fi network count against available rate plan minutes.

- For more information, refer to “*Wi-Fi Calling*” on page 259.

Configuring Additional Voice Call Settings

1. From the main **Call settings** page, tap **Additional settings**.
2. Tap one of the following options:
 - **Caller ID**: chooses whether your number is displayed when someone answers your outgoing call. Choose from: Network default, Hide number, or Show number.
 - **Call forwarding**: configures the forwarding settings. For more information, refer to “*Configuring Call Forwarding*” on page 283.
 - **Auto area code**: allows you to automatically prepend a specific area code to all outbound calls.

- **Call barring**: blocks specific types of calls (All outgoing calls, International calls, etc..).
- **Call waiting**: notifies you of an incoming call while you are on another call.
- **Auto redial**: automatically redial the dialed number if it is unable to connect or the call is cut off.
- **Fixed dialing numbers**: manages fixed dialing numbers.

Configuring Call Forwarding

1. From the main **Call settings** page, tap **Additional settings** → **Call forwarding**.

Important! Call Forwarding is disabled when the Wi-Fi Calling feature is enabled.

2. Tap an available option:
 - **Always forward**: incoming calls are re-routed to a secondary number that you specify.
 - **Forward when busy**: forwards all your calls to voicemail when your phone is busy.

- **Forward when unanswered:** automatically forwards to your voicemail number when the phone is not answered, and otherwise allows you to enter a voicemail number.
- **Forward when unreachable:** automatically forwards to your voicemail number when the phone is not in service, or is turned off.

Using Auto Area Code

This feature prepends an area code to all outbound calls. When enabled, the designated prefix is always added before your dialed numbers.

Ex: If you were using 999 as your area code, 555-5555 would be dialed as 999 - 555-5555.

1. From the main **Call settings** page, tap **Additional settings**.
2. Tap **Auto area code**, enter a new prefix, and then tap **OK**.

Call Barring

Configures the device to barr (prevent) selected outbound calls.

1. From the main **Call settings** page, tap **Additional settings**.
2. Tap **Call barring** and select from the available settings. Choose from: All outgoing calls, International calls, Intl' calls except home, All incoming calls, or Incoming when roaming.

Call Waiting

1. From the main **Call settings** page, tap **Additional settings**.
2. Tap **Call waiting** to enable/disable the on-screen notification of new incoming call during an active call.

Auto Redial

1. From the main **Call settings** page, tap **Additional settings**.
2. Tap **Auto redial** to automatically enable/disable the feature whereby the device redials the dialed number if it is unable to connect or the call is cut off.

DRAFT
Internal Use Only

Fixed Dialing Numbers

Fixed Dial Number (FDN), allows you to restrict outgoing calls to a limited set of phone numbers.

Enabling FDN

1. From the main **Call settings** page, tap **Additional settings** → **Fixed dialing numbers**.
2. Tap **Enable FDN**.
3. At the prompt, enter your PIN2 code and tap **OK**.

Important! Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering an incorrect PIN2 code could cause the phone to lock. Contact customer service for assistance.

Changing the PIN2 Code

1. From the main **Call settings** page, tap **Additional settings** → **Fixed dialing numbers**.
2. Tap **Change PIN2**.
3. At the prompt, enter your old PIN2 code.
4. At the prompt, enter a new PIN2 code.
5. Confirm your PIN2 code.

Important! Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering the PIN2 incorrectly three times will cause the device to lock. Contact customer service for assistance.

Managing the FDN List

When this feature is enabled, you can make calls only to phone numbers stored in the FDN list on the SIM card.

1. From the main **Call settings** page, tap **Additional settings** → **Fixed dialing numbers**.
2. Tap **Enable FDN**.
3. At the prompt, enter your PIN2 code and tap **OK**. FDN is enabled.
4. Tap **FDN list** then press  and then tap **Add contact** or edit the contacts that were stored.

Important! Not all SIM cards use a PIN2 code. If your SIM card does not, this menu does not display.

The PIN2 code is provided by your carrier. Entering the PIN2 incorrectly three times will cause the device to lock. Contact customer service for assistance.

Ringtones and keypad tones

1. From the main **Call settings** page, tap **Ringtones and keypad tones**.
2. Tap **Ringtones**, select a ringtone, and tap **OK**.
 - Tap **Add** to locate an audio file to create as a ringtone.
3. Tap **Vibrations**, select a vibration type, and tap **OK**.
 - Tap **Create** to begin creating your own custom vibration.
4. Tap **Vibrate when ringing** to create a check mark if you want your phone to vibrate when a call is incoming.
5. Tap **Keypad tones** to create a check mark if you want tones to play when the keypad is pressed.

Personalize call sound

This option allows you to personalize the sounds you hear during a call with and without earphones.

- From the main **Call settings** page, tap **Personalize call sound** and activate the feature by selecting an available option.

For more information, refer to “*Personalizing the Call Sound Setting*” on page 65.

Noise reduction

This option allows you to suppress background noise during a call.

- From the main **Call settings** page, tap **Noise reduction** to create a check mark and enable the feature.

Increase volume in pocket

This option increases the ringtone volume when the device is in a pocket or a bag. It uses the proximity sensor to detect its location.

- From the main **Call settings** page, tap **Increase volume in pocket** to create a check mark and enable the feature.

DRAFT
Internal Use Only

Voicemail

You can view your voicemail number from this menu.

1. From the main **Call settings** page, tap **Voicemail service**.
2. If an additional voicemail service is in use (other than carrier), tap **Voice settings** to now view your selected voicemail number and information.

Sound - Device Ringtone

This option allows you to assign your default device ringtone.

1. From the main **Call settings** page, tap **Sound**.
2. Select a ringtone and tap **OK**.

Vibrate

This option allows you to activate a vibration for an incoming call.

- From the main **Call settings** page, tap **Vibrate** field to toggle the feature on or off.

TTY Mode

A TTY (also known as a TDD or Text Telephone) is a telecommunications device that allows people who are deaf, hard of hearing, or who have speech or language disabilities, to communicate by telephone.

Your device is compatible with select TTY devices. Please check with the manufacturer of your TTY device to ensure that it is compatible with digital cell phones.

Your phone and TTY device will connect via a special cable that plugs into your phone's headset jack. If this cable was not provided with your TTY device, contact your TTY device manufacturer to purchase the connector cable.

1. From the main **Call settings** page, tap **TTY mode**.
2. Tap **TTY Full**, **TTY HCO**, or **TTY VCO** to activate the feature, or **TTY Off** to deactivate the feature. Off is the default setting.

DRAFT

Internal Use Only

HAC Mode

This menu is used to activate or deactivate Hearing Aid Compatibility for this device.

1. From the main **Call settings** page, tap **Call settings**.
2. Tap the **Hearing aids** field to activate the feature (green check mark), or tap it again to deactivate the feature. Off is the default setting.

Blocking Mode

When Blocking mode is enabled, notifications for selected features will be disabled. You will only receive notifications of incoming calls from people on your allowed list.

1. From the Home screen, press  and then tap **Settings** →  (Device tab).
2. In a single motion touch and slide the **Blocking mode** slider to the right to turn it on.
Confirm the Blocking mode active icon  appears in the Status bar.
3. Place a green check mark adjacent to those features you would like to enable. Choose from: Disable incoming calls, Disable notifications, Disable alarm and timer, Disable LED indicator.

4. Configure a timeframe for these features to be active. Remove the check mark from the **Always** field to configure the **From** and **To** time fields.
5. Tap **Allowed contacts** to assign those contacts that are exempted from these rules. Choose from None, All contacts, Favorites, or Custom. Allowed contacts will then appear in the **Allowed contact list**.

Language and Input Settings

This setting allows you to configure the language in which to display the menus. You can also set on-screen keyboard options.

- From the Home screen, press  and then tap **Settings** →  (Controls tab) → **Language and input**.

Language Settings

To set the language that the menus display on the phone:

1. From the main **Settings** page, tap **Controls** tab → **Language and input** → **Language**.
2. Select a language and region from the list.

Choose Input Method

1. From the main **Settings** page, tap **Controls** tab → **Language and input** → **Default**.
2. Select an input method.
 - or –Tap **Set up input methods** to alter/modify the available input methods.

Samsung Keyboard Settings

1. From the main **Settings** page, tap **Controls** tab → **Language and input** → **Samsung keyboard**.

– or –

From within an active text entry screen, touch and hold



(**Input Methods**), drag across the icons, and select  (**Settings**) to reveal the **Samsung keyboard settings** screen.

2. Set any of the following options:
 - **Input languages** sets the input language. Tap a language from the available list. The keyboard is updated to the selected language.
 - **Predictive text** enables predictive text entry mode. This must be enabled to gain access to the advanced settings. Touch and hold to access the advanced settings.
 - **Auto replacement** automatically completes or replaces the current word with the most probable word match after tapping the space bar or entering a punctuation mark.
 - **Auto capitalization** automatically capitalizes the first letter of the first word in each sentence (standard English style).
 - **Auto spacing** automatically inserts space between words.

- **Auto punctuate** automatically inserts a full stop in a sentence by tapping the space bar twice when using the on-screen QWERTY keyboard.
- **Keyboard swipe**: allows you to combine the Samsung keyboard with an additional input method choose from:
 - **None** leaves text input as only via the on-screen keyboard.
 - **SwiftKey Flow** like using Swipe, allows you to enter text by sliding your fingers across the on-screen keyboard. This feature is optimized for use with the on-screen QWERTY keyboard.
 - **Cursor control** when enabled, allows you to control your on-screen cursor by moving your finger across the keyboard.
- **Key-tap feedback** provides feedback functions to be enabled such as:
 - **Sound** enables auditory feedback when you tap an on-screen key.
 - **Vibration** enables vibration feedback when you tap an on-screen key.
 - **Character preview** provides an automatic preview of the current character selection within the text string. This is helpful when multiple characters are available within one key.
- **Moe settings** provides access to additional access to more settings.
 - **Pen detection** enables the device to automatically switch to handwriting mode when the S Pen is detected.
 - **Help** launches a brief on-screen help tutorial covering the main concepts related to the Samsung keyboard.
 - **Reset settings** resets the keyboard settings back to their original configuration.

DRAFT
Internal Use Only

Predictive Text - Advanced Settings

The predictive text system provides next-letter prediction and regional error correction, which compensates for users pressing the wrong keys on QWERTY keyboards.

Note: Only available when ABC mode is selected. Predictive text advanced settings are available only if the Predictive function is enabled.

1. From the main **Settings** page, tap **Controls** tab → **Language and input** → **Samsung keyboard**.
— or —
From within an active text entry screen, touch and hold  (Input Methods) →  to reveal the **Samsung keyboard settings** screen.
2. In a single motion touch and slide the **Predictive text** slider to the right to turn it on.
3. Tap the **Predictive text** field and configure any of the following advanced options:
 - **Live word update** allows the device to automatically update its word database with popular new words every day.

- **Personalized data** activate this feature to use the personal language data that you have entered and selected to make your text entry prediction results better. By enabling this feature you can choose from the following personalization features:
- **Learn from Facebook** allows you to log into your current Facebook account and add used text to your personal dictionary.
- **Learn from Gmail:** allows you to sign in to your existing Gmail account from where your style and existing contact information is added to your personal dictionary. Helps recognize familiar names.
- **Learn from Twitter** allows you to sign into your existing Twitter account and add used text to your personal dictionary.
- **Learn from Messages** allows your device to learn your messaging style by using your Messaging information.
- **Learn from Contacts** updates predictive style by learning your Contacts style.
- **Clear remote data** allows you to delete your anonymous data stored on the personalization server.
- **Clear personal data** removes all personalized data entered by the user.

- **Privacy** displays on-screen privacy information.

4. Press  to return to the previous screen.

Configure Google Voice Typing

1. From the main **Settings** page, tap **Controls** tab → **Language and input**.

– or –

From a screen where you can enter text, in a single motion, touch and drag the Status bar down to the bottom of the screen, then select  (**Select input method**) → **Set up input methods**.

2. Tap  (adjacent to the **Google voice typing** field).
3. Select a language by tapping **Choose input languages** area.
4. Remove the check mark from the **Automatic** field. This allows you to select additional languages.
5. Select the desired languages.
6. Activate **Block offensive words** to block recognition of known offensive words or language. (A blue check mark indicates the feature is active).

7. Tap **Download offline speech recognition** to enable speech recognition via locally stored files so that even if you are not connected to a network you can still use the service.

Handwriting Language Search

1. From the main **Settings** page, tap **Controls** tab → **Language and input** → **Language**.
2. Select an available language.

DRAFT
Internal Use Only

Configuring Voice Input Recognition

This feature allows the device to correctly recognize verbal input.

1. From the main **Settings** page, tap **Controls** tab → **Language and input**.
2. Tap **Voice search** to configure the following:
 - **Language**: choose a language for your voice input.
 - **Speech output**: Sets whether you will use speech output always or only when using hands-free.
 - **Block offensive words**: enable or disable blocking of recognized offensive words from the results of your voice-input Google searches.
 - **Hotword detection**: enable to being able to launch voice search by saying the word “Google”.
 - **Download offline speech recognition**: enables voice input while offline.
 - **Personalized recognition**: enables the improvement of speech recognition accuracy.
 - **Google Account dashboard**: allows you to manage your collected data.

- **Bluetooth headset**: records audio through a connected Bluetooth headset.

3. Press  to return to the previous screen.

Configuring Text-to-speech

This feature allows the device to provide a verbal readout of on-screen data such as messages and incoming caller information. This action is called TTS (Text To Speech).

1. From the main **Settings** page, tap **Controls** tab → **Language and input** → **Text-to-speech options**.
2. Select a current Preferred TTS engine from the list of available options. Select **Samsung text-to-speech engine** or **Google Text-to-speech Engine**. The default is Samsung text-to-speech options.
3. Tap  next to the preferred TTS engine configure the following settings:
 - **Language**: allows you to set the language for spoken text.
 - **Settings for Google Text-to-speech Engine**: allows you to view Open Source Licenses.
 - **Settings for Samsung text-to-speech engine**: allows you to configure the General settings for the Samsung TTS.

- **Install voice data:** allows you to install voice data for speech synthesis.
4. Configure the General options to alter the settings associated with this feature:
 - **Speech rate:** adjusts the rate at which on-screen text is spoken by the device. Choose from: **Very slow**, **Slow**, **Normal**, **Fast**, and **Very fast**.
 - **Listen to an example:** plays a short example of what the text-to-speech feature sounds like on your device when activated.

Configuring the Mouse-TrackPad

This feature allows you to configure the pointer speed for a connected mouse or trackpad.

1. From the main **Settings** page, tap **Controls** tab → **Language and input** → **Pointer speed**.
2. Adjust the slider and tap **OK**.

Voice control

The Voice control settings allow you to set up voice commands to control your device.

1. From the Home screen, press  and then tap **Settings** →  (**Controls** tab) → **Voice control**.
2. Verify the feature is active by tapping  at the top of your screen to activate Voice control.
3. The following options are available. Tap an option to create a checkmark and activate the feature.
 - **Incoming calls:** allows you to answer or reject calls using the commands **Answer** and **Reject**.
 - **ChatON:** allows you to answer or reject calls using the commands **Answer** and **Reject**.
 - **Alarm:** allows you to stop or snooze an alarm by using the commands **Stop** and **Snooze**.
 - **Camera:** allows you to take pictures using the voice commands **Smile**, **Cheese**, **Capture**, or **Shoot**.
 - **Music:** allows you to control your Music player using the voice commands **Next**, **Previous**, **Pause**, **Play**, **Volume Up**, and **Volume Down**.

DRAFT
Internal Use Only

Note: If you set the alert type for calls or alarms to vibration, voice control will not be available.

Hands-free Mode

When enabled, alarm and information will be read aloud.

1. From the Home screen, press  and then tap **Settings** →  (Controls tab) → **Hands-free mode**.
2. Tap  to turn the mode **ON**.
3. Touch **Driving mode** for options:
 - **Incoming call:** read out callers' information when receiving incoming calls.
 - **ChatON:** read out callers' information when receiving incoming ChatON calls.
 - **Air call-accept:** wave your hand over the screen to accept incoming calls.
 - **Message:** read out senders' information when receiving incoming calls.
 - **Alarm:** read out alarm information when alarms sound.
 - **Schedule:** read out scheduled alarm information when alarms sound.

When this option is enabled,  displays in the Status Bar.

S Pen Settings

This menu allows you to customize settings for the S Pen.

1. From the main **Settings** page, tap **S Pen**.
2. The following options are available:
 - **Turn off pen detection:** allows you to deactivate pen detection
 - **S Pen keeper:** allows to enable a a sound alert and on-screen notification when you walk around with the device without the pen inserted in its slot.
 - **Pointer:** allows you to activate the ability to show the pointer when you hover the S Pen over the screen.
 - **Direct pen input:** displays the handwriting pad within the text input area when the S Pen is detected.
 - **Pen detachment options:** allows you activate a selected action when the device detects the S Pen is detached. Choose from: None, Action Memo, or Air command.
 - **Pen attach/detach sound:** allows you to select a sound to be played whenever the pen is attached or detached.

One-Handed Operation

This feature can be used to customize screen display and input for use with one hand.

1. From the Home screen, press  and then tap **Settings** →  (Controls tab) → **One-handed operation**.
2. Select or activate any of the following:
 - **Use for all screens:** configures selected options for all available screens. This feature adjusts the scale and position of all screens by swiping the edge of the current screen.
 - **Hand adaptive mode:** allows you to set up the device to be oriented for either left -handed or right-handed use.
 - Activate the feature.
 - Hold the device in either your left or right hand and move your thumb in the opposite direction across the screen to make the configuration.
 - **Keypad and in-call buttons:** activate the feature to adjust the position of the dialing keyboard and in-call buttons for one-handed operation.
 - **Samsung keyboard:** activate the feature to adjust the position of the Samsung keyboard for one-handed operation.

- **Calculator:** activate the feature to adjust the position of the Samsung calculator for one-handed operation.
- **Unlock pattern:** activate to adjust the scale of the unlock pattern screen for use with one hand.
- **Tutorial:** provides an on-screen tutorial for the use of these one-handed features/functions.

Motions and Gestures Settings

This feature allows you to assign specific functions to certain phone actions that are detected by both the accelerometer and gyroscope.

Caution! Excessive shaking or impact to the device may cause unintended results. To learn how to properly control motions, tap  (**Apps**) → **Settings** → **Controls** tab. When tapped, each entry comes with an on-screen tutorial.

- From the Home screen, press  and then tap **Settings** →  (**Controls** tab).
 - **Air gesture:** allows you to control your device by performing motions above the sensor (without touching the device).
 - **Air view:** displays helpful information when you hover your finger over the screen.
 - **Air command:** allows you to activate or deactivate the Air command function that appears on-screen once you remove the S Pen from its internal slot.
 - **Motions:** allows you to control your device using natural movements (on the screen).

- **Palm motion:** allows you to control your device by touching the screen with your entire hand.
- **Smart screen:** allows you to control your device by using intelligent face detection features such as: Smart stay, Smart rotation, Smart pulse, and Smart scroll.
- **High touch sensitivity:** allows you to increase the screen's touch sensitivity.

To activate Air gesture:

1. From the main **Settings** page, tap **Controls** tab.
2. In a single motion touch and slide the **Air gesture** slider to the right to turn it on.
If the feature is available for your selected action, an Air gesture icon  will appear in the status bar.
3. Read the on-screen notification and tap **OK**.

Note: At least one feature must be activated before Air gesture can be activated.

4. Tap **Learn about sensor and icon** field to review on-screen information about the Air gestures sensor and related icon.

5. In a single motion, slide a feature's activation slider to the on position.

The following is a description some of the most commonly used gestures:

- **Quick glance:** Once enabled, you can move your hand over the air gesture sensor (located above the on-screen clock at the upper-right) to temporarily activate preview window that can be used to display selected user-enabled information such as: Time & Date, Notification icons, Missed calls, etc..
- **Air jump:** Once enabled, you can move your hand over the air gesture sensor (up or down) and easily jump to either the top or bottom of a lengthy display page (ex: Internet or Email).
- **Air browse:** Once enabled, you can move your hand over the air gesture sensor (left or right) and easily move to either the previous or next item in a series (ex: music tracks, pictures, or pages).
- **Air move:** Once enabled, you can move use one finger to hold down on an app shortcut or event entry and then swipe across the air gestures sensor to then move it to a new a different page.
- **Air call-accept:** Once enabled, you can simply wave your hand over the air gesture sensor to accept any incoming call.

To activate Air View:

With the Air view feature, you can hover your finger over the screen and Air view features will be displayed. For example, you can hover your finger over a scheduled item in your calendar to see more details.

1. From the main **Settings** page, tap **Controls** tab.
2. In a single motion touch and slide the **Air view** slider to the right to turn it on.
3. Tap the **Air view mode** field to select the method used to activate the feature. Choose from Pen, Finger, or Auto.
4. Tap the **Air view pen options** field and configure the available options:
 - **Information preview:** allows you to see information previews, extended text, and enlarged images when you hover your finger over the screen.

Note: It is recommended that the Information preview function be enabled if using Air view.

- **Progress preview:** allows you to preview a scene or show elapsed time when you hover your finger over the progress bar while watching a video.
 - **Speed dial preview:** allows you to see the contacts and their speed dial numbers when you hover your finger over them in your contacts list.
 - **Icon labels (by pen nib):** activate the ability to hover over an icon and display an on-screen pop up description.
 - **List scrolling:** allows you to enable the ability to scroll up and down a screen by holding the S Pen over the edge of the screen.
 - **Sound and haptic feedback:** allows you to play sound and feel vibration when you hover your finger over Air view items.
5. When enabled via the Air view mode menu, tap the **Air view finger options** field and configure the available options.
 6. In a single motion touch and slide the **Air command** slider to the right to turn it on. When active, you can press the button on the S Pen while hovering over the screen to view an on-screen contextual menu.

To activate Air Command:

With the Air command feature active, the Air Command button toolbar appears once you remove the S Pen from its slot. This toolbar allows you to quickly activate frequently used applications or actions.

1. From the main **Settings** page, tap **Controls** tab.
2. In a single motion touch and slide the **Air command** slider to the right to turn it on.

DRAFT
Internal Use Only

To activate Motion:

1. From the main **Settings** page, tap **Controls** tab.
2. In a single motion touch and slide the **Motions** slider to the right to turn it on.
3. Read the on-screen notification and tap **OK**.

Note: At least one feature must be activated before Motion can be activated.

4. In a single motion, slide a feature's activation slider to the on position.

The following is a description some of the most commonly used gestures:

- **Direct call:** Once enabled, the device will dial the currently displayed on-screen Contact entry as soon as you place the device to your ear.
- **Smart alert:** Once enabled, pickup the device to be alerted and notified of you have missed any calls or messages.
- **Zoom:** Once enabled, you must be on a screen where content can be zoomed. In a single motion, touch and hold two points on the display then tilt the device back and forth to zoom in or out.

- **Browse an image:** Once enabled, touch and hold a desired on-screen image to pan around it. Move the device left or right to pan vertically or up and down to pan horizontally around the large on-screen image.
- **Mute/pause:** Once enabled, mute incoming calls and any playing sounds by turning the device display down on a surface. This is the opposite of the Pickup to be Notified Gesture.

To activate Palm Motion:

1. From the main **Settings** page, tap **Controls** tab.
2. In a single motion touch and slide the **Palm motion** slider to the right to turn it on.
3. Read the on-screen notification and tap **OK**.


Note: At least one feature must be activated before Palm motion can be activated.

4. In a single motion, slide a feature's activation slider to the on position.

The following is a description some of the most commonly used gestures:

- **Capture screen:** Once enabled, you can capture any on-screen information swiping across the screen. In a single motion, press the side of your hand on the screen and swipe from left to right. The image is then copied to the clipboard.

Palm Swipe to
Screen Capture



- **Mute/pause:** Once enabled, you can pause any on-screen video or mute any current sound by simply covering the screen with your hand. Once you remove your hand from the screen, the device goes back to normal by either continuing to play the current video or unmuting the current sound.

To activate Smart Screen:

The Smart screen options allow you to customize your screen settings to make the screen more responsive and easier to use.

1. From the main **Settings** page, tap **Controls** tab.
2. In a single motion touch and slide the **Smart screen** slider to the right to turn it on.
3. Tap any of the following options to create a checkmark and activate the features:
 - **Smart stay:** disables the screen timeout if your phone detects that your face is watching the screen.
 - **Smart rotation:** disables the auto screen rotation by checking the orientation of your face and the device.
 - **Smart pause:** pauses videos when your device detects that your head has moved away from the screen.
 - **Smart scroll:** once your eyes have been detected, the screen will scroll according to your device's tilt angle. Tap the adjacent field to the right of the Smart scroll field to activate the feature. With Smart scroll, the screen will scroll depending on the phone's tilt angle once your eyes have been detected.

DRAFT
Internal Use Only

To activate High Touch Sensitivity:

Activating this feature allows you to increase the screen's sensitivity to touching while wearing gloves.

1. From the main **Settings** page, tap **Controls** tab.
2. Place a check mark alongside the **High touch sensitivity** field to turn it on.

Add Account

This menu allows you to set up, manage, and synchronize accounts, including your Google and email accounts.

Adding an Account

1. From the Home screen, press  and then tap **Settings** →  (General tab) → **Accounts**.
2. Navigate to the **My accounts** area and then tap **Add account** and select one of the account types.
3. Use the keyboard and follow the prompts to enter your credentials and set up the account.
4. A green circle will appear next to the account type once you have created an account. Your email account will also be displayed in the **Accounts** section of the main Settings menu.

Removing an Account

Important! Removing an account also deletes all of its messages, contacts, and other data from the device.

1. From the Home screen, press  and then tap **Settings** → **General** tab → **Accounts**.
2. Navigate to the **My accounts** area and then tap the account name.
3. From the Accounts area of the screen, tap the account entry.
4. Tap **Remove account**, then tap **Remove account** at the prompt to remove the account and delete all its messages, contacts, and other data.

DRAFT
Internal Use Only

Synchronizing a Accounts

By default, all managed accounts are synchronized. You can also manually sync all current accounts.

1. From the Home screen, press  and then tap **Settings** → **General** tab → **Accounts**.
2. Navigate to the **My accounts** area and then tap the account name.
3. Tap the account name entry.
4. Tap **Sync now** to synchronize your account or tap **Sync all** to synchronize all your accounts. Tap **Cancel sync** to stop the synchronization.
5. Tap **Settings** to access your account settings.

Creating a Samsung Account

Just as important as setting up and activating a Google account to help provide access to Play Store, etc.. An active Samsung account is required to begin accessing applications such as Samsung Hub.

Note: The Samsung account application will manage your access to the previously mentioned applications, and there is no longer a need to remember different passwords for each application.

1. From the Home screen, press  and then tap **Settings** →  (**General** tab).
2. Navigate to the **Accounts** area and then tap **Add account** → **Samsung account**.
3. If you have previously created a Samsung account, tap **Sign in**.

– or –

If this is your first time, tap **Create new account**.

DRAFT
Internal Use Only

4. Follow the on-screen instructions.

Note: You may be prompted to confirm your credentials via email.

5. If prompted, follow the on-screen instructions to verify your account via the provided email address.

Note: Without confirming your email address and following the documented procedures, related applications will not function properly since it is Samsung account that is managing their username and password access.

Cloud

This feature allows you to use your external cloud storage solution to both synchronize your device to your Samsung account and then backup that local content to the cloud.

Your device comes with a built-in Cloud storage solution known as Dropbox.

Important! This feature requires an active Wi-Fi connection prior to use.

1. Log into your Samsung account and verify it is active. For more information, refer to “*Creating a Samsung Account*” on page 303.
2. Log into your external cloud storage solution. In our case we are using a Dropbox account. For more information, refer to “*Dropbox*” on page 159.
3. From the Home screen, press  and then tap **Settings** →  (General tab) → **Cloud**.
4. Confirm your Samsung account appears at the top of the screen.

DRAFT

Internal Use Only

5. Tap **Sync settings**, select which device parameters will be synched, and tap **Sync now**. Choose from: Sync Calendar, Sync Contacts, Sync Internet bookmarks, Sync Internet opened pages, and Sync Memo.
6. Tap **Backup or Restore** to launch the feature.
 - **Backup**: manually loads up the currently selected categories and backs up the data to your cloud storage location. Tap **Backup** to begin the manual backup process.
 - **Restore**: allows you to retrieve your previously backed up data from your Samsung account and then download it to your device.

Backup and Reset

Location settings, backup configurations, or reset the phone to erase all personal data.

- From the Home screen, press  and then tap **Settings** →  (General tab) → **Backup and reset**.

Mobile Backup and Restore

The device can be configured to back up your current settings, application data and settings.

1. From the main **Settings** page, tap **Accounts** tab → **Backup and reset**.
2. Tap **Back up my data** to create a backup of your current phone settings and applications.
3. Tap **Backup account** to assign the account being backed up.
4. Tap **Automatic restore** to assist in the re-installation of a previously installed application (including preferences and data).
5. Tap **Factory data reset** to reset your device and sound settings to the factory default settings. For more information, refer to “*Factory Data Reset*” on page 309.
6. Tap **Collect diagnostics** to collect diagnostic data for troubleshooting use. For more information, refer to “*Collect Diagnostics*” on page 309.

DRAFT
Internal Use Only

Backing up Your Data Before Factory Reset

Backing Up Your Contacts using an SD card

Before initiating a factory reset, it is recommended that you backup your personal data prior to use.

Important! If you choose to back up contacts to your SIM card, all information other than name and number is lost. Therefore, it is recommended that you back up contacts to your SD card.

To export a Contact list to your microSD card:

1. From the Home screen, tap  (**Contacts**).
2. Press  and then tap **Import/Export**.
3. Tap **Export to SD card** → **OK**. The contacts will be stored in a .vcf file on your SD card.

For more information, refer to “*Export/Import*” on page 93.

To copy contacts from an SD card back to your device:

1. From the Home screen, tap  (**Contacts**).
2. Press  and then tap **Import/Export** → **Import from USB storage**.
3. At the Save contact to prompt, tap **Device**. The contacts on the SD card are copied to your phone.

Backing Up Media to your PC

You can back up your pictures, videos, documents, and other media to your PC. You can connect your device to a PC as a removable disk and copy files back and forth between your phone and PC. If you insert an SD card in the device, you can also access the files directory from the SD card by using your device as a memory card reader.

1. Connect the USB cable to your device, then connect the cable to your PC USB port. After a few seconds, a pop-up window displays on the PC when it is connected with your device.
2. On the PC pop-up, click Open device to view files.
3. Verify your device appears as a removable disk on your PC. Once connected, you can access the Phone folder (internal phone memory) and the Card folder (SD card).

DRAFT
Internal Use Only

4. Select the location where the files are that you would like to copy to your PC (Phone or Card).
5. Select the folders where the information is kept. This would include folders such as DCIM (camera pictures and videos), Pictures, Music, Playlists, Download, etc.
6. Select the files that you want to copy and copy them (Control C - copy) to a folder on your PC (Control V - paste).
7. Disconnect the USB cable from your phone and the PC.
8. To copy files on your PC back to your phone, simply reverse the procedure.

Verify your images and videos are on your microSD card:

1. From the Home screen, tap  (Apps) →  (Gallery).
2. Verify the Gallery contains all of your pictures and videos.
3. Remove both the back cover and remove the internal microSD card prior to initiating the process.

Backing Up Media to your SD card

You can back up your pictures, videos, documents, and other media to your SD card.

1. From the Home screen, tap  (Apps) →  (Samsung) →  (My Files).
2. Select the folder where the files are that you would like to copy to the SD card. This would include folders such as DCIM (camera pictures and videos), Pictures, Music, Playlists, Download, etc. For example, tap  (Apps) →  (Samsung) →  (My Files) → Images → Camera.
3. Tap the files that you want to copy to create a checkmark in the box next to the filename.
4. Tap the options icon in the top right corner of the display.
5. Select **Copy → SD memory card**.
6. Go to the folder on your SD card where you would like to copy to files to. For example, Pictures.
7. Tap Paste here in the top right corner of the display.
8. The files are copied to the folder.

DRAFT
Internal Use Only

Backing Up Internet Bookmarks to your Samsung Account

You can back up your Internet bookmarks by using your Samsung account. Only bookmarks you have added (non-default) can be backed up.

1. From the main **Settings** page, tap **General** tab → **Account**.
2. Navigate to the **My accounts** area and then tap **Add account** and select **Samsung account**.
3. Sign in to your Samsung account or tap **Create new account** if you don't have one yet. Follow the on-screen instructions.
4. From the Home screen, tap  (**Apps**) →  (**Samsung**) →  (**Internet**).
5. From the webpage, tap  (**Bookmarks**).
6. Press  and then tap **Move to folder**.
7. Place a checkmark on those Bookmarks you want to back up, then tap **Done**.
8. Select a location or folder. The Bookmarks that you moved are now listed under the Samsung account heading in your Bookmark list.

9. When you get a new phone, update your software, or reset your device, sign in to your Samsung account and the backed up bookmarks will be displayed on your Bookmarks page under the Samsung account heading.

Backing Up Settings to Google

You can use your Google account to back up apps, Wi-Fi passwords, and other data.

1. From the Home screen, tap  (**Apps**) →  (**Google**) →  (**Gmail**).
2. Tap **Existing** if you have a Google account. The Inbox loads conversations and email.
– or –
Tap **New** if you do not have a Google account.
3. Confirm that immediately after signing in to your Google account, the Backup and restore screen is displayed.
4. From within the Backup and restore screen, tap the checkbox next to **Keep this phone backed up with my Google Account** field.
5. From the main **Settings** page, tap **Accounts** tab → **Backup and reset**.

6. Tap **Back up my data** to create a checkmark. This will back up your app data, Wi-Fi passwords, and other settings.
7. Your Google account should be listed under the Backup option. If not, Tap **Backup account → Add account** and sign into your Google account.
8. Tap the checkbox next to **Automatic restore** to create a checkmark. This will restore the settings that were backed up when you re-install an application.

Factory Data Reset

From this menu you can reset your device and sound settings to the factory default settings.

1. From the main **Settings** page, tap **General tab → Backup and reset → Factory data reset**.
2. Read the on-screen reset information.
3. Tap **Reset device**.
4. If necessary, enter your password and tap **Delete all**. The device resets to the factory default settings automatically and when finished displays the Home screen.

Collect Diagnostics

This feature only collects diagnostic data for troubleshooting use.

1. From the main **Settings** page, tap **General tab → Backup and reset → Collect diagnostics**.
2. Read the on-screen System Manager Application information.

Note: This software collects only diagnostic data from your device so that T-Mobile technicians can better troubleshoot issues with your device.

3. Choose to enable or disable the feature by placing a check mark in the **Allow Diagnostics** field.
4. Select either **More Info...** (to read additional information) or **Close** to close the message screen.

Important! Selecting **Close** only closes the current description screen and does not disable data collection. To disable data collection, go to **Settings → Back up and reset → Collect diagnostics** and turn off the **Allow Diagnostics** feature.

Date and Time

This menu allows you to change the current time and date displayed.

1. From the Home screen, press  and then tap **Settings** →  (General tab) → **Date and time**.
2. Tap **Automatic date and time** to allow the network set the date and time.

Important! Deactivate **Automatic date and time** to manually set the rest of the options.

3. Tap **Set date** and use the plus or minus icons to set the **Month**, **Day**, and **Year** then tap **Set**.
4. Tap **Set time** and use the plus or minus icons, set **Hour**, and **Minute**. Tap **PM** or **AM**, then tap **Set**.
5. Tap **Automatic time zone** to allow the network set the time zone information automatically.
6. Tap **Select time zone**, then tap a time zone.
7. Tap **Use 24-hour format**. If this is not selected the device automatically uses a 12-hour format.
8. Tap **Select date format** and select the date format type.

Accessory

This menu allows you to select the Audio output mode when using a car or desk dock.

1. From the Home screen, press  and then tap **Settings** →  (General tab) → **Accessory**.
2. Tap **Dock sound** to play sounds when inserting or removing the phone from the dock.
3. Tap **Audio output mode** to use the external dock speakers when the phone is docked.
4. Tap **Desk home screen display** if you wish to show the desk home screen when the device is docked.
5. Tap **Automatic unlock** if you are using a phone cover and you want your phone to unlock when you open the cover.
6. Tap **Audio output** to set your Audio output to Stereo or Surround.

Application Manager

This device can be used for Android development. You can write applications in the SDK and install them on this device, then run the applications using the hardware, system, and network. This feature allows you to configure the device for development.

Warning! Because the device can be configured with system software not provided by or supported by Google or any other company, end-users operate these devices at their own risk.

This menu allows you to manage installed applications. You can view and control currently running services, or use the device for application development.

You can also view the amount of memory or resources used as well as the remaining memory and resources for each of the applications on your phone and clear the data, cache, or defaults.

- From the Home screen, press  and then tap **Settings** →  (General tab) → **Application manager** → **ALL**.

Clearing Application Cache and Data

Important! You must have downloaded applications installed to use this feature.

1. From the main **Settings** page, tap **General** tab → **Application manager**.
2. Tap an application in which to clear the cache or data.
3. Tap **Force stop**, **Uninstall**, **Clear data**, **Clear cache**, or **Clear defaults**.

Uninstalling Third-party Applications

Important! You must have downloaded applications installed to use this feature.

1. From the main **Settings** page, tap **General** tab → **Application manager**.
2. Tap the **DOWNLOADED** tab and select your desired application.
3. Tap **Uninstall** (from within the top area of the Application info page).
4. At the prompt, tap **OK** to uninstall the application.

5. Select a reason for uninstalling the application, then tap **OK**.

Memory Usage

See how memory is being used by Downloaded or Running applications.

1. From the main **Settings** page, tap **General** tab → **Applications manager**.
2. Tap **DOWNLOADED**, **RUNNING**, or **ALL** to display memory usage for that category of applications.

The graph at the bottom of the Downloaded tab shows used and free device memory. The graph at the bottom of the Running tab shows used and free RAM.

Downloaded

Displays apps you have downloaded onto your device.

1. From the main **Settings** page, tap **General** tab → **Applications manager**.
2. Tap the **DOWNLOADED** tab to view a list of all the downloaded applications on your device.
3. To switch the order of the lists displayed in the Downloaded tabs, press  and select **Sort by size** or **Sort by name**.

4. Tap an application to view and update information about the application, including memory usage, default settings, and permissions.

Running Services

The Running services option allows you to view and control currently running services such as Backup, Google Hangouts, SNS (messaging), Swype, and more.

1. From the main **Settings** page, tap **General** tab → **Application manager**.
2. Tap the **RUNNING** tab to view all currently active and running applications. This tab also shows the total RAM being used by these currently active applications.
3. Tap a process and select **Stop** to end the process and stop it from running. When you stop the process the service or application will no longer run until you start the process or application again.
4. Tap **Show cached processes** to view additional cached applications.

Important! Stopping a process might have undesirable consequences on the application.

Storage Used

This option allows you to view a list (on the current tab) of current applications as sorted by size.

1. From the main **Settings** page, tap **General** tab → **Application manager**.
2. Tap the **ALL** tab to display all available applications.
3. Press  and then tap **Sort by size** to change the current list to show items based on the amount of storage they occupy.

Reset App Preferences

This feature provides you with the ability to reset all preferences for the following features: Disabled apps, Disabled app notifications, Default applications for actions, and Background data restrictions.

1. From the main **Settings** page, tap **General** tab → **Applications manager**.
2. Tap the **ALL** tab to display all available applications.
3. Press  and then tap **Reset app preferences** → **Reset apps**.

Important! As an example, if you assigned your browser to always launch YouTube links and want that changed, you must reset the default actions.

Battery Usage

This option allows you to view a list of those components using battery power. The amount of time the battery was used also displays. Battery usage displays in percentages per application.

1. From the Home screen, press  and then tap **Settings** →  (**General** tab) → **Battery**. The battery level displays in percentage.
2. From the upper-right tap  (**Refresh**) to update the list.
– or –
Tap an entry to view more detailed information.

Note: Other applications may be running that affect battery use.

Internal Use Only

Power Saving Mode

This feature allows you both automatically set the phone to use a power saving mode and configure additional power saving options manually, all in an effort to conserve battery power.

1. From the Home screen, press  and then tap **Settings** →  (General tab) → **Power saving mode**.
2. In a single motion touch and slide the slider to the right to turn it on.
3. Tap the following options to create a check mark and conserve power:
 - **CPU power saving**: allows you to limit the maximum performance of the CPU.
 - **Screen power saving**: allows you to lower the screen power level.
 - **Turn off haptic feedback**: allows you to turn off vibration when you tap or touch the screen.
4. Tap **Learn about Power saving mode** to learn about various ways to conserve battery power.

When the power gets low, confirm  appears at the top of the screen. This indicates the power saving mode is active.

SD Card & Device Storage

From this menu you can view the memory allocation for the memory card as well as mount or unmount the SD card.

- microSD memory cards include capacities of up to 4GB.
- microSDHC™ memory card types can range from 4GB to up to 32GB.
- microSDXC™ memory card types can include capacities greater than 32GB.

To view the memory allocation for your external SD card:

- From the Home screen, press  and then tap **Settings** →  (General tab) → **Storage**.
The available memory displays under the Total space and SD card headings.

Important! DO NOT remove a microSD card while the device is accessing or transferring files. Doing so will result in loss or damage of data. Make sure your battery is fully charged before using the microSD card. Your data may become damaged or lost if the battery runs out while you are using the microSD card.

Mounting the SD Card

To store photos, music, videos, and other applications. You must mount (install) the SD card prior to use. Mounting the SD card establishes a USB connection with your computer.

1. From the main **Settings** page, tap **General** tab → **Storage**.
2. Tap **Mount SD card**.

Unmounting the SD card

Unmounting the SD card prevents corruption and damage to the SD card while removing it from the slot.

1. From the main **Settings** page, tap **General** tab → **Storage**.
2. Tap **Unmount SD card** → **OK**.

3. After the “**SD card will be unmounted**” message displays and the **Mount SD card** now appears in the menu list, remove the SD card.

Erasing Files from the SD card

To erase files from the SD card using the device:

1. Ensure the SD card is mounted.
2. From the main **Settings** page, tap **General** tab → **Storage** → **Mount SD card**.
3. Tap **Format SD card** → **Format SD card** → **Delete all** to format the SD card. The SD card formats and erases all the data stored on it.

Security

The Security settings allow you to determine the security level for your device.

Encrypt Device

When enabled, this feature requires a numeric PIN or password to decrypt your device each time you power it on or encrypt the data on your SD card each time it is connected:

1. From the Home screen, press  and then tap **Settings** →  (General tab) → **Security**.
2. Tap **Encrypt device**. For more information, read the displayed help screen.
3. Tap **Encrypt external SD card** to enable the encryption on SD card data that requires a password be entered each time the microSD card is connected.

Tip: Make sure your battery is charged more than 80 percent. Encryption may take an hour or more.

Setting up SIM Card Lock

Prevent another user from using your SIM card to make unauthorized calls or from accessing information stored on your SIM card by protecting the information using a PIN code.

When enabled, your phone will ask for a PIN number each time you use the phone. Using this option you can also change your SIM PIN number.

1. From the main **Settings** page, tap **General** tab → **Security**.
2. Tap **Set up SIM card lock**.
3. Tap **Lock SIM card**, enter your SIM PIN code, then tap **OK**.

Note: You must activate Lock SIM card before you can change your SIM PIN code.

To change an existing SIM Card PIN:

1. Tap **Change SIM PIN**.
2. Enter the old SIM PIN code and tap **OK**.
3. Enter the new SIM PIN code and tap **OK**.
4. Re-type the new SIM PIN code and tap **OK**.

Password Settings

When you create a phone password you can also configure the phone to display the password as you type it instead of using an asterisk (*).

1. From the main **Settings** page, tap **General** tab → **Security**.
2. Tap **Make passwords visible** to activate this feature.

Device Administration

Activating this feature allows Google to administrate your phone in a way similar to IT security settings on a corporate PC. This would be beneficial in the case that your phone was lost or stolen. The phone could be “deactivated” or “restricted” (through administration) from a remote location.

1. From the main **Settings** page, tap **General** tab → **Security**.
2. Tap **Device administrators** to begin configuring this setting.
3. Select an administrator device and follow the prompts.

Unknown Sources

Before you can download a web application you must enable the Unknown sources feature (enables downloading). Developers can use this option to install non-Play Store applications.

1. From the main **Settings** page, tap **General** tab → **Security**.
2. Tap **Unknown sources** to activate this feature.

Verify Apps

Allows you to block or warn yourself before installing apps that can cause harm.

1. From the main **Settings** page, tap **More** tab → **Security**.
2. Tap **Verify apps** to activate this feature.

Note: Enabling this feature can prevent installation of some applications from the Play Store.

DRAFT
Internal Use Only

Credential Storage

This option allows certain applications to access secure certificates and other credentials. Certificates and credentials can be installed to the SD card and password protected.

1. From the main **Settings** page, tap **General** tab → **Security**.
2. Tap **Trusted credentials** to display only trusted CA certificates. A check mark displayed next to the feature indicates secure credentials.
3. Tap **Install from device storage** to install encrypted certificates from the USB Storage location.
4. Tap **Clear credentials** to clear the device (SD card or phone memory) of all certificate contents and reset the credentials password.

About Device

This menu contains legal information, system tutorial information, and other phone information such as the model number, firmware version, baseband version, kernel version, and software build number.

To access phone information:

- From the Home screen, press  and then tap **Settings** →  (General tab) → **About device**. The following information displays:
 - **Software update:** allows you to connect to the network and upload any new phone software directly to your device. The device automatically updates with the latest available software when you access this option.
 - **Updates for preloaded apps:** allows you to configure the parameters for updating preloaded apps.
 - **Status:** displays the Battery status, Battery level (as a percentage), Network, Signal strength, Mobile network type, Service state, Roaming, Mobile network state, My phone number, IMEI, IMEISV, IP address, Wi-Fi MAC address, Bluetooth address, Serial number, Up time, and Device status.

DRAFT
Internal Use Only

- **Legal information:** This option displays information about Open source licences, Google legal information, as well as License settings. This information clearly provides copyright and distribution legal information and facts as well as Google Terms of Service, Terms of Service for Android-powered Phones, and much more pertinent information as a reference. Read the information and terms, then press  to return to the Settings menu.

Tip: To find your device's DivX® registration code and information about registering your device to play DivX protected video, tap **License settings → DivX® VOD**.

- **Device name:** allows you to both display and edit the device's name.
- **Model number:** displays the device's model number.
- **Android version:** displays the firmware version loaded on this device.
- **Baseband version:** displays the baseband version loaded on this device.
- **Kernel version:** displays the kernel version loaded on this device.

- **Build number:** displays the software, build number.

Note: Firmware, baseband, kernel and build numbers are usually used for updates to the handset or support. For additional information please contact your T-Mobile service representative.

- **SELinux status:** displays the status of SELinux. SELinux is a set of security policies/modules which is applied to the device to improve the overall security.

Software Update

The Software Update feature enables you to use your device to connect to the network and upload any new software directly to your device. The device automatically updates with the latest available software when you access this option.

The following icons show your Bluetooth connection status at a glance:



Displays when the Software updated feature is active.



Displays when the Software update feature is in progress.

To update your device:

1. From the Home screen, press  and then tap **Settings** →  (General tab) → **About device** → **Software update**.
2. Read the Software update information screen.
3. Select an available option:

Note: You configure the device's software update parameters.

- **Cancel:** Tap this option to cancel the operation.
- **Wi-Fi settings:** Enable this option to only download available updates via an active Wi-Fi connection. If disabled, the device will begin available downloads via its' T-Mobile connection.
- **OK:** Tap this option to connect to the remote server, detect if there is an available update, the begin the download over your existing data connection.
 - Software updates can include bug fixes, enhancements to services, to the device or currently installed software.

DRAFT
Internal Use Only

Section 11: Health and Safety Information

This device is capable of operating in Wi-Fi™ mode in the 2.4 and 5 GHz bands. The FCC requires that devices operating within 5.15-5.25 GHz may only be used indoors, not outside, in order to avoid interference with Mobile Satellite Services (MSS). Therefore, this device is restricted from being used outdoors when operating in frequencies between 5.15-5.25 GHz.

This section outlines the safety precautions associated with using your phone. The terms “mobile device” or “cell phone” are used in this section to refer to your phone. **Read this information before using your mobile device.**

Exposure to Radio Frequency (RF) Signals

The U.S. Food and Drug Administration (FDA) has published information for consumers relating to Radio Frequency (RF) exposure from wireless phones. The FDA publication includes the following information:

Do cell phones pose a health hazard?

Many people are concerned that cell phone radiation will cause cancer or other serious health hazards. The weight of scientific evidence has not linked cell phones with any health problems.

Cell phones emit low levels of Radio Frequency (RF) energy. Over the past 15 years, scientists have conducted hundreds of studies looking at the biological effects of the radio frequency energy emitted by cell phones. While some researchers have reported biological changes associated with RF energy, these studies have failed to be replicated. The majority of studies published have failed to show an association between exposure to radio frequency from a cell phone and health problems.

The low levels of RF cell phones emit while in use are in the microwave frequency range. They also emit RF at substantially reduced time intervals when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects.

The biological effects of radio frequency energy should not be confused with the effects from other types of electromagnetic energy.

Very high levels of electromagnetic energy, such as is found in X-rays and gamma rays, can ionize biological tissues. Ionization is a process where electrons are stripped away from their normal locations in atoms and molecules. It can permanently damage biological tissues including DNA, the genetic material.

The energy levels associated with radio frequency energy, including both radio waves and microwaves, are not great enough to cause ionization of atoms and molecules. Therefore, RF energy is a type of non-ionizing radiation. Other types of non-ionizing radiation include visible light, infrared radiation (heat), and other forms of electromagnetic radiation with relatively low frequencies.

While RF energy does not ionize particles, large amounts can increase body temperatures and cause tissue damage. Two areas of the body, the eyes and the testes, are particularly vulnerable to RF heating because there is relatively little blood flow in them to carry away excess heat.

Research Results to Date: Is there a connection between RF and certain health problems?

The results of most studies conducted to date say no. In addition, attempts to replicate and confirm the few studies that have shown a connection have failed.

The scientific community at large therefore believes that the weight of scientific evidence does not show an association between exposure to Radio Frequency (RF) from cell phones and adverse health outcomes. Still the scientific community has supported additional research to address gaps in knowledge. Some of these studies are described below.

Interphone Study

Interphone is a large international study designed to determine whether cell phones increase the risk of head and neck cancer. A report published in the International Journal of Epidemiology (June, 2010) compared cell phone usage for more than 5,000 people with brain tumors (glioma and meningioma) and a similar number of healthy controls.

Results of this study did NOT show that cell phones caused brain cancer. In this study, most people had no increased risk of brain cancer from using cell phones. For people with the heaviest use of cell phones (an average of more than ½ hour per day, every day, for over 10 years) the study suggested a

slight increase in brain cancer. However, the authors determined that biases and errors prevented any conclusions being drawn from this data. Additional information about Interphone can be found at

http://www.iarc.fr/en/media-centre/pr/2010/pdfs/pr200_E.pdf.

Interphone is the largest cell phone study to date, but it did not answer all questions about cell phone safety. Additional research is being conducted around the world, and the FDA continues to monitor developments in this field.

International Cohort Study on Mobile Phone Users (COSMOS)

The COSMOS study aims to conduct long-term health monitoring of a large group of people to determine if there are any health issues linked to long-term exposure to radio frequency energy from cell phone use. The COSMOS study will follow approximately 300,000 adult cell phone users in Europe for 20 to 30 years. Additional information about the COSMOS study can be found at

<http://www.ukcosmos.org/index.html>.

Risk of Brain Cancer from Exposure to Radio Frequency Fields in Childhood and Adolescence (MOBI-KIDS)

MOBI-KIDS is an international study investigating the relationship between exposure to radio frequency energy from communication technologies including cell phones and brain cancer in young people. This is an international multi-center study involving 14 European and non-European countries. Additional information about MOBI-KIDS can be found at

http://www.creal.cat/programes-recerca/en_projectes-creal/view.php?ID=39.

Surveillance, Epidemiology, and End Results (SEER) Program of the National Cancer Institute

The National Cancer Institute (NCI) actively follows cancer statistics in the United States to detect any change in rates of new cases for brain cancer. If cell phones play a role in risk for brain cancer, rates should go up, because heavy cell phone use has been common for quite some time in the U.S. Between 1987 and 2005, the overall age-adjusted incidence of brain cancer did not increase. Additional information about SEER can be found at

<http://seer.cancer.gov/>.

Cell Phone Industry Actions

Although the existing scientific data do not justify FDA regulatory actions, the FDA has urged the cell phone industry to take a number of steps, including the following:

- Support-needed research on possible biological effects of RF for the type of signal emitted by cell phones;
- Design cell phones in a way that minimizes any RF exposure to the user; and
- Cooperate in providing users of cell phones with the current information on cell phone use and human health concerns.

The FDA also is working with voluntary standard-setting bodies such as the Institute of Electrical and Electronics Engineers (IEEE), the International Commission on Non-Ionizing Radiation Protection (ICNIRP), and others to assure that safety standards continue to adequately protect the public.

Reducing Exposure: Hands-Free Kits and Other Accessories

Steps to Reduce Exposure to Radio Frequency Energy

If there is a risk from being exposed to radio frequency energy (RF) from cell phones - and at this point we do not know that there is - it is probably very small. But, if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your RF exposure.

- Reduce the amount of time spent using your cell phone;
- Use speaker mode or a headset to place more distance between your head and the cell phone.

Hands-Free Kits

Hands-free kits may include audio or Bluetooth® headsets and various types of body-worn accessories such as belt-clips and holsters. Combinations of these can be used to reduce RF energy absorption from cell phones.

Headsets can substantially reduce exposure because the phone is held away from the head in the user's hand or in approved body-worn accessories. Cell phones marketed in the U.S. are required to meet RF exposure compliance requirements when used against the head and against the body.

DRAFT
Internal Use Only

Because there are no known risks from exposure to RF emissions from cell phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used for convenience and comfort. They are also required by law in many states if you want to use your phone while driving.

Cell Phone Accessories that Claim to Shield the Head from RF Radiation

Because there are no known risks from exposure to RF emissions from cell phones, there is no reason to believe that accessories which claim to shield the head from those emissions reduce risks. Some products that claim to shield the user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone.

Studies have shown that these products generally do not work as advertised. Unlike “hands-free” kits, these so-called “shields” may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption.

Children and Cell Phones

The scientific evidence does not show a danger to any users of cell phones from RF exposure, including children and teenagers. The steps adults can take to reduce RF exposure apply to children and teenagers as well.

- Reduce the amount of time spent on the cell phone;
- Use speaker mode or a headset to place more distance between the head and the cell phone.

Some groups sponsored by other national governments have advised that children be discouraged from using cell phones at all. For example, The Stewart Report from the United Kingdom made such a recommendation in December 2000. In this report, a group of independent experts noted that no evidence exists that using a cell phone causes brain tumors or other ill effects. Their recommendation to limit cell phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

Additional information on the safety of RF exposures from various sources can be obtained from the following organizations (updated 10/1/2010):

- FCC RF Safety Program:
<http://www.fcc.gov/oet/rfsafety/>

- Environmental Protection Agency (EPA):
<http://www.epa.gov/radtown/wireless-tech.html>.
- Occupational Safety and Health Administration (OSHA):
<http://www.osha.gov/SLTC/radiofrequencyradiation/>.
(Note: This web address is case sensitive.)
- National Institute for Occupational Safety and Health (NIOSH):
<http://www.cdc.gov/niosh/>.
- World Health Organization (WHO):
<http://www.who.int/peh-emf/en/>.
- International Commission on Non-Ionizing Radiation Protection:
<http://www.icnirp.de>.
- Health Protection Agency:
<http://www.hpa.org.uk/Topics/Radiation/>.
- US Food and Drug Administration:
<http://www.fda.gov/Radiation-EmittingProducts/RadiationEmittingProductsandProcedures/HomeBusinessandEntertainment/CellPhones/default.htm>.

Specific Absorption Rate (SAR) Certification Information

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for Radio Frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government.

These FCC RF exposure limits are derived from the recommendations of two expert organizations: the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The RF exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg).

DRAFT
Internal Use Only

The FCC SAR limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum reported value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the phone.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the SAR limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. For body-worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the mobile device a minimum of 1.0cm from the body.

Use of other accessories may not ensure compliance with FCC RF exposure guidelines. The FCC has granted an Equipment Authorization for this mobile device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. This mobile phone has a FCC ID number: A3LSMN900T [Model Number: SM-N900T] and the specific SAR levels for this mobile phone can be found at the following FCC website: <http://www.fcc.gov/oet/ea/>.

The SAR information for this device can also be found on Samsung's website: <http://www.samsung.com/sar>.

SAR information on this and other model phones can be accessed online on the FCC's website through <http://transition.fcc.gov/oet/rfsafety/sar.html>. To find information that pertains to a particular model phone, this site uses the phone FCC ID number which is usually printed somewhere on the case of the phone. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular phone, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional SAR information can also be obtained at <http://www.fcc.gov/encyclopedia/specific-absorption-rate-sar-cellular-telephones>.

FCC Part 15 Information to User

Pursuant to part 15.21 of the FCC Rules, you are cautioned that changes or modifications not expressly approved by Samsung could void your authority to operate the device.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Commercial Mobile Alerting System (CMAS)

This device is designed to receive wireless emergency alerts from the Commercial Mobile Alerting System ("CMAS"; which may also be known as the Personal Localized Alerting Network ("PLAN")). If your wireless provider has chosen to participate in CMAS/PLAN, alerts are available while in the provider's coverage area. If you travel outside your provider's coverage area, wireless emergency alerts may not be available. For more information, please contact your wireless provider.

Smart Practices While Driving On the Road - Off the Phone

The primary responsibility of every driver is the safe operation of his or her vehicle.

Responsible drivers understand that no secondary task should be performed while driving whether it be eating, drinking, talking to passengers, or talking on a mobile phone - unless the driver has assessed the driving conditions and is confident that the secondary task will not interfere with their primary responsibility. **Do not engage in any activity while driving a moving vehicle which may cause you to take your eyes off the road or become so absorbed in the activity that your ability to concentrate on the act of driving becomes impaired.** Samsung is committed to promoting responsible driving and giving drivers the tools they need to understand and address distractions.

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. For example, only hands-free use may be permitted in certain areas.

Before answering calls, consider your circumstances. Let the call go to voicemail when driving conditions require. Remember, driving comes first, not the call!

If you consider a call necessary and appropriate, follow these tips:

- Use a hands-free device;
- Secure your phone within easy reach;
- Place calls when you are not moving;
- Plan calls when your car will be stationary;
- Do not engage in stressful or emotional conversations;
- Let the person with whom you are speaking know that you are driving and will suspend the call if necessary;
- Do not take notes or look up phone numbers while driving;

Notice regarding legal restrictions on mounting this device in an automobile:

Laws in some states may prohibit mounting this device on or near the windshield of an automobile. In other states, the law may permit mounting this device only in specific locations in the automobile. Be sure to consult the state and local laws or ordinances where you drive before mounting this device in an automobile. Failure to comply with these restrictions could result in fines, penalties, or other damages.

Never mount this device in a manner that will obstruct the driver's clear view of the street and traffic.

Never use wireless data services such as text messaging, Web browsing, or e-mail while operating a vehicle.

Never watch videos, such as a movie or clip, or play video games while operating a vehicle.

For more information, go to <http://www.ctia.org>.

Battery Use and Safety

Important! Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling of batteries and, particularly, from the continued use of damaged batteries.

- **Do not disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.** Do not put a high degree of pressure on the battery. This can cause leakage or an internal short-circuit, resulting in overheating.

- **Do not let the phone or battery come in contact with liquids.** Liquids can get into the phone's circuits, leading to corrosion. Even when the phone appears to be dry and appears to operate normally, the circuitry could slowly corrode and pose a safety hazard. If the phone and/or battery get wet, have them checked by your service provider or contact Samsung, even if they appear to be working properly.
- **Do not place your battery in or near a heat source.** Excessive heating can damage the phone or the battery and could cause the phone or the battery to explode. Do not dry a wet or damp battery with an appliance or heat source such as a microwave oven, hair dryer, iron, or radiator. Avoid leaving your phone in your car in high temperatures.
- **Do not dispose of the phone or the battery in a fire.** The phone or the battery may explode when overheated.
- **Do not handle a damaged or leaking battery.** Do not let leaking battery fluid come in contact with your eyes, skin or clothing. For safe disposal options, contact your nearest Samsung-authorized service center.

DRAFT

Internal Use Only

- **Avoid dropping the cell phone.** Dropping the phone or the battery, especially on a hard surface, can potentially cause damage to the phone and battery. If you suspect damage to the phone or battery, take it to a service center for inspection.
- **Never use any charger or battery that is damaged in any way.**
- **Do not allow the battery to touch metal objects.** Accidental short-circuiting can occur when a metallic object (coin, key, jewelry, clip, or pen) causes a direct connection between the + and - terminals of the battery (metal strips on the battery), for example when you carry a spare battery in a pocket or bag. Short-circuiting the terminals may damage the battery or the object causing the short-circuiting.

Important! Use only Samsung-approved batteries, and recharge your battery only with Samsung-approved chargers which are specifically designed for your phone.

WARNING!

Use of a non-Samsung-approved battery or charger may present a risk of fire, explosion, leakage, or other hazard. Samsung's warranty does not cover damage to the phone caused by non-Samsung-approved batteries and/or chargers.

- **Do not use incompatible cell phone batteries and chargers.** Some websites and second-hand dealers not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers. Consumers should purchase manufacturer or carrier-recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- **Misuse or use of incompatible phones, batteries, and charging devices could result in damage to the equipment and a possible risk of fire, explosion, or leakage, leading to serious injuries, damages to your phone, or other serious hazard.**

Samsung Mobile Products and Recycling

Samsung cares for the environment and encourages its customers to recycle Samsung mobile devices and genuine Samsung accessories.

Proper disposal of your mobile device and its battery is not only important for safety, it benefits the environment. Batteries must be recycled or disposed of properly.

Recycling programs for your mobile device, batteries, and accessories may not be available in your area.

We've made it easy for you to recycle your old Samsung mobile device by working with respected take-back companies in every state in the country.

Drop It Off

You can drop off your Samsung-branded mobile device and batteries for recycling at one of our numerous Samsung Recycling Direct (SM) locations. A list of these locations may be found at:

http://pages.samsung.com/us/recyclingdirect/usactivities_environment_samsungrecyclingdirect_locations.jsp.

Samsung-branded devices and batteries will be accepted at these locations for no fee.

Consumers may also recycle their used mobile device or batteries at many retail or carrier-provided locations where mobile devices and batteries are sold. Additional information regarding specific locations may be found at: <http://www.epa.gov/epawaste/partnerships/plugin/cellphone/index.htm> or at <http://www.call2recycle.org/>.

Mail It In

The Samsung Mobile Take-Back Program will provide Samsung customers with a free recycling mailing label. Just go to <http://fun.samsungmobileusa.com/recycling/index.jsp> and follow the instructions to print out a free pre-paid postage label and then send your old mobile device or battery to the address listed, via U.S. Mail, for recycling.

Dispose of unwanted electronics through an approved recycler.

To find the nearest recycling location, go to our website:

www.samsung.com/recyclingdirect

Or call, (877) 278-0799.

Follow local regulations regarding disposal of mobile devices and batteries

Dispose of your mobile device and batteries in accordance with local regulations. In some areas, the disposal of these items in household or business trash may be prohibited. Help us protect the environment - recycle!

Warning! Never dispose of batteries in a fire because they may explode.

UL Certified Travel Charger

The Travel Charger for this phone has met applicable UL safety requirements. Please adhere to the following safety instructions per UL guidelines:

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

FOR CONNECTION TO A SUPPLY NOT IN NORTH AMERICA, USE AN ATTACHMENT PLUG ADAPTOR OF THE PROPER CONFIGURATION FOR THE POWER OUTLET.

THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

Display / Touch-Screen

Please note the following information when using your mobile device:

WARNING REGARDING DISPLAY

The display on your mobile device is made of glass or acrylic and could break if your mobile device is dropped or if it receives significant impact. Do not use if screen is broken or cracked as this could cause injury to you.

WARRANTY DISCLAIMER: PROPER USE OF A TOUCH-SCREEN MOBILE DEVICE

If your mobile device has a touch-screen display, please note that a touch-screen responds best to a light touch from the pad of your finger or a non-metallic stylus. Using excessive force or a metallic object when pressing on the touch-screen may damage the tempered glass surface and void the warranty. For more information, please refer to the "Standard Limited Warranty".

DRAFT
Internal Use Only

GPS & AGPS

Certain Samsung mobile devices can use a Global Positioning System (GPS) signal for location-based applications. A GPS uses satellites controlled by the U.S. Government that are subject to changes implemented in accordance with the Department of Defense policy and the 2008 Federal Radio navigation Plan (FRP). Changes may affect the performance of location-based technology on your mobile device.

Certain Samsung mobile devices can also use an Assisted Global Positioning System (AGPS), which obtains information from the cellular network to improve GPS performance. AGPS uses your wireless service provider's network and therefore airtime, data charges, and/or additional charges may apply in accordance with your service plan. Contact your wireless service provider for details.

Your Location

Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile devices which are connected to a wireless network transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. The location-based information

may be shared with third-parties, including your wireless service provider, applications providers, Samsung, and other third-parties providing services.

Use of AGPS in Emergency Calls

When you make an emergency call, the cellular network may activate AGPS technology in your mobile device to tell the emergency responders your approximate location.

AGPS has limitations and **might not work in your area**.

Therefore:

- Always tell the emergency responder your location to the best of your ability; and
- Remain on the mobile device for as long as the emergency responder instructs you.

Navigation

Maps, directions, and other navigation-data, including data relating to your current location, may contain inaccurate or incomplete data, and circumstances can and do change over time. In some areas, complete information may not be available. **Therefore, you should always visually confirm that the navigational instructions are consistent with what you see before following them. All users should pay attention to road conditions, closures, traffic, and all other factors that may impact safe driving or walking. Always obey posted road signs.**

Emergency Calls

This mobile device, like any wireless mobile device, operates using radio signals, wireless and landline networks, as well as user-programmed functions, which cannot guarantee connection in all conditions, areas, or circumstances.

Therefore, you should never rely solely on any wireless mobile device for essential communications (medical emergencies, for example). Before traveling in remote or underdeveloped areas, plan an alternate method of contacting emergency services personnel. Remember, to make or receive any calls, the mobile device must be switched on and in a service area with adequate signal strength.

Emergency calls may not be possible on all wireless mobile device networks or when certain network services and/or mobile device features are in use. Check with local service providers.

To make an emergency call:

1. If the mobile device is not on, switch it on.
2. From the Home screen, tap .

3. Key in the emergency number for your present location (for example, 911 or other official emergency number). Emergency numbers vary by location.

4. Tap .

If certain features are in use (call blocking, for example), you may first need to deactivate those features before you can make an emergency call. Consult your User Manual and your local cellular service provider. When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your mobile device may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

Care and Maintenance

Your mobile device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you fulfill any warranty obligations and allow you to enjoy this product for many years:

DRAFT
Internal Use Only

Keep your Samsung Mobile Device away from:

Liquids of any kind

Keep the mobile device dry. Precipitation, humidity, and liquids contain minerals that will corrode electronic circuits. If the mobile device does get wet, do not accelerate drying with the use of an oven, microwave, or dryer, because this may damage the mobile device and could cause a fire or explosion.

Do not use the mobile device with a wet hand. Doing so may cause an electric shock to you or damage to the mobile device.

Extreme heat or cold

Avoid temperatures below 0°C / 32°F or above 45°C / 113°F.

Microwaves

Do not try to dry your mobile device in a microwave oven. Doing so may cause a fire or explosion.

Dust and dirt

Do not expose your mobile device to dust, dirt, or sand.

Cleaning solutions

Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the mobile device. Wipe it with a soft

cloth slightly dampened in a mild soap-and-water solution.

Shock or vibration

Do not drop, knock, or shake the mobile device. Rough handling can break internal circuit boards.

Paint

Do not paint the mobile device. Paint can clog the device's moving parts or ventilation openings and prevent proper operation.

Responsible Listening

Caution! Avoid potential hearing loss.

Damage to hearing occurs when a person is exposed to loud sounds over time. The risk of hearing loss increases as sound is played louder and for longer durations. Prolonged exposure to loud sounds (including music) is the most common cause of preventable hearing loss. Some scientific research suggests that using portable audio devices, such as portable music players and cell phones, at high volume settings for long durations may lead to permanent noise-induced hearing loss.

This includes the use of headphones (including headsets, earbuds, and Bluetooth® or other wireless devices). Exposure to very loud sound has also been associated in some studies with tinnitus (a ringing in the ear), hypersensitivity to sound, and distorted hearing. Individual susceptibility to noise-induced hearing loss and potential hearing problem varies. Additionally, the amount of sound produced by a portable audio device varies depending on the nature of the sound, the device settings, and the headphones that are used. As a result, there is no single volume setting that is appropriate for everyone or for every combination of sound, settings, and equipment.

You should follow some common sense recommendations when using any portable audio device:

- Always turn the volume down before plugging the earphones into an audio source.
- Set the volume in a quiet environment and select the lowest volume at which you can hear adequately.
- Be aware that you can adapt to higher volume settings over time, not realizing that the higher volume may be harmful to your hearing.

- When using headphones, turn the volume down if you cannot hear the people speaking near you or if the person sitting next to you can hear what you are listening to.
- Do not turn the volume up to block out noisy surroundings. If you choose to listen to your portable device in a noisy environment, use noise-cancelling headphones to block out background environmental noise. By blocking background environment noise, noise cancelling headphones should allow you to hear the music at lower volumes than when using earbuds.
- Limit the amount of time you listen. As the volume increases, less time is required before your hearing could be affected.
- Avoid using headphones after exposure to extremely loud noises, such as rock concerts, that might cause temporary hearing loss. Temporary hearing loss might cause unsafe volumes to sound normal.
- Do not listen at any volume that causes you discomfort. If you experience ringing in your ears, hear muffled speech, or experience any temporary hearing difficulty after listening to your portable audio device, discontinue use and consult your doctor.

You can obtain additional information on this subject from the following sources:

American Academy of Audiology

11730 Plaza American Drive, Suite 300
Reston, VA 20190

Voice: (800) 222-2336

Email: info@audiology.org

Internet:

<http://www.audiology.org/Pages/default.aspx>

National Institute on Deafness and Other Communication Disorders

National Institutes of Health
31 Center Drive, MSC 2320
Bethesda, MD 20892-2320

Email: nidcdinfo@nih.gov

Internet:

<http://www.nidcd.nih.gov/>

National Institute for Occupational Safety and Health (NIOSH)

395 E Street, S.W., Suite 9200
Patriots Plaza Building
Washington, DC 20201

Voice: 1-800-35-NIOSH

(1-800-356-4674)

1-800-CDC-INFO (1-800-232-4636)

Outside the U.S. 513-533-8328

Email: cdcinfo@cdc.gov

Internet:

<http://www.cdc.gov/niosh/topics/noise/default.html>

1-888-232-6348 TTY

Operating Environment

Remember to follow any special regulations in force in any area, and always switch your mobile device off whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the mobile device or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products.

Using Your Mobile Device Near Other Electronic Devices

Most modern electronic equipment is shielded from Radio Frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless mobile device. Consult the manufacturer to discuss alternatives.

Implantable Medical Devices

A minimum separation of six (6) inches should be maintained between a handheld wireless mobile device and an implantable medical device, such as a pacemaker or implantable cardioverter defibrillator, to avoid potential interference with the device.

Persons who have such devices:

- Should ALWAYS keep the mobile device more than six (6) inches from their implantable medical device when the mobile device is turned ON;
- Should not carry the mobile device in a breast pocket;
- Should use the ear opposite the implantable medical device to minimize the potential for interference;
- Should turn the mobile device OFF immediately if there is any reason to suspect that interference is taking place;

- Should read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your wireless mobile device with an implantable medical device, consult your health care provider.

For more information see: <http://www.fcc.gov/oet/rfsafety/rf-faqs.html#>.

Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch your mobile device off in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle before using your mobile device in a motor vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Switch your mobile device off in any facility where posted notices require you to do so.

Potentially Explosive Environments

Switch your mobile device off when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised to switch the mobile device off while at a refueling point (service station).

Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants, or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

When your Device is Wet

Do not turn on your device if it is wet. If your device is already on, turn it off and remove the battery immediately (if the device will not turn off or you cannot remove the battery, leave it as-is). Then, dry the device with a towel and take it to a service center.

FCC Hearing Aid Compatibility (HAC) Regulations for Wireless Devices

The U.S. Federal Communications Commission (FCC) has established requirements for digital wireless mobile devices to be compatible with hearing aids and other assistive hearing devices.

When individuals employing some assistive hearing devices (hearing aids and cochlear implants) use wireless mobile devices, they may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and mobile devices also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless mobile devices to assist hearing device users find mobile devices that may be compatible with their

Internal Use Only

hearing devices. Not all mobile devices have been rated. Mobile devices that are rated have the rating on their box or a label located on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated mobile device successfully. Trying out the mobile device with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Wireless mobile devices rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. M4 is the better/higher of the two ratings. M-ratings refer to enabling acoustic coupling with hearing aids that do not operate in telecoil mode.

T-Ratings: Mobile devices rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. T4 is the better/higher of the two ratings. T-ratings refer to enabling inductive coupling with hearing aids operating in telecoil mode.


Hearing devices may also be rated. Your hearing aid manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise.

Under the current industry standard, American National Standards Institute (ANSI) C63.19, the hearing aid and wireless mobile device rating values are added together to indicate how usable they are together. For example, if a hearing aid meets the M2 level rating and the wireless mobile device meets the M3 level rating, the sum of the two values equals M5.

Under the standard, this should provide the hearing aid user with normal use while using the hearing aid with the particular wireless mobile device. A sum of 6 or more would indicate excellent performance.

However, these are not guarantees that all users will be satisfied. T ratings work similarly.

DRAFT
Internal Use Only



The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

HAC for Newer Technologies

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids.

It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Restricting Children's Access to Your Mobile Device

Your mobile device is not a toy. Do not allow children to play with it because they could hurt themselves and others, damage the mobile device, or make calls that increase your mobile device bill.

Keep the mobile device and all its parts and accessories out of the reach of small children.

FCC Notice and Cautions

FCC Notice

The mobile device may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the mobile device if such interference cannot be eliminated. Vehicles using liquefied petroleum gas (such as propane or butane) must comply with

the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association.

Cautions

Any changes or modifications to your mobile device not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment. Only use approved batteries, antennas, and chargers. The use of any unauthorized accessories may be dangerous and void the mobile device warranty if said accessories cause damage or a defect to the mobile device.

Although your mobile device is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending, or sitting on it.

Other Important Safety Information

- Only qualified personnel should service the mobile device or install the mobile device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Ensure that any mobile devices or related equipment installed in your vehicle are securely mounted.

- Check regularly that all wireless mobile device equipment in your vehicle is mounted and operating properly.
- When using a headset in dry environments, static electricity can build up in the headset and cause a small quick static electrical shock. To minimize the risk of electrostatic discharge from the headset avoid using the headset in extremely dry environments or touch a grounded unpainted metal object to discharge static electricity before inserting the headset.
- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the mobile device, its parts, or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including installed or portable wireless equipment near or in the area over the air bag or in the air bag deployment area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.
- Switch your mobile device off before boarding an aircraft. The use of wireless mobile devices in aircraft is illegal and may be dangerous to the aircraft's operation. Check with appropriate authorities before using any function of a mobile device while on an aircraft.

- Failure to observe these instructions may lead to the suspension or denial of cell phone services to the offender, or legal action, or both.
- While using your device, leave some lights on in the room and do not hold the screen too close to your eyes.
- Seizures or blackouts can occur when you are exposed to flashing lights while watching videos or playing games for extended periods. If you feel any discomfort, stop using the device immediately.
- Reduce risk of repetitive motion injuries. When you repetitively perform actions, such as pressing keys, drawing characters on a touch screen with your fingers, or playing games, you may experience occasional discomfort in your hands, neck, shoulders, or other parts of your body. When using your device for extended periods, hold the device with a relaxed grip, press the keys lightly, and take frequent breaks. If you continue to have discomfort during or after such use, stop use and see a physician.
- If your device has a camera flash or light, do not use the flash or light close to the eyes of people or pets. [122011]

DRAFT
Internal Use Only

Section 12: Warranty Information

Standard Limited Warranty

What is covered and for how long?

SAMSUNG TELECOMMUNICATIONS AMERICA, LLC (“SAMSUNG”) warrants that SAMSUNG’s handsets and accessories (“Products”) are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase by the first consumer purchaser and continuing for the following specified period of time after that date:

Phone	1 Year
Batteries	1 Year
Case/Pouch/Holster	90 Days
Other Phone Accessories	1 Year

What is not covered?

This Limited Warranty is conditioned upon proper use of the Product.

This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abnormal use, abnormal conditions, improper storage, exposure to liquid, moisture, dampness, sand or dirt, neglect, or unusual physical, electrical or electromechanical stress; (b) scratches, dents and cosmetic damage, unless caused by SAMSUNG; (c) defects or damage resulting from excessive force or use of a metallic object when pressing on a touch screen; (d) equipment that has the serial number or the enhancement data code removed, defaced, damaged, altered or made illegible; (e) ordinary wear and tear; (f) defects or damage resulting from the use of Product in conjunction or connection with accessories, products, or ancillary/peripheral equipment not furnished or approved by SAMSUNG; (g) defects or damage resulting from improper testing, operation, maintenance, installation, service, or adjustment not furnished or approved by SAMSUNG; (h) defects or damage resulting from external causes such as collision with an object, fire, flooding, dirt, windstorm, lightning, earthquake, exposure to weather conditions, theft, blown fuse, or improper use of any electrical source; (i) defects or damage resulting from cellular signal reception

or transmission, or viruses or other software problems introduced into the Product; or (j) Product used or purchased outside the United States. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery; (ii) any of the seals on the battery are broken or show evidence of tampering; or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

What are SAMSUNG's obligations?

During the applicable warranty period, provided the Product is returned in accordance with the terms of this Limited Warranty, SAMSUNG will repair or replace the Product, at SAMSUNG's sole option, without charge. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product, or may replace the Product with a rebuilt, reconditioned or new Product.

Repaired/replaced cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Products will be warranted for a period equal to the

remainder of the original Limited Warranty on the original Product or for ninety (90) days, whichever is longer. All replaced Products, parts, components, boards and equipment shall become the property of SAMSUNG. Except to any extent expressly allowed by applicable law, transfer or assignment of this Limited Warranty is prohibited.

What must you do to obtain warranty service?

To obtain service under this Limited Warranty, you must return the Product to an authorized phone service facility in an adequate container for shipping, accompanied by the sales receipt or comparable proof of sale showing the original date of purchase, the serial number of the Product and the seller's name and address.

To obtain assistance on where to deliver the Product, please call SAMSUNG Customer Care at 1-888-987-4357. If SAMSUNG determines that any Product is not covered by this Limited Warranty, you must pay all parts, shipping, and labor charges for the repair or return of such Product.

You should keep a separate backup copy of any contents of the Product before delivering the Product to SAMSUNG for warranty service, as some or all of the contents may be deleted or reformatted during the course of warranty service.

What are the limits on SAMSUNG's liability?

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF SAMSUNG'S RESPONSIBILITIES, AND THE EXCLUSIVE REMEDY REGARDING THE PRODUCTS.

ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SAMSUNG BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR FOR, WITHOUT LIMITATION, COMMERCIAL LOSS OF ANY SORT; LOSS OF USE, TIME, DATA, REPUTATION, OPPORTUNITY, GOODWILL, PROFITS OR SAVINGS; INCONVENIENCE; INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES; OR DAMAGES ARISING FROM THE USE OR INABILITY TO USE THE PRODUCT. SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE DISCLAIMER OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND DISCLAIMERS MAY NOT APPLY TO YOU.

SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE

OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT USED IN CONJUNCTION WITH THE PRODUCT, OR THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE. RESPONSIBILITY FOR THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT RESTS SOLELY WITH THE USER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT.

Nothing in the Product instructions or information shall be construed to create an express warranty of any kind with respect to the Products. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of SAMSUNG regarding the Products or this Limited Warranty.

This Limited Warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

What is the procedure for resolving disputes?

ALL DISPUTES WITH SAMSUNG ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE PRODUCTS SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY.

Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's Product or claim, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty.

For any arbitration in which your total damage claims, exclusive of attorney fees and expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant SAMSUNG its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and SAMSUNG shall pay the remainder of such fees.

Administrative, facility and arbitrator fees for arbitrations in which your total damage claims, exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction.

This arbitration provision also applies to claims against SAMSUNG's employees, representatives and affiliates if any such claim arises from the Product's sale, condition or performance.

You may opt out of this dispute resolution procedure by providing notice to SAMSUNG no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product. To opt out, you must send notice by e-mail to optout@sta.samsung.com, with the subject line: "Arbitration Opt Out." You must include in the opt out e-mail (a) your name and address; (b) the date on which the Product was purchased; (c) the Product model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the Product box; (ii) on the Product information screen, which can be found under "Settings;" (iii) on a label on the back of the Product beneath the battery, if the battery is removable; and (iv) on the outside of the Product if the battery is not removable). Alternatively, you may opt out by calling 1-888-987-4357 no later than 30 calendar days from the date of the first consumer purchaser's purchase of the Product and providing the same information. These are the only two forms of notice that will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and you will continue to enjoy the benefits of the Limited Warranty.

Severability

If any portion of this Limited Warranty is held to be illegal or unenforceable, such partial illegality or unenforceability shall not affect the enforceability of the remainder of the Limited Warranty.

Precautions for Transfer and Disposal

If data stored on this device is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data by means of special software.

To avoid unintended information leaks and other problems of this sort, it is recommended that the device be returned to Samsung's Customer Care Center for an Extended File System (EFS) Clear which will eliminate all user memory and return all settings to default settings. Please contact the **Samsung Customer Care Center** for details.

Important! Please provide warranty information (proof of purchase) to Samsung's Customer Care Center in order to provide this service at no charge. If the warranty has expired on the device, charges may apply.

Samsung Telecommunications America, LLC
1301 E. Lookout Drive
Richardson, Texas 75082
Phone: 1-800-SAMSUNG
Phone: 1-888-987-HELP (4357)

No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice. [111611]

End User License Agreement for Software

IMPORTANT. READ CAREFULLY: This End User License Agreement ("EULA") is a legal agreement between you (either an individual or a single entity) and Samsung Electronics Co., Ltd. ("Samsung") for software, owned by Samsung and its affiliated companies and its third party suppliers and licensors, that accompanies this EULA, which includes computer software and may include associated media, printed materials, "online" or electronic documentation in connection with your use of this device ("Software").

This device requires the use of preloaded software in its normal operation. BY USING THE DEVICE OR ITS PRELOADED SOFTWARE, YOU ACCEPT THE TERMS OF THIS EULA. IF YOU DO NOT ACCEPT THESE TERMS, DO NOT USE THE DEVICE OR THE SOFTWARE.

1. GRANT OF LICENSE. Samsung grants you the following rights provided that you comply with all terms and conditions of this EULA: You may install, use, access, display and run one copy of the Software on the local hard disk(s) or other permanent storage media of one computer and use the Software on a single computer or a mobile device at a time, and you may not make the Software available over a network where it could be used by multiple computers at the same time. You may make one copy of the Software in machine readable form for backup purposes only; provided that the backup copy must include all copyright or other proprietary notices contained on the original.

Certain items of the Software may be subject to open source licenses. The open source license provisions may override some of the terms of this EULA. We make the applicable open source licenses available to you on the Legal Notices section of the Settings menu of your device.

Internal Use Only

2. RESERVATION OF RIGHTS AND OWNERSHIP. Samsung reserves all rights not expressly granted to you in this EULA. The Software is protected by copyright and other intellectual property laws and treaties. Samsung or its suppliers own the title, copyright and other intellectual property rights in the Software. The Software is licensed, not sold.

3. LIMITATIONS ON END USER RIGHTS. You may not reverse engineer, decompile, disassemble, or otherwise attempt to discover the source code or algorithms of, the Software (except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation), or modify, or disable any features of, the Software, or create derivative works based on the Software. You may not rent, lease, lend, sublicense or provide commercial hosting services with the Software.

4. CONSENT TO USE OF DATA. You agree that Samsung and its affiliates may collect and use technical information gathered as part of the product support services related to the Software provided to you, if any, such as IMEI (your device's unique identification number), device number, model name, customer code, access recording, your device's current SW version, MCC (Mobile Country Code), MNC (Mobile Network Code). Samsung and its affiliates may use this information solely to improve their products or to provide customized

services or technologies to you and will not disclose this information in a form that personally identifies you. At all times your information will be treated in accordance with Samsung's Privacy Policy, which can be viewed at: <http://account.samsung.com/membership/pp>.

5. SOFTWARE UPDATES. Samsung may provide to you or make available to you updates, upgrades, supplements and add-on components (if any) of the Software, including bug fixes, service upgrades (parts or whole), products or devices, and updates and enhancements to any software previously installed (including entirely new versions), (collectively "Update") after the date you obtain your initial copy of the Software to improve the Software and ultimately enhance your user experience with your device. This EULA applies to all and any component of the Update that Samsung may provide to you or make available to you after the date you obtain your initial copy of the Software, unless we provide other terms along with such Update. To use Software provided through Update, you must first be licensed for the Software identified by Samsung as eligible for the Update. After the Update, you may no longer use the Software that formed the basis for your Update eligibility. The updated Software version may add new functions and, in some limited cases, may delete existing functions.

While the Update will be generally available, in some limited circumstances, the Software updates will only be offered by your network carrier, and such Software updates will be governed by your contractual relationship with your network carrier.

With the “Automatic Update” function enabled (as in the default setting in the System Update menu in the Setting), your device downloads some Updates automatically from time to time. Your device will, however, ask for your consent before installing any Update. If you choose to disable the “Automatic Update” function, then you can check the availability of new Updates by clicking on the “Check Update” menu in the Setting. We recommend that you check availability of any new Updates periodically for optimal use of your device. If you want to avoid any use of network data for the Update downloads, then you should choose the “Wi-Fi Only” option in the Setting. (Regardless of the option you choose, the “Automatic Update” function downloads Updates only through Wi-Fi connection.)

6. Some features of the Software may require your device to have access to the internet and may be subject to restrictions imposed by your network or internet provider. Unless your device is connected to the internet through Wi-Fi connection, the Software will access through your mobile

network, which may result in additional charges depending on your payment plan. In addition, your enjoyment of some features of the Software may be affected by the suitability and performance of your device hardware or data access.

7. SOFTWARE TRANSFER. You may not transfer this EULA or the rights to the Software granted herein to any third party unless it is in connection with the sale of the mobile device which the Software accompanied. In such event, the transfer must include all of the Software (including all component parts, the media and printed materials, any upgrades, this EULA) and you may not retain any copies of the Software. The transfer may not be an indirect transfer, such as a consignment. Prior to the transfer, the end user receiving the Software must agree to all the EULA terms.

8. EXPORT RESTRICTIONS. You acknowledge that the Software is subject to export restrictions of various countries. You agree to comply with all applicable international and national laws that apply to the Software, including all the applicable export restriction laws and regulations.

9. TERMINATION. This EULA is effective until terminated. Your rights under this License will terminate automatically without notice from Samsung if you fail to comply with any of the

terms and conditions of this EULA. Upon termination of this EULA, you must cease all use of the Software and destroy all copies, full or partial, of the Software.

10. DISCLAIMER OF WARRANTY. UNLESS SEPARATELY STATED IN A WRITTEN EXPRESS LIMITED WARRANTY ACCOMPANYING YOUR DEVICE, ALL SOFTWARE PROVIDED BY SAMSUNG WITH THIS MOBILE DEVICE (WHETHER INCLUDED WITH THE DEVICE, DOWNLOADED, OR OTHERWISE OBTAINED) IS PROVIDED "AS IS" AND ON AN "AS AVAILABLE" BASIS, WITHOUT WARRANTIES OF ANY KIND FROM SAMSUNG, EITHER EXPRESS OR IMPLIED. TO THE FULLEST EXTENT POSSIBLE PURSUANT TO APPLICABLE LAW, SAMSUNG DISCLAIMS ALL WARRANTIES EXPRESS, IMPLIED, OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY OR WORKMANLIKE EFFORT, FITNESS FOR A PARTICULAR PURPOSE, RELIABILITY OR AVAILABILITY, ACCURACY, LACK OF VIRUSES, QUIET ENJOYMENT, NON INFRINGEMENT OF THIRD PARTY RIGHTS OR OTHER VIOLATION OF RIGHTS. SOME JURISDICTIONS DO NOT ALLOW EXCLUSIONS OR LIMITATIONS OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, OBTAINED BY YOU FROM

SAMSUNG OR ITS AFFILIATES SHALL BE DEEMED TO ALTER THIS DISCLAIMER BY SAMSUNG OF WARRANTY REGARDING THE SOFTWARE, OR TO CREATE ANY WARRANTY OF ANY SORT FROM SAMSUNG.

11. THIRD-PARTY APPLICATIONS. Certain third party applications may be included with, or downloaded to this mobile device. Samsung makes no representations whatsoever about any of these applications. Since Samsung has no control over such applications, you acknowledge and agree that Samsung is not responsible for the availability of such applications and is not responsible or liable for any content, advertising, products, services, or other materials on or available from such applications. You expressly acknowledge and agree that use of third party applications is at your sole risk and that the entire risk of unsatisfactory quality, performance, accuracy and effort is with you. It is up to you to take precautions to ensure that whatever you select to use is free of such items as viruses, worms, Trojan horses, and other items of a destructive nature. References on this mobile device to any names, marks, products, or services of any third-parties are provided solely as a convenience to you, and do not constitute or imply an endorsement, sponsorship, or recommendation of, or affiliation with the third party or its products and services. You agree that Samsung shall not be

responsible or liable, directly or indirectly, for any damage or loss, including but not limited to any damage to the mobile device or loss of data, caused or alleged to be caused by, or in connection with, use of or reliance on any such third party content, products, or services available on or through any such application. You acknowledge and agree that the use of any third-party application is governed by such third party application provider's Terms of Use, License Agreement, Privacy Policy, or other such agreement and that any information or personal data you provide, whether knowingly or unknowingly, to such third-party application provider, will be subject to such third party application provider's privacy policy, if such a policy exists. SAMSUNG DISCLAIMS ANY RESPONSIBILITY FOR ANY DISCLOSURE OF INFORMATION OR ANY OTHER PRACTICES OF ANY THIRD PARTY APPLICATION PROVIDER. SAMSUNG EXPRESSLY DISCLAIMS ANY WARRANTY REGARDING WHETHER YOUR PERSONAL INFORMATION IS CAPTURED BY ANY THIRD PARTY APPLICATION PROVIDER OR THE USE TO WHICH SUCH PERSONAL INFORMATION MAY BE PUT BY SUCH THIRD PARTY APPLICATION PROVIDER.

12. SAMSUNG APPLICATIONS. Certain Samsung applications and services may be included with, or downloaded to, this mobile device. Many of them require Samsung Services

membership registration ("Samsung Account"), and your rights and obligations will be set forth in separate Samsung Account terms and conditions and privacy policies. There are non-Samsung Account applications and services that require your consent to their separate terms and conditions and privacy policies. You expressly acknowledge and agree that your use of such applications and services will be subject to the applicable terms and conditions and privacy policies.

13. LIMITATION OF LIABILITY. SAMSUNG WILL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND ARISING OUT OF OR RELATING TO THE USE OR THE INABILITY TO USE THE SOFTWARE OR ANY THIRD PARTY APPLICATION, ITS CONTENT OR FUNCTIONALITY, INCLUDING BUT NOT LIMITED TO DAMAGES CAUSED BY OR RELATED TO ERRORS, OMISSIONS, INTERRUPTIONS, DEFECTS, DELAY IN OPERATION OR TRANSMISSION, COMPUTER VIRUS, FAILURE TO CONNECT, NETWORK CHARGES, IN-APP PURCHASES, AND ALL OTHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES EVEN IF SAMSUNG HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY TO YOU. NOTWITHSTANDING

THE FOREGOING, SAMSUNG ELECTRONIC CO.'S TOTAL LIABILITY TO YOU FOR ALL LOSSES, DAMAGES, CAUSES OF ACTION, INCLUDING BUT NOT LIMITED TO THOSE BASED ON CONTRACT, TORT, OR OTHERWISE, ARISING OUT OF YOUR USE OF THE SOFTWARE OR THIRD PARTY APPLICATIONS ON THIS MOBILE DEVICE, OR ANY OTHER PROVISION OF THIS EULA, SHALL NOT EXCEED THE AMOUNT PURCHASER PAID SPECIFICALLY FOR THIS MOBILE DEVICE OR ANY SUCH THIRD PARTY APPLICATION THAT WAS INCLUDED WITH THIS MOBILE DEVICE. THE FOREGOING LIMITATIONS, EXCLUSIONS, AND DISCLAIMERS (INCLUDING SECTIONS 10, 11, 12 AND 13) SHALL APPLY TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, EVEN IF ANY REMEDY FAILS ITS ESSENTIAL PURPOSE.

14. U.S. GOVERNMENT END USERS RESTRICTED RIGHTS. The Software is licensed only with "restricted rights" and as "commercial items" consisting of "commercial software" and "commercial software documentation" with only those rights as are granted to all other end users pursuant to the terms and conditions herein. All Products are provided only with "restricted rights" with only those rights as are granted to all other end users pursuant to the terms and conditions herein. All Software and Products are provided subject to Federal Acquisition Regulation (FAR) 52.227.19.

15. APPLICABLE LAW. This EULA is governed by the laws of the jurisdiction where you are a resident or, if a resident of the United States, by the laws of the state of Texas, without regard to its conflict of law provisions. This EULA shall not be governed by the UN Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded.

16. DISPUTE RESOLUTION.

(a) Non-United States residents. If a dispute, controversy or difference arising in any way from this EULA or your use of the Software is not amicably settled, it shall be subject to the non-exclusive jurisdiction of the courts of the jurisdiction where you are a resident. Notwithstanding the foregoing, Samsung may apply for injunctive remedies (or an equivalent type of urgent legal relief) in any jurisdiction.

(b) United States residents. ALL DISPUTES WITH SAMSUNG ARISING IN ANY WAY FROM THIS EULA OR YOUR USE OF THE SOFTWARE SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY. Any such dispute shall not be combined or consolidated with any other person's or entity's claim or dispute, and specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class

action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by the applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of Texas, without reference to its choice of laws principles, shall govern the interpretation of the EULA and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the EULA. For any arbitration in which your total damage claims, exclusive of attorney fees and expert witness fees, are \$5,000.00 or less ("Small Claim"), the arbitrator may, if you prevail, award your reasonable attorney fees, expert witness fees and costs as part of any award, but may not grant Samsung its attorney fees, expert witness fees or costs unless it is determined that the claim was brought in bad faith. In a Small Claim case, you shall be required to pay no more than half of the total administrative, facility and arbitrator fees, or \$50.00 of such fees, whichever is less, and Samsung shall pay the remainder of such fees. Administrative, facility and arbitrator fees for arbitrations in which your total damage claims,

exclusive of attorney fees and expert witness fees, exceed \$5,000.00 ("Large Claim") shall be determined according to AAA rules. In a Large Claim case, the arbitrator may grant to the prevailing party, or apportion among the parties, reasonable attorney fees, expert witness fees and costs. Judgment may be entered on the arbitrator's award in any court of competent jurisdiction. This arbitration provision also applies to claims against Samsung's employees, representatives and affiliates if any such claim arises from the licensing or use of the Software. You may opt out of this dispute resolution procedure by providing notice to Samsung no later than 30 calendar days from the date of the first consumer purchaser's purchase of this device. To opt out, you must send notice by e-mail to optout@sta.samsung.com, with the subject line: "Arbitration Opt Out." You must include in the opt out e-mail (a) your name and address; (b) the date on which the device was purchased; (c) the device model name or model number; and (d) the IMEI or MEID or Serial Number, as applicable, if you have it (the IMEI or MEID or Serial Number can be found (i) on the device box; (ii) on the device information screen, which can be found under "Settings;" (iii) on a label on the back of the device beneath the battery, if the battery is removable; and (iv) on the outside of the device if the battery is not

removable). Alternatively, you may opt out by calling 1-888-987-4357 no later than 30 calendar days from the date of the first consumer purchaser's purchase of the device and providing the same information. These are the only two forms of notice that will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect your use of the device or its preloaded Software, and you will continue to enjoy the benefits of this license.

17. ENTIRE AGREEMENT; SEVERABILITY. This EULA is the entire agreement between you and Samsung relating to the Software and supersedes all prior or contemporaneous oral or written communications, proposals and representations with respect to the Software or any other subject matter covered by this EULA. If any provision of this EULA is held to be void, invalid, unenforceable or illegal, the other provisions shall continue in full force and effect. [050113]

DRAFT
Internal Use Only

Numerics

2G Network

Using Only 257

2-Sec Pause

Adding 59

A

Access to My Location 179

Accessibility

Text Booster 177

Accessing

Voicemail 18

Accessory 310

Audio Output 310

Dock Sound 310

Action Memo 42

Creating a New Memo 148

S Pen 44

Add 2 Sec Pause 62

Add to Favorites 96

Adobe PDF 202

Air 41

Air Button 42

Air Call-Accept 60

Air Command 42, 299

Activation 47, 297

On 299

Toolbar 44

Air Gesture

Activate 297

Air Browse 298

Air Call-Accept 298

Air Jump 298

Air Move 298

Answering a Call 60

On 297

Quick Glance 298, 299, 300,

301, 302

Air View 41, 47, 297, 298

On 298

Airplane Mode

On 252

Alarm

Deleting an Existing Alarm 157

Setting 156

Turning Off 157

Alerts

Presidential 108

Alerts on Call 280

Allow Diagnostics 16, 309

AllShare Cast Hub 28

Activation on Device 144

Connecting 143

Set Up Hardware 143

AllShare Play

see Samsung Link 210, 211

AllShareCast Hub 210

AMBER Alerts 108

Disable 109

Android Beam 262

Answering

Home Key 279, 281

Answering a Call 60
Application cache and data
Clearing 202
Application Folders 147
Application Groups
Customizing Names 148
Application Menus
Navigating through 54
Applications
Bloomberg+ 149
Calculator 150
Camera 153
Email 161
Google Mail 163
Google Maps 179
Hide 146
Internet 171
KNOX 178
Messages 182
Sharing with Others 35
Show Disabled 146
Shutting Down 147
Storage Used 313
Using the Camcorder 131

Using the Camera 123
Video 217
Voice Recorder 222
YouTube 228
Applications and Development 145
Apps
Adding 32
Reset Preferences 313
Apps Screen
Customizing 145
Area Code
Auto Assign 283
Audio
Output Mode 310
Audio Output 267
Auto Redial 283, 284
Auto Reject
Configuration 61
Auto Reject List 279
Auto Reject Mode 279
Automatic Answering 280
Automatic Restore 305

B

Back up
My Account 305
My Data 305
Backup and Restore 305
Battery
Charging 13
Display Percentage 14
Extending Life 15
Installing 12
Low Battery Indicator 14
Removal 12
Show Display Percentage 268
Wall Charger 13
Battery Cover
Removal 8
Replace 12
Battery Life
Extending 15
Battery Usage 313
Battery Use & Safety 330
Bigger Font
Setting 277

Blocking Mode 288

On 288

Bloomberg+ 149**Bluetooth** 243

About 243

Changing Name 244

Configure Device Settings 247

Deleting a Paired Device 247

Device Name 16

Disconnecting a Paired Device
247

Media Audio 247

Microphone Function 247

Off 243

On 243

Outgoing Headset Condition 280,
282

Pairing Devices 246

Review Downloaded Files 245

Scanning for other Devices 245

Sending Contact Information 248

Sending Contacts Via 248

Settings 244

Status indicators 243

Turning on and off 243

Visibility 245

Visible Time-Out 245

Bookmarks

Backing Up 308

Brightness

Adjusting 268

Browser

Adding bookmarks 175

Deleting bookmarks 175

Emptying cookies 175

Entering a URL 172

Navigation 171

Options 171

Resetting Default Actions 313

Settings 176

Bubble

Options 104

Sharing 104

Burst Shots 124**Calculator**

Scientific Functions 150

Calendar

Creating An Event 151

Handwriting Mode 151

Settings 152

Call

Accessories 280

Settings 59, 60, 279

Call Alert

Call Vibrations 280, 282

Call Alerts 280**Call Answering/Ending** 279**Call Barring** 283, 284**Call Duration** 72

Resetting Times 72

Call Forwarding 280

Configuring 283

Call Functions 56

Answering 60

Answering w Gestures 60

Background Calling 57

Ending 57

Ending a Call 57

Ending via Status Bar 57

Making a Multi-Party Call 67

- Pause Dialing 62
- Redialing the last number 63
- Vibrate 281
- Wait Dialing 62

Call Rejection 60, 279

Call Settings 279

- Additional Settings 283
- General 279

Call Sound

- Personalize 65

Call Status Tones 280

Call Vibration 280, 282

Call Waiting 68, 283, 284

Caller ID 283

Calling

- Using Wi-Fi 259

Calls

- Auto Reject 279
- Making a 56
- Multi-party 67

Camcorder 131

- Accessing the Video Folder 133
- Settings 128
- Shooting Video 131

Camera 122

- Camera Options 124
- Enabling Share Shot 134
- Quick Settings 126
- Settings 128
- Taking Pictures 123

Care and Maintenance 335

Certificates

- Install 240

Charging battery 13

ChatON 153

- Adding a Buddy 154
- Adding New Buddy 154
- Buddy photo share 130
- Chatting On 155
- Deleting Bubble 155
- Register Service 154

Children and Cell Phones 325

Chrome

- Google 155

Clearing

- Application cache and data 202

Cloud 304

CMAS 108

Collect Diagnostics 16

Commercial Mobile Alerting System (CMAS) 328

Configuration

- Initial 16

Connections

- Accessing the Internet 171

Contact

- Copying to microSD Card 90
- Copying to SIM Card 90
- Creating a New 80
- Linking 86
- New From Keypad 82
- Photo 139

Contact Entry

- Options 86

Contact List

- Options 84

Contact Menus

- Options 85

Contacts

- Adding a Number to Existing 83
- Additional Options 92
- Deleting 84
- Display Options 92, 93
- Displaying Contacts by Name 93
- Export List to microSD 306
- First Name 93
- Groups 94
- Import from microSD 306
- Last Name First 93
- Merge with Samsung Account 84
- Sending All 89
- Setting Default Location 85
- Settings 93
- Share Via 85
- Sharing Settings 93
- Sharing/Sending 89

Contacts List 56

Context Menus 83, 85

- Navigation 55
- Using 55

Cookies

- Emptying 175

Copying Contact 90

Create Folder

- Group Apps 146

Creating a Playlist 186

Creating and sending

- Messages 98

Customizing

- Home screens 34

D

Data

- Auto Sync Data 253
- Restrict Background Data 253

Data Limit

- Setting 253

Data Roaming 255

- Activate/Deactivate 253, 255

Data Usage

- Cycle 253
- Limiting 253

Date

- Selecting Format 310

Date and Time 310

Default Storage

- Assigning 122

Camcorder 122

Camera 122

Deleting

- Message Bubbles 105
- Message Threads 105

Deleting a contact 84

Deregister

- Web Storage 213

Desk Clock 156

Device

- Reset 309

Device Name

- Edit 319

Device Options

- Screen 265

Disable

- Applications 146

Disabled Applications

- Show 146

Display

- Icons 24
- Status Bar 24
- Using Negative Colors 277

Display / Touch-Screen 333

Display Settings 268

Displaying your phone number 56

DivX

Locating VOD Number 219

Overview 219

Registering Your DivX Device 219

Registration Code 319

Do cell phones pose a health hazard?

321

Dock

Sound 310

Downloading

New application 200

Downloads 159

Draft Messages 100

Dropbox 212

Uploading Picture 161

Dual Camera 127

Relocate 127

Resize 127

Dual View

see Dual Camera 127

E

Easy Mode 276

EDGE Network 257

Edit Page 34

Editing a Picture 140

Email 111

Changing Signature 116, 120

Composing 114

Configuring Settings 115

Creating a Spam List 115, 119

Creating an Internet Account 112

Internet Email 112

Opening 113

Refreshing Messages 114

Sending 92

Wi-Fi Download of Attachments
117, 121

Emergency

Alert Preview 108

Alerts 108

Emergency Alert

Configuration 108

Emergency Alerts 108

AMBER 108

Imminent Extreme 108

Message Settings 108

Severe 108

Emergency Calls 335

Making 58

With SIM 58

Without SIM 58

Emoticons 101

Ending

A call 57

Entering Text 73

Erasing Files

Memory Card 315

Evernote 162

Exchange Email 117

Account Setup 117

Composing 118

Configuring Settings 119

Deleting Message 119

Opening 118

Refreshing Messages 118

Exposure to Radio Frequency (RF)

Signals 321

Extreme Alert

Disable 109

F

Facebook

Personalize 291

Predictive Text 291

Factory Data Reset 309

Prior To 306

Favorites Tab 96

FCC Hearing Aid Compatibility (HAC)

Regulations for Wireless Devices 340

FCC Notice and Cautions 342

Fixed Dialing Numbers 285

Flipboard 162

Folder

Create 32

Font 275

Size 275

Style 275

Font Size

Caption 228

Changing 277

Forgot Pattern? 273

G

Gallery

Folder Options 138

Opening 142

Picture-In-Picture 218

Games

Volume 265

Gesture

Settings 297

Gestures

Overview 46

Getting Started 7

Battery 12

Battery Cover 8

Locking/Unlocking the Device 17

microSD card 11

SIM Card 9

Switching Device On/Off 15

Voicemail 17

Gmail 163

Composing a Message 164

Creating an Additional Account
165

Opening 163

Other Options 163

Personalize 291

Refreshing 163

Viewing 164

Google

Backing Up Settings 308

Retrieving Password 165

Settings 166

Signing into Your Account 163

Voice Typing 73

Google Books 191

Google Mail

see also Gmail 164

Google Maps

Enabling a location source 179

Opening a map 180

Google Music 193

Google Now 165, 223

Adjust Settings 166

Google Settings 166

Google Talk

see Hangouts 170

Google Voice Typing

Configuring 292

- Using 74
- GPS & AGPS** 334
- Group**
 - Joining 168
- Group Play** 167
 - Creating a Group 168
 - Dropbox 160
 - Joining a Group 168
 - Share Music 169, 184
 - Share Pictures 130
 - Sharing Pictures 168
 - Spanning Screens 169
- Groups**
 - Adding an Member to an Existing Group 94
 - Creating a new caller group 94
 - Deleting 95
 - Deleting a Caller Group 95
 - Editing a Caller Group 95
 - Removing an Entry 95
 - Settings 95

H

- Handwriting**
 - Language Search 292

- Handwriting** 76
- Haptic Feedback**
 - Turn On/Off 314
 - Vibrate 267
 - Vibration Setting 265
- HDR** 125
- Health and Safety Information** 321
- Hearing Aid**
 - Compatability 288
- Hearing Aids** 278
- Help**
 - In-Device 170
- High Touch Sensitivity** 302
- Hold**
 - Placing a Call on Hold 66
- Home** 30
- Home Screen**
 - Assigning a New 35
 - Changing Wallpaper 38
 - Menu Settings 32
 - Overview 30
- Home screens**
 - Customizing 34

- Homepage**
 - Setting New 174

- Icons**
 - Description 24
 - Indicator 24
 - Status 24
- Images**
 - Assigning as a Contact icon 139
 - Assigning as wallpaper 140
 - Transferring 307
 - Verifying 307
- Importing and Exporting**
 - To micro SIM card 93
- In Call**
 - Options 65
- In call**
 - Options 66
- Incognito** 173
 - Create Window 173
 - Exit Window 174
- Incoming Call**
 - Vibration Setting 265

- Indicator icons** 24
- International Call** 61
- International Calls**
 - Making 61
- Internet** 171
 - Brightness Setting 172
 - Search 172
 - Set Home Page 176
 - Set New Homepage 174
- Internet Email** 111
- IP Address** 318
- IR**
 - Smart Remote 19
- L**
- Language**
 - Select 289, 292
- Latitude** 180
- Linking**
 - Contact Information 86
- Live Wallpaper**
 - Selecting 39
- Location**
 - Settings 181

- Lock Pattern**
 - If I Forgot My Pattern 273
- Lock Screen** 269
 - Changing Wallpaper 39
 - Say Wake-Up Command 270
 - Shortcuts 270
- Logs** 69
 - Accessing 70
 - Accessing from Notifications 70
 - Altering Numbers 71
 - Erasing 72
- Lookout Security** 178
- Low battery indicator** 14
- LTE**
 - Network Mode 256
 - Selecting 256
- LTE Network** 256
- M**
- Magnification**
 - Gestures 277
- Making**
 - Emergency Calls 58
 - International Calls 61
 - New call 56

- Managing Applications**
 - Clearing Application Cache 311
 - Uninstalling Third-party Applications 311
- Market**
 - see Play Store 199
- Marking contact**
 - As a default 88
- Media**
 - Backing Up to microSD Card 307
 - Backing Up to PC 306
- Memory Card**
 - Erasing Files 315
- Merge Calls** 67
- Merge with Google** 84
- Message**
 - Options 99
 - Read 103
 - Register a Number as Spam 104
 - Reply 103, 155
 - Thread Options 104
 - Threads 103

Message Search 105

Message threads 103

Messaging

Adding a Signature 106

Adding Attachments 98

Additional Text 102

Block Unknown Senders 108,
110

Creating and sending 98

Creating and Sending Text
Messages 98

Current Message Options 101

Deleting a message 105

Draft 100

Google Mail 163

Icons on the Status Bar 97

Insert Smiley 101

Locked 100

Menu Options 99

Options 99

Scheduled Messages 100

Settings 106

Signature 106

Spam 100

Text Templates 111

Translate Text 102

Types of Messages 97

Viewing new 103

Messenger 182

micro SIM Card 9

Changing Existing PIN 316

Importing and Exporting 93

Insertion 9

Lock 316

Removal 10

Setting Up Lock 316

microSD Card

Insertion 11

Removal 11

Microsoft Exchange 80, 111

Mobile Data

Activate/Deactivate 253

Set Data Limit 253

Usage 255

Mobile HotSpot 232, 248

Activating 232, 249

Allowed Devices 234, 250

Changing Password 233, 250

Connecting 233, 249

MAC Filtering 234, 250

Transmit Power Mode 251

Mobile HotSpots

Detect and Connect 254

Mobile Networks 255

Data Roaming 255

Mobile Data 255

Mobile Web 171

Entering Text in the Mobile Web
Browser 172

Navigating with the Mobile Web
171

Using Bookmarks 174

Mono

Audio Setup 278

Motion

Activate 300

Air Command 299

Air View 298

Browse Image 300

Direct Call 300

High Touch Sensitivity 302

Mute/Pause 300

- On 300
- Overview 46
- Settings 297
- Smart Alert 300
- Smart Screen 301
- Zoom 300
- Mounting the SD card** 315
- Multi Window**
 - Activate/Deactivate 47
 - Activation 269
 - Close App 53
 - Custom Preset 53
 - Customizing 50
 - Enabling Two Applications 53
 - Increase App Window Size 52
 - Panel Relocation 49
 - Rearrange Apps 50
 - Removing Apps 50
 - Restoring Apps 51
 - Running Multiple Apps 51
 - Switch Arrangement 52
 - Tab Repositioning 49
 - Tiling Windows 53
 - Using 47

- Multi-Party Call** 67
 - Dropping One Participant 68
 - Private conversation 67
- Multi-party call**
 - Setting up 67
- Multi-party calls** 67
- Multi-Tasking**
 - Background Calling 57
 - Watching Videos 218
- Music** 183
 - Adding Music 186
 - Creating a Playlist 186
 - Editing a Playlist 187
 - Making a Song a Ringtone 184
 - Options 184
 - Playing Music 183
 - Removing Music 186, 187
 - Share via Group Play 169
 - Simultaneously Playback 169
 - Using Playlists 186
 - Volume 265
- Music App**
 - Adding Songs to Playlists 198
 - Changing Library View 194

- Changing Settings 195
- Creating a Playlist 197
- Deleting a Playlist 198
- Listening 195
- Music Application 193
- Now Playing Screen 196
- Options While Playing 196
- Playing 195
- Playing a Playlist 198
- Searching for Music 195
- Tab Options 196
- Music File Extensions**
 - 3GP 183
 - AAC 183
 - AAC+ 183
 - eAAC+ 183
 - M4A 183
 - MP3 183
 - MP4 183
 - WMA 183
- Music Files**
 - Removing 187
 - Transferring 187
- My Places** 179, 255

N

Namecard

- Sending 89
- Sending All 89
- Share Via 89

Navigating

- Application Menus 54
- Sub-Menus 54
- Through Screens 40

Navigation

- Go Home 190
- Options 189

Negative Colors 277

Network Mode

- 2G Network 256, 257
- LTE 256
- WCDMA/GSM 256

New applications

- Downloading 200

NFC (Near Field Communication) 262

Non-Market Applications 201

Notification

- Vibration Setting 265

Notification Bar 32

- Using 32

Notification Panel

- Customizing Quick Access 275

Notifications

- Volume 265

O

On/Off Switch 15

One-Handed Operation 296

- On/Off 59, 66

Operating Environment 338

Organizer

- Calculator 150
- World Clock 157

Other Important Safety Information

343

Out of Office

- Message 120
- Settings 120

Outlook 111

Overview

- Home Screen 30

P

Paired Windows

- Multi Window Preset 53

Palm Motion

- Activate 300
- Capture Screen 301
- Mute/Pause 301
- On 139, 300

Passpoint

- On 238

Passwords

- Make Visible 317

Pause Dialing 62

Pen Window 46

Personal Localized Alerting Network (PLAN) 328

Phone

- Icons 24
- Switching on/off 15

Phone number

- Finding 56

DRAFT
Internal Use Only

Phone Ringtone 266

Phone Vibration 266

Photo

Editing 140

Photos

Change Player 130

Options 130, 131, 133

Sharing 130, 131, 133

Picture

Color Correction 141

Face Corrections 141

Frame 141

Set As 139

Streaming from Gallery 138

Picture-In-Picture 218

Pictures

Instant Sharing 134

Sharing 134, 136

Pinning

Memo 148

Play Books 191

Play Store 199

Quick Access 145

Pointer Speed

Configuration 294

Power

Auto Adjust Screen Tone 268

Power Saving

CPU Power 314

Haptic Feedback 314

LCD Adjustment 268

Learning About 314

Screen Power 314

Power Saving Mode 314

Predictive Text

Activation 291

Prepend

Area Code 284

Primary Shortcuts 31

Adding and Deleting 36

Customizing 36

Replacing 37

Q

Quick Dialing 57

Quick Messaging 99

R

Reading Mode 268

Red Eye

Correction 141

Redialing the last number 63

Reducing Exposure

Hands-Free Kits and Other

Accessories 324

Reject Call

Rejection Messages 279

Reject Calls

Managing 60

Reject List

Add To 61

Add to 71

Auto Reject 61

Rejection List

Assigning Multiple Numbers 61

Assigning Single Numbers 61

Rejection Messages

Set Up 279

- Reset** 309
- Reset App Preferences** 313
- Reset Device** 309
- Responsible Listening** 336
- Restarting**
 - Device 17
- Restore** 305
- Restrict**
 - Background Data 253
- Restricting Children's Access to Your Mobile device** 342
- Ringtone**
 - Assigning 281, 287
 - Device 266
 - Volume 265
- rvice** 213

S

- S Beam** 263
 - On 136, 263
 - Sharing Multiple Pictures 137
 - Sharing Pictures 136
- S Finder**
 - Using S Pen 46

- S Note** 204
- S Pen**
 - Functionality 42
 - Handwriting Input 42, 43
 - Kepper Notification 295
 - Overview 41
 - Removing 42
 - Settings 295
 - Taking Screen Shots 43
 - Using 43

- S Translator**
 - Translate Text 204
 - Translate Using Voice 204

- S Voice** 205
 - Using 205

- Samsung Account**
 - Backing Up Bookmarks 308
 - Creating 303
 - Merge Contacts 84

- Samsung Hub**
 - Creating a New Account 207
 - Using 208

- Samsung Keyboard** 75
 - ABC Mode 77

- Changing the Input Type 76
- Enabling 75
- Entering Symbols 78
- Keyboard Swipe 290
- Predictive Text Settings 291
- Reset Settings 290
- Settings 289
- Symbol/Numeric Mode 78

- Samsung Link**
 - Configuring Settings 211
 - Definitions 210
 - Deregister Storage 213
 - Sharing Media 213
 - Web Storage Setup 212

- Samsung Mobile Products and Recycling** 331

- Save a Number**
 - From Keypad 82
- Scan for Nearby Devices** 184

- Scrapbook** 214
 - Copy Using S Pen 46
 - Using S Pen 46

- Screen**
 - Home 30

- Navigation 40
- Screen Capture** 301
 - Taking a Screen Shot 139
- Screen Lock**
 - Set Up 271
 - Sounds 267
- Screen Lock Pattern**
 - Changing 272
 - Creating 271
 - Deleting 272
 - Forgot My Pattern 273
- Screen Mirroring**
 - Activate on Device 144
 - Activation 264
 - On 144, 264
 - Using AllShare Cast Hub 143
- Screen Rotation**
 - Auto-Rotate 268
- Screen Shots**
 - Selective 45
- Screen Timeout** 268
- Screen Unlock**
 - Signature 271
 - Swipe 270

- Screen Write**
 - Using S Pen 46
- Screens**
 - Adding and Deleting 34
 - Customizing 34
 - Rearranging 35
- SD card**
 - Mounting the 315
 - Unmounting 315
- Sending a Namecard** 89
- Sensitivity**
 - High Touch Sensitivity 47, 302
 - Touch Sensitivity 297
- Setting an alarm** 156
- Setting up**
 - Voicemail 17
- Settings** 128, 235
 - Accessing 235
 - Browser 176
 - Call 59
 - Contact list 93
 - Enabling the GPS Satellites 254
 - Enabling Wireless Locations 254
 - Messaging 106

- Tab Overview 235
- Wallpaper 39
- Setup**
 - Initial 16
- Severe Alert**
 - Disable 109
- Share Applications** 35
- Share Shot** 134
 - Activate 127
 - Configuring 136
 - Enabling 135
 - Stop Sharing 136
 - Taking Images 136
- Share Videos** 169
- Shortcuts**
 - Adding from Application Screen 36
 - Adding from Home Screen 36
 - Deleting from a Screen 36
 - Managing 35
 - Primary 31
- Signature Unlock** 271
- SIM**
 - Micro 7, 9

see also micro SIM 9
SketchBook for Galaxy 214

SkyDrive 212

Smart Alarm 157

Smart Clip 42

Using 45

Smart Practices While Driving 328

Smart Screen 47, 297, 301

On 301

Smart Switch 19

Snooze 157

Repeat 156

Software Update 318

Wi-Fi 320

Song

Set As 184

Sound

Adapt Sound 267

Sounds

Hearing Aids 278

Turn Off All 278

Spam 111

Accessing Your Spam Folder 111

Add a Phrase 108, 110

Add Number 100, 101, 104

Assigning Manually 109

Assigning Phone Numbers 109

Block Unknown Numbers 110

Block Unknown Senders 108,
110

Email Addresses 115, 119

Manually Add a Number 108, 109

Match Criteria 110

Registering a Phrase as Spam 110

Settings 108, 109

Spam Messages 100

Assigning 100

Specific Absorption Rate (SAR)

Certification Information 326

Speed Dial

Changing an entry 64

Making a call 64

Removing an entry 64

Setting up entries 63

Split Screens

Group Play 169

Spotify 215

Standard Limited Warranty 345

Status Bar 24

Sub-Menus

Navigation 54

SugarSync 212

SwiftKeyFlow

Samsung Keyboard 290

Swype

see SwiftKey Flow 73

System

Volume 265

System Manager 309

System Tone

Settings 267

T

Task Manager 146

Tethering

Active Icon 231, 252

Disconnecting 231, 252

see USB Tethering 231, 251

Text Booster

Accessibility 177

Text Input

Methods 73

Text Input Method

Selecting 73

Text Templates 111

Create Your Own 111

Text To Speech 293**Text-to-speech**

Configuration 293

Third-Party Applications 311

Uninstalling 202

Time Zone

Selecting 310

Timer

Automatic Answering 280, 282

Tools

Camera 123

TrackPad

Configure 294

Transferring Large Files 136, 263**Transferring Music Files** 187**Translate** 102**Translate Message Bubble** 105**Transmit Power Mode** 251**Travel Wallpaper**

Lock Screen 39

TTS 293**TTY Mode** 287**Twitter**

Predictive Text 291

U**UL Certified Travel Charger** 333**Understanding Your Device** 19

Back View 22

Features 19

Front View 20

Home 30

S Pen 41

Side Views 23

Uninstalling

Third-party applications 202

Unknown Numbers

Blocking Messages 110

Unknown Sources 201**Unlock**

Using a Signature 271

Unmounting

SD card 315

Usage

Battery 313

USB 3.0 19**USB Connections**

As Storage Device 230

USB Settings

As Storage Device 230

USB Tethering 231, 251

Activating 231, 252

Use GPS Satellites 179, 254**Use Wireless Networks** 179, 254**Using Favorites**

Adding Favorites 175

V**Vibrate** 281

Activate/Deactivate 287

Vibration

- Create 286
- Device 266
- Intensity Setup 265

Video

- Picture-In-Picture 218
- Sharing Videos 217
- Volume 265

Videos

- Options 131

Voice Input

- Recognition 293

Voice Search 223, 293

Voice Typing 73

- Configuring 292
- Using 74

Voicemail 287

- Accessing 18
- Setting up 17

Volume Settings

- Adjusting 265

VPN

- Adding 258
- Settings 258

VPN Client 223

W

Wait 62

Wait dialing 62

Wallpaper

- Assign Home 32
- Home and Lock Screens 39

Wallpapers

- Assigning from Gallery 131
- Changing Home Screen 38
- Changing Lock Screen 39
- Changing via Settings Menu 39
- Managing 38

Warranty Information 345

WatchON 224

- Adding a New Room 228
- Changing Channels 226
- Configure Just For You 227
- Customizing Your Remote 224
- Initial Configuration 224
- Locating Programs 226
- Personalize 227
- Settings 227
- Using 226

Web 171

- History 176

Widget

- Adding Widgets 32

Widgets

- Adding and Removing 37
- Moving to a Different Screen 38
- Settings 214
- Stopwatch 158

Wi-Fi

- About 236
- Activating 236
- Calling 259
- Connecting to 237
- Deactivating 237
- Direct Connection 242
- During Sleep 239
- MAC Address 240
- Manually Adding Network 240
- Off 237
- On 135, 236
- Settings 236, 237
- Show Usage 253
- Sortin Entries 238

Status icons 237

Wi-Fi Calling 10

Activating 259, 260

Connection Preferences 261

Icons 262

Launching 261

Settings 260

Wi-Fi Direct 242

Activate and Connect 242

Device Name 16

On 135, 242

World Clock

DST Settings 158

WPA2 PSK 232, 233, 249, 250

WPS PIN

Pairing 241

WPS Push Button

Connect 241

Pairing 241

Y

YouTube

High Quality 229

Settings 228

DRAFT

Internal Use Only