




MMT

Works with
Apple Find My

MF18

Item Finder

Product Manual



Applicable to iOS 14.5 and iPhone 6S or above

Key Features(iOS Only?) Find My app, not available for Android)
1. Locate your lost/misplaced items (out of Bluetooth connection)
If your lost/misplaced item isn't nearby, the Find My app can still help you find it using the Apple EcoChain network, and there are hundreds of millions of iPhone, iPad, and Mac devices around the world, and nearby devices will securely send the location of your lost device to iCloud, and then you can see its location in the Find My app. Apple Cloud will encrypt the data and privacy generated by this operation, so you don't have to worry about privacy leakage.
2. Play a sound (within 100 meters of Bluetooth connection range)
- Open the Find My app, tap on the Devices option, and tap on the device you are looking for.
Click Play Sound and the device will beep so you can find the device by the sound.

Directions for use:
1. MF18 power on
Activate the MF18 by center.
2. Pair MF18
- Open Apple's own Find My app.
Hold the MF18 close to your iPhone, tap the "Items" tab, select "Add New Item", and tap "Other Supported Items".
Click Connect.
Fill in the "Custom Name" to name your MF18 and choose an emoji.
Tap "Agree" to confirm that this MF18 will be linked to your Apple ID.
- Click Done.
3. Enable Lost Mode
Open the Find My app, tap on "MF18", and then tap on the missing MF18 name. Under "Lost mode," click "Enable."

Follow the on-screen instructions and click "Continue" to enter your contact number or email address.
Click "Next" to check the information, and then click "Enable" again to complete the setup.
4. Remove the device
- Open Apple's built-in Find My app, tap "MF18" at the bottom of the screen, and then tap the name you want to delete MF18.
Find Remove Item at the bottom of the list, tap Remove to finish.
Note: After removing MF18 from the app, MF18 will be standby for at least 6 months, you can connect it directly at any time.



WARNING
a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate."
b) The statement "Even used batteries may cause severe injury or death."
c) The statement "Call a local poison control center for treatment information."
d) A statement indicating the compatible battery type (e.g., LR44, CR2032).
e) A statement indicating the nominal battery voltage.
f) The statement "Non-rechargeable batteries are not to be recharged."
g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."
CAUTION
a) The statement "Ensure the batteries are installed correctly according to polarity (+ and -)."
b) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries."
c) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations."
d) The statement "Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children."

WARNING


- INGESTION HAZARD:** This product contains a button cell or battery.
- DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Frequently asked questions:
1. When will I find the MF18?
When an item has been separated from its owner for a period of time, it can be found by other Apple devices in Find My, and the owner can start getting the location of the MF18.
2. How do I confirm if the MF18 is powered on?
After getting the device, press the button in the middle of the device, and the device will sound a beep to indicate that the device has been started. If there is no response, you can try to press the button 5 times to reset and wait for the prompt tone, if there is no response, you can try to replace the battery of the device or contact our after-sales service for processing.
3. How can I prevent MF18 from being used for malicious tracking?
If you notice that someone else's device has been mixed with your belongings for more than a period of time, you will be notified in one of two ways:
(1) If you have an iPhone, iPad, or iPod touch, the Find My app will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
(2) If you don't have an iOS device, when someone else's device tracks you for a while, MF18 will randomly sound an alarm after 8 hours and 24 hours after leaving the owner, these features are specially created to discourage people from trying to track you without your knowledge.
4. Why can't I find the MF18 with Bluetooth connection?
Try resetting the MF18 by pressing and holding the button 5 times. Or you can get a new battery.

Battery:
The MF18 contains a coin cell battery. During use, when the power is low, a new battery needs to be replaced. At present, MF18 only supports batteries of the same type (CR2032) and the same rating, pay attention to the correct polarity.

Replace the battery:
1. Loosen the screws and remove the casing.
2. Split the product into two parts through the gap between the upper and lower lids.
3. Remove the battery.
4. Insert the CR2032 battery into the device with the positive (+) side facing up.
4. Connect the upper and lower covers, and press tightly.



Safety precautions:
Important safety information for handling MF18 with care: It contains sensitive electronic components, including batteries, that may damage, impair functionality or cause injury if dropped, burned, punctured, crushed, disassembled, or exposed to excessive heat or hot liquids, or exposed to high concentrations of industrial chemicals. Do not use damaged MF18.

The company undertakes all the problems caused by the product materials and workmanship. If there is any problem with the product during the specified warranty period, and the reason is justified, the company will deal with it according to the specific requirements of the purchaser:
(1) Free repair of defective products and replacement of new parts.
(2) Replace the product with a new one.
(3) The transportation cost of the product to and from the product shall be borne jointly by the manufacturer and the consumer (the consumer shall bear the transportation cost of sending the product that needs to be overhauled to the manufacturer, and the manufacturer shall bear the transportation cost of sending the new or repaired product back to the consumer). The cost of replacement or the repair of products that do not meet the warranty conditions and the cost of transportation to and from the product are borne by the consumer.

Environmentally friendly treatment:
Old appliances cannot be disposed of with residual waste and must be disposed of separately. Private processing at public collection points is free of charge. It is the responsibility of the owner of the used appliance to bring the appliance to these or similar collection points. With this small personal effort, you contribute to the recycling of valuable raw materials and the disposal of toxic substances.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCC Warning
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.