

Wireless Microphone

Specification

Distance between transmitter and receiver:>20m no barrier

Operating frequency band: 2400MHz~2480MHz

Receiver input: 1/4" (6.3 mm) / 3.5mm unbalanced

Receiver rechargeable Battery: Lithium-ion 3.7V


Receiver charge time:3-4 hours @5V/1A

Maximum Radio-Frequency Power: 4 dBm

How to use


1. Connect the receiver's 6.3mm (1)jack into a microphone input of a mixer, amplifier, HiFi system, or other powered speakers.
2. Turn on the receiver.
3. Turn on one or two microphones. The pairing LED on the receiver (6) will light up orange, or green all the time, it means units are connected successfully. Adjust the volume of the microphone(s) using the VOL+/VOL- (5/6) button.

1. Charge LED indicator, the actual machine is still charging if there is no movement in the three bars. Please let the machine be fully charged for 3 hours until the charging sign in the upper left corner goes out
2. **Microphone(ABCD)**: Connect sign: If sign flash means not connected, If sign keep on means connected already
3. **Power button**: Long press for power on/off, short press for mute
4. Reset volume
5. The volume+
6. The volume-
7. 5V charging port
10. ECHO+ (for C microphone)
11. ECHO- (for C microphone)



Receiver

1. 6.35MM plug
2. Power indicator Light
3. Power button
4. Type-C charging port
5. Charging indicator Light
6. Signal indicator Light
7. Battery compartment



Battery charging of the receiver

1. The receiver cannot be used while charging. When the charging cable is connected, the receiver will automatically power off.
2. Using the supplied USB Type-C cable, connect the Type-C socket side to the socket (4) and the other end to a device with a USB charging socket or to a DC5V power supply (not included).
3. The charging LED indicator (5) will light red. When charging is complete, the LED charging indicator (5) will turn off.



WARNING:

This product can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.

Warm reminder: Please charge units for 3 hours before using it for the first time!!
If the boot fails, please check whether the battery insulation sheet has been removed!!

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.