



Quick Start Guide



AirLock

TSA Find My Lock



How To Reset The Combination

1. Set the dials to the default code 0-0-0.
2. Press and hold the reset button using a pen until it is stuck at a 45-degree angle.
3. Change the dials to your new combination and display it in the combination window
4. Push the reset button back to its original position using a pen.
5. Your lock will now open with the new combination.

Remark:


- Always note down your combination and store it safely.
- Repeat steps 1-4 to change the combination again.
- If you forget your combination, there's no way to reset the lock without it, and no key is provided.



Adding The AirLock To The Find My App

1. Turn on the device


Press and hold the button for 5 seconds, until the AirLock beeps and turn on




2. Pairing The AirLock

Make sure Bluetooth is enabled on your iPhone and follow the procedures below to add the AirLock:


- Open the Find My App
- Select "Items", then tap "Add Item"
- Select "Other Item"



- d) "Searching Items" will pop
- e) Place the AirLock close to your iPhone and wait until "AirLock" is found and tap "Connect"



- f) Follow the pop-up to change the item name and select an emoji for the AirLock, then select continue



- g) Follow the on screen instructions to link the AirLock to your Apple ID and finish set-up

3. Enable Lost Mode

- Open Apple Find My app, tap the items tab, select the AirLock
- Enable Lost Mode
- Follow the instructions, tap continue and enter your phone number or email address
- Confirm the information and customize Lost Message and activate to complete setup

4. Remove The AirLock

- Tap the items tab in the Apple Find My App, select the AirLock and tap "Remove Item" and tap "Remove" to remove the AirLock

Note: The AirLock will beep upon removal and will remain in pairing mode for 10 minutes before entering power saving mode. Press the AirLock button once to enter pairing mode again.

Using The Apple Find My App

1. Play Sound:

Select the "Items" tab in the Apple Find My App, select the AirLock. Click Play Sound, the AirLock will beep when within range.

2. Locate Your Item:

If the AirLock is not nearby, the Find My App can still help track it down using the Find My Network by hundreds of millions of iPhone, iPad and Mac devices around the world. Nearby devices securely send the location of your missing device to iCloud and locate the last seen location.

Instructions For The AirLock

1. Power On

Press and hold the button for 5 seconds to turn on the device; it will beep to indicate it's on.

2. Device Status Confirmation

Tap the button twice quickly. If it beeps, the device is on. If it doesn't, it's off—press and hold the button for 5 seconds to turn it on.

3. Pairing Mode

Remove the device in the app; it will beep but remain on in pairing mode. If not re-paired within 10 minutes, it exits pairing mode. To re-enter pairing mode, press the button once; it will beep and be ready to pair again.

4. Factory Reset

After removing the device from the Find My app and ensuring it's on, double-click the button (it will beep). Then, hold the button for 8 seconds until it beeps again. Release the button to complete the reset. The device is now ready to pair.

5. Power Off

Press the button 5 times within 2 seconds when the device is on. It will beep and then power off.

FAQ:

1. When can the device be located?

The device can be located when it is away from its owner and detectable by other devices in the Find My network.

2. How to check if the device is on?

Click the device button twice. If it beeps, it's on. If not, press and hold the button for five seconds to turn it on.

3. Preventing unwanted tracking

You'll be alerted if a Find My device that's not with its owner moves with you over time:

- Using an iPhone, iPad, or iPod touch, you'll get a notification.
- Without a smartphone, the device will make a noise if moved.


4. How is my privacy protected?

Only you can see your item's location. Location data is encrypted and not stored on the device. Devices helping to locate your item remain anonymous.

5. Replacing the battery:

- Turn the battery cover on the back 90 degrees counterclockwise with a coin or screwdriver.
 - Insert a new battery with the positive side up.
- Close and secure the cover to restart the device.

The AirLock uses CR2032 battery, replace the battery as shown below:





Works with

Apple Find My

The Apple Find My network provides an easy, secure way to locate The AirLock using the FindMy app on your iPhone, iPad, Mac or the Find Items app on Apple Watch.

To use the Apple Find My app to locate AirLock, the latest version of iOS, iPadOS, macOS and the Find Items app on watchOS.

Use of the Works with Apple Badge means that a product has been designed to work and certified by manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. 10S is trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.